


# Mojikoo

## S01 User Manual




**18-month Warranty**


After-sales mailbox:  
**support@mojikoo.com**

Thank you for purchasing Mojikoo!  
Please read these instructions carefully before use and retain for future reference.


# FRONT VIEW



## BACK VIEW




# TOP VIEW



# BOTTOM VIEW

Auto-Dimmer Switch ON/OFF  
(Slide "☀️ AUTO" switch to the "ON" position, the smart dimming sensor will adjust the display brightness on the environmental brightness.)

Battery compartment  
(Battery is built in already)




Power connector

Silicone protective pad

# GETTING STARTED


1. Plug the adapter into a standard household outlet, you will see 12:00 AM on the display and the clock is ready to be set.
2. Please remove the battery tab before use.

## NOTICE:

1. If the display is "blank" after plugging in, please press the "  " button to adjust the brightness to high level.
2. Battery backup for saving TIME/ALARM/NIGHTLIGHT/SLEEP SOUND setting only, the display will go blank and preset alarm will not go off under the battery power.
3. Once the battery is removed and with an interruption of power, the TIME/ALARM/NIGHTLIGHT/SLEEP SOUND need to be reset when the power comes back.

# BLUETOOTH CONNECTION SETTING

1. Press the "BT" to turn on Bluetooth. Press and hold the "BT" for 2 seconds to turn off Bluetooth. When Bluetooth is ON, the "BT" icon will flash on the display.



2. Turn on Bluetooth on your phone and connect with the device "S01". The "BT" icon will stop flashing on the display upon connecting successfully.

3. When music is playing, press "−" or "+" button to change the music. Press the "BT" to pause the music and press again to play.


4. Press "🔊" or "🔊" to adjust volume with a range of 01-32 level. The default volume is 16 level.

## NOTICE:

- 1.The Bluetooth will automatically turn off if fails to connect to the phone within 5 minutes.
2. If a call comes in, the Bluetooth will stop playing the music.
3. Place your machine and phone no more than 10 meters(33ft) away from each other.

## TIME ZONE SELECTION

- 1.Press the "⌚" button, the time zone options will flash, and the time in the corresponding time zone will flash immediately after 3 seconds. Press "⌚" repeatedly to select one of five time zones.(01=EST;02=CST;03=MST;04=PST;05=AKST).






2.If the time zone options, for example “04(PST)” and the time in the corresponding time zone, totally flashes more than 12 seconds, the time zone “04(PST)” will be confirmed automatically and exit from Time Zone Selection Mode.

### NOTICE:

- 1.Press any button except the "⌚" button to confirm your time zone quickly.
- 2.If you are located outside the above time zones, please follow the **MANUAL TIME SETTING** steps below to set the correct time.


## TIME SETTING

1. Press and hold the "⌚" button for 2 seconds to enter HOUR setting. The HOUR digits will flash on the display. Press “-” or “+” button to advance to the correct hour(hold for rapid setting).



2. Press the “⌚” button second time to confirm and enter MINUTE setting.

When the MINUTE digits flash , press “-” or “+” button to advance to the correct minute (hold for rapid setting).



3. Press the “⌚” button third time to confirm and enter TIME FORMAT (12/24H) setting.

"12H" will flash, it means 12 hour mode, the default is 12-hour time format.


4. Press “-” or “+” button to select time format. "24H" will flash, it means 24 hour mode.


5. Press the “⌚” button fourth time to confirm and exit the time setting mode.

## NOTICE:

- 1.The clock will exit automatically from the time setting mode if no action is taken within 10 seconds.
- 2.When using the 12-hour time format, the AM icon will be appeared for 12:00 midnight through 11:59am, and the PM icon will be appeared for 12:00 noon through 11:59pm.
- 3.24-hour time fomate does not display AM or PM.


## ALARM ON/OFF

To switch the alarm on or off, press and hold “” for 2 seconds. The alarm icon will appear when the alarm is on.




# ALARM SETTING

1. Press the “🕒” button first time to enter ALARM HOUR setting. The HOUR digits will flash on the display. Press “-” or “+” button to advance to the desired hour.




2. Press the “🕒” button second time to confirm and enter ALARM MINUTE setting. The MINUTE digits will flash on the display. Press “-” or “+” button to advance to the desired minute.




3. Press the “⌚” button third time to confirm and enter WAKE UP SOUND setting.

The alarm sound options will display, and the alarm sound will ring. Press “-” or “+” button to choose one of eight built-in alarm sounds (01=Bird Chirping; 02=Piano; 03=Soft Music; 04=Wind-bell; 05=Ocean Wave; 06=Siren; 07=Beep; 08=Buzzer)





"A 01" Flash and Bird Chirping Ring

4. Press the “🔔” button fourth time to confirm and enter ALARM VOLUME setting.  
Press “🔊” or “🔊” to adjust the alarm volume, 01-32 level adjustable. The default alarm volume is 16 level.



5. Press the “🔔” button fifth time to confirm and exit the alarm setting mode.

## **SNOOZE/TURN OFF ALARM DAILY**


1. When the alarm goes off, press “” button to snooze, the alarm icon will flash on the display. The alarm will go off again 9 minutes later.
2. To cancel the snooze at any time or to TURN OFF this day alarm while it is sounding, press “” button. The alarm will go off again at the same time the next day.

### **NOTICE:**

The alarm will automatically turn off after 15 minutes if no action is taken.

# WHITE NOISE SOUND MACHINE

1. Press the “🎵” button, sound machine will be ON /OFF.



2. Press the “🔊” button to increase the volume.

Press the “🔊” button to decrease the volume.(1-32 adjustable)



## NOTICE:

1. When Bluetooth music is turned on, press the “🎵” button to turn off the Bluetooth, the sleep sound will turn on, and the sound icon appear.

2. The sleep sound machine has a memory function: When the function is turned on next time, the music and volume will be the same as before it was turned off.



# PICKING YOUR SOUNDS


When sound machine is on, press “” or “” button to switch among all the 24 sounds in sequence.

Here is the list of tracks			
S01	White Noise 1	S14	Heartbeat
S02	White Noise 2	S15	Shush
S03	White Noise 3	S16	Rain
S04	White Noise 4	S17	Thunderstorm
S05	White Noise 5	S18	Brook
S06	White Noise 6	S19	Cricket Chirping
S07	Fan 1	S20	Train
S08	Fan 2	S21	Forest
S09	Fan 3	S22	Wind
S10	Fan 4	S23	Yoga Music
S11	Bird Chirping	S24	Meditation
S12	Lullary		
S13	Ocean Wave		

# NIGHTLIGHT SETTING

1. In normal time display mode, press "💡" to turn on the night light.
2. Press "💡" repeatedly to choose among 9 different night light color options. 9 colors change as shown in the following sequence: orange, yellow, red, green, indigo, blue, purple, RGB color, breathing light.
3. Press and hold the "⌚" button for 3 seconds to adjust the night light brightness when it lights up, 10%-100% brightness adjustable.
4. Press and hold "💡" for 3 seconds (release it) to turn the light off.

Nightlight ON/OFF &  
Change Color




## NOTICE:

The night light will default to the last color you choose when you reopen it.

# SLEEP TIMER SETTING

You can use sleep timer to turn off sleep sound/bluetooth/nightlight automatically when the preset sleep timer comes.

1. Press the “⌚” button repeatedly to select the sleep timer ranging from 30,60,90,120,180, 240 minutes to OFF. The sleep timer will be shown on display.
2. When the sleep timer is set, please wait 5 seconds to exit from the setup. The “⌚” indicator will be shown on the display.
3. Press the “⌚” button repeatedly to select " OFF " option to turn off sleep timer.
4. When sleep timer is on, press “⌚” button to see the sleep timer remained.



## NOTICE:

1. When the nightlight and the sleep sound are both on, the sleep timer can only be set for both.
2. When the nightlight and the bluetooth are both on, the sleep timer can only be set for both.

# BRIGHTNESS CONTROL

The display brightness control has two modes: Automatic and manual.


## Automatic Dimmer Mode

Slide "☀️ AUTO" switch to the "ON" position at the bottom of the clock.


The smart dimming sensor will adjust the display brightness on the environmental brightness.


### NOTICE:

1. The default Auto-Dimmer is OFF.
2. When the Auto-Dimmer is ON, you cannot manually adjust the brightness via top button "☀️".



## Manual Dimmer Mode

There are 5 brightness levels for LED display. Press the "  " repeatedly to adjust the display brightness when the Auto Dimmer Switch is OFF.



Repeatedly press to adjust the display brightness(5 levels)

# BATTERY & MEMORY FUNTION

Install 1 \* CR2032 battery into battery compartment for memory function.

(Battery is built in already)



## NOTICE:

1.Under the battery power, the display will go blank and preset alarm will not go off.

Battery power is for saving TIME/ALARM Settings only.

2.Sleep sounds and volume memory: When the sleep sound is turned off and turned on again, the sounds and volume are the same as before.

3.Light memory: When the light is turned off and turned on again, the color of the light is the last one.

 <b>WARNING</b>	
<ul style="list-style-type: none"><li>• <b>INGESTION HAZARD:</b> This product contains a button or coin cell battery.</li><li>• <b>DEATH</b> or serious injury can occur if ingested.</li><li>• <b>A</b> swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours.</li><li>• <b>KEEP</b> new and used batteries <b>OUT OF REACH of CHILDREN</b></li><li>• <b>Seek immediate medical attention</b> if a battery is suspected to be swallowed or inserted inside any part of the body.</li></ul>	

# RESTORE FACTORY SETTINGS

Unplug the power and remove the backup battery device to restore factory settings.

## SPECIFICATIONS


Power Input: DC, 5V/2A

Power: AC, 100-240V (50/60Hz)

Speaker Output: 5 Watt RMS

## TROUBLESHOOTING

### 1. Display doesn't light up?

- Check if the power connection is loosed or not;
- Change another working outlet to try again;
- Press "  " to adjust the brightness to high level.


### 2. Press the top " " button can't adjust the display brightness manually?

- Slide "  AUTO " switch at the bottom of the clock to the "OFF" position.

### 3. Alarm doesn't go off at the set time?

- Check if the alarm is set to AM or PM time;
- Check if the alarm is turn on (alarm icon display on the screen)

#### 4. How to turn off the alarm completely?

In the normal time display, you can turn the alarm off completely by pressing and hold the "  " for 2 seconds.

The alarm icon will be disappear when the alarm is disabled.

#### 5. How Do I Fix Bluetooth Connection Issues?

- Confirm it's not paired with other devices.
- Forget all Bluetooth pairing records on your device.
- Unplug and remove the battery to reset, set again after power cycle.
- Disable and enable Bluetooth on your device.
- Try to connect the speaker to another device.

## WARRANTY & SUPPORT

- We offer a 45 day money-back guarantee and 18-month free replacement.
- Mojikoo customer support is committed to providing you with best-in-class service.

For assistance, please keep the model number and order ID number of this product, then contact us by sending email, email address as below:

**[support@mojikoo.com](mailto:support@mojikoo.com)**



FCC STATEMENT This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/ TV technician for help.

FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, Human proximity to the antenna shall not be less than 20cm(8 inches)during normal operation