

# 1/32 Scale Collectable Racers

60-4308

OWNER'S MANUAL — Please read before using this equipment.

## ! IMPORTANT !

If an icon appears at the end of a paragraph, go to the box on that page with the corresponding icon for pertinent information.

- Warning     — Important  
 — Caution     — Hint  
 — Note


## WARNING

Dispose of batteries promptly and properly. Do not burn or bury them.


Thank you for buying a RadioShack 1/32 Scale Collectable Racer. Built to 1/32 scale, it can reach speeds of up to 270-300 feet per minute. While you are not racing, you can show off your racer and transmitter using the supplied display base..

Your racer comes in one of these exciting designs. Collect all three and have a vehicle perfect for any driving situation!


Your racer comes in two frequencies (27 MHz and 49 MHz), so you and your friends can drive together. Check the box to see which frequency you have.



Mercedes-Benz CLK  
DTM 2000



PT Cruiser



Chevy SSR

## CAUTION

- Use only fresh batteries of the required size and recommended type.
- If you do not plan to use the vehicle for a week or more, remove the batteries from the transmitter and the vehicle. Batteries can leak chemicals that can damage electronic parts.
- Never leave dead or weak batteries in the vehicle or transmitter.

## INSTALLING BATTERIES

### IN THE TRANSMITTER

You need one 9V battery (not supplied, available at your local RadioShack store) to power the transmitter. For the best performance and longest life, we recommend a RadioShack alkaline battery.

1. Slide the transmitter's ON/OFF switch to OFF.
2. Slide the battery compartment cover in the direction of the arrow and lift it off.
3. Put the battery in the compartment as indicated by the polarity symbols (+ and -) marked inside.



**RadioShack®**

www.radioshack.com<sup>SM</sup>

© 2002 RadioShack Corporation.

All Rights Reserved.

RadioShack and RadioShack.com are trademarks used by RadioShack Corporation.

### **⚠ WARNING ⚠**

Never play with your racer in the street.

### **⚡ CAUTION ⚡**

If the vehicle gets stuck under an object, immediately release both buttons on the transmitter. Then retrieve the vehicle.

### **💡 HELPFUL HINT 💡**

- Running your racer continuously for long periods generates high heat levels. Heat causes wear and tear on the motor. To help keep heat levels down, when your racer's batteries die, let the racer cool at least 10 minutes before installing new batteries.
- If the racer's motor runs but does not respond to the transmitter, move closer to the racer and try again.
- If someone uses a CB nearby, it might interfere with control of the racer. If this happens, move the racer away from the CB.
- You cannot operate your racer near devices with transmitters that use the same frequency as your racer (27 or 49 MHz). Check the box to see which frequency you have.
- If the racer moves slowly and you have installed new batteries, check the wheel mechanisms for lint, thread, hair, or dust.

4. Replace the cover and snap it shut.

When the transmitter's range decreases, replace its battery.

## **IN THE RACER**

You need two AA alkaline batteries (not supplied) to power the racer.

1. Slide **ON/OFF** on the bottom of the racer to **OFF**.
2. Use a Phillips screwdriver to loosen the screw on the battery compartment cover, then remove the cover.
3. Insert two AA batteries in the supplied adapter according to the polarity symbols (+ and -) marked inside.
4. Replace the cover and secure it with the screw.

When the racer runs slowly or not at all or does not respond to the transmitter, replace the batteries.

## **DRIVING THE RACER ⚠ 💡**

1. Set **ON/OFF** on the bottom of the racer to **ON**.
2. Set **ON/OFF** on the transmitter to **ON**. The indicator on the transmitter lights.
3. Use the transmitter's control buttons to drive and steer the racer. ⚡


### *Left Control Button*

- Press forward to move forward.
- Press backward to move backward.
- Release to stop.

### *Right Control Button*

- Press left to turn left.
- Press right to turn right.
- Release to go straight.

4. When you finish driving the racer, slide **ON/OFF** on the vehicle and **ON/OFF** on the transmitter to **OFF**.



## FCC DECLARATION OF CONFORMITY

This device complies with Part 15 of the *FCC Rules*. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Product:	1/32 Scale Collectable Racers
Model:	60-4308
Responsible Party:	RadioShack 100 Throckmorton Fort Worth, TX 76102
Phone:	817-415-3200



## THE FCC WANTS YOU TO KNOW

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the *FCC Rules*. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

## WHEEL ALIGNMENT

If the racer does not drive in a straight line when you release the right control button, adjust the wheel alignment control on the bottom of the racer.

Turn the control toward L if the racer is pulling to the right or toward R if the racer is pulling to the left.

#### Limited Ninety-Day Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from RadioShack company- owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, crash, collision, impact, violent contact, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations, 200 Taylor Street, 6th Floor, Fort Worth, TX 76102

12/99

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult your local RadioShack store or an experienced radio/TV technician for help.

If you cannot eliminate the interference, the FCC requires that you stop using your racer.

Changes or modifications not expressly approved by RadioShack may cause interference and void the user's authority to operate the equipment.

## CARE

Keep the racer dry; if it gets wet, wipe it dry immediately. Use and store the racer only in normal temperature environments. Handle the racer carefully; do not drop it. Keep the racer away from dust and dirt, and wipe it with a damp cloth occasionally to keep it looking new.

## SERVICE AND REPAIR

If your racer is not performing as it should, take it to your local RadioShack store for assistance. Modifying or tampering with the racer's internal components can cause a malfunction and might invalidate its warranty and void your FCC authorization to operate it.