


Quick Start Guide

P12



EN DE

English


1. Product Introduction

1.1 Packing List



The complimentary ribbon has been installed in the printer and can be seen through the Window.


1.2 Printer Parts Instruction



2. Getting Started

2.1 Downloading the App

Method 1: Search for the "Print Master" app on App Store® or Google Play™ to download and install it.



Method 2: Scan the QR code to download the app. Simply scan the code with your cell phone's camera, the built-in scanning feature of your browser, or a dedicated scanning app.




As the Safari browser on Apple devices does not support direct QR code scanning, please use your device's built-in QR code scanner instead.

2.2 Power Supply Instructions

Method 1: Direct Power Supply via Type-C Cable


- Ensure you have a Type-A port adapter that supplies 5-volt, 2-amp DC power (5V/2A).
- Insert the Type-C end (flat end) of the USB cable into the Type-C Charger Port of P12 and connect the Type-A end (narrow end) into the corresponding port of the power adapter.
- Once the printer is connected to a power outlet via the power adapter, power it up by long pressing the Power Button for 3 seconds until the Indicator Light illuminates steadily in green.
- As the printer may generate heat during operation when powered, please avoid placing it on materials such as cotton or linen when it is in use. After printing is completed, promptly unplug the original cable and the power adapter.

Powering the printer directly through the Type-C cable will not charge any installed dry cells.




Method 2: Installing 6 New AAA Alkaline Dry Cells (User-supplied)

- Find the Bottom Cover Open Mark, place your thumb on it, and pull open the Bottom Cover.
- Properly insert the dry cells according to the positive and negative indicators within the Dry Cell Compartment.




- Align the Bottom Cover hooks with holes ①②③ in the Main Body. Push the Bottom Cover inward until it clicks, which indicates that it has been securely closed.



Upon installing the dry cells, power up the printer by long pressing the Power Button for 3 seconds. If the Indicator Light is not on or flashes red, please check:
① if the dry cells are brand new;
② if the dry cells are correctly inserted.

2.3 User Guide


- Remove the protective film.
- Push the Cutter Button to cut off the blank label.
- Long press the Power Button for 3 seconds until the Indicator Light is green to power up the printer.
- Open the "Print Master" app.



- Click [Auto Connect].



- Grant Authorization.




For more information about app permissions, see 6.2 Permission Description in the Online Guide.

- Wait for the printer to be found.



You can also find manual connection options on [Home]. For more details, see 5. More Connection Methods in this guide.

- The printer is successfully connected.




- Edit your first label, and tap [Print] after you finish editing.




- Printing is completed.




- Push the Cutter Button and peel off the printed label.




- Remove the carbon ribbon.



- Peel off the back liner along the Easy Tear Line on the back of the label.






- Attach the label to a dry, flat surface.




3. Replacing the Label Ribbon

- Place your thumb on the Cover Opening and pull it outward to open the Top Cover.
- Remove the label ribbon to be replaced.
- Take out a new label ribbon.
- Remove the anti-loosening sticker.




Please skip this step if there is no brand new label ribbon (Packaged in Bag) separately purchased.




Please skip this step if the label ribbon to be installed is not brand new.


- Check if the label ribbon has been pulled to the dashed line position as indicated in the diagram; if not, please follow the instructions on the right-hand diagram.




- Place the label ribbon into the Ribbon Compartment and feed the extended ribbon into the Paper Outlet; then press down on the label ribbon until you hear a click, indicating the installation is complete.



- Align the Top Cover clasps with marked holes ①②③ on the Main Body.



- Push the Top Cover inward until it clicks, which indicates that it has been securely closed. Ribbon installation is now completed.




4. Cleaning and Maintenance

In the case of blurry print, try cleaning the Print Head. When the printer functions properly, it is recommended to perform cleaning and maintenance every 6 months.

- Long press the Power Button for 3 seconds until the Indicator Light is off to turn off the printer.
- Open the Top Cover and remove the label ribbon.




- Use a cotton swab dipped in a small dab of alcohol to gently wipe the Print Head up and down about 10 times.



Please avoid scraping the Print Head with any hard objects, as it may cause damage to the Print Head and worsen print quality.



- After wiping, wait 5 seconds for the alcohol to evaporate. Then, reinstall the label ribbon to complete the cleaning process.




For detailed instructions on installing a label ribbon, see steps 05-08 in 3. Replacing the Label Ribbon in this guide.

5. More Connection Methods

- Select your printer.
- Tap [] at the top right corner for connection.
- Wait for the printer to be discovered.
- The printer is successfully connected.



6. Additional Instructions



6.1 Button Instructions

Button Type	Action	Function
Power Button	Long press for 3s	Power on/off
	Double press	Print a self-test page

6.2 Indicator Light Instructions

Status	Description	Advised Action
Solid Green Light	Device functioning properly	/
Solid Red Light	Label ribbon missing/ No ribbon detected	Reinstall label ribbon
Flashing Red Light	Low battery	Please replace the alkaline dry batteries
Light remains off after long pressing Power Button for 3 seconds	Battery depleted	Please replace the alkaline dry batteries

For instructions on reinstalling the label ribbon, see 3. Replacing the Label Ribbon in this guide. For replacing Alkaline Dry Batteries instruction, see 2.2 Power supply Instructions in this guide.

7. Accessing Detailed Online Guide

Scan the QR code to access the Detailed Online Guide, video tutorials.



Special Notes

The company assumes full responsibility for the revision and explanation of this manual, exercising utmost diligence to guarantee its accuracy. Nevertheless, please note that any technical improvements to the product may not be separately notified, and that the images of the product, accessories, software interfaces, etc. in this manual serve solely as illustrations and references. Due to product updates and upgrades, the actual product may vary slightly from the images. Please refer to the physical product for accurate representations.

FCC Warning statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

IC Warning statement

CAN ICES(B)/NMB(B)

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.

L' émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d' Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L' exploitation est autorisée aux deux conditions suivantes:

- L' appareil ne doit pas produire de brouillage;
- L' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d' en compromettre le fonctionnement.

IC RF exposure statement:

The device has been evaluated to meet general IC RF exposure requirement. The device can be used in portable exposure condition without restriction.

IC Déclaration d'exposition aux RF:

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF d'IC. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.

This device complies with part 15 of the FCC rules and RSS-247 of Industry Canada. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.