

FIBOCOM NL668-LA Series Hardware Guide

Version: V1.0.7 Date: 2021-05-12



Applicability Type

No.	Product Model	Description
1	NL668-LA	MCP is 2+1, support MAIN_ANT, DIV_ANT, GNSS_ANT
2	NL668-LA-30	MCP is 4+2, support MAIN_ANT, DIV_ANT, GNSS_ANT
3	NL668-LA-05	MCP is 2+1, support MAIN_ANT, DIV_ANT, GNSS_ANT
4	NL668-LA-10	MCP is 1+1, support MAIN_ANT, DIV_ANT, GNSS_ANT



Copyright

Copyright ©2021 Fibocom Wireless Inc. All rights reserved.

Without the prior written permission of the copyright holder, any company or individual is prohibited to excerpt, copy any part of or the entire document, or transmit the document in any form.

Notice

The document is subject to update from time to time owing to the product version upgrade or other reasons. Unless otherwise specified, the document only serves as the user guide. All the statements, information and suggestions contained in the document do not constitute any explicit or implicit guarantee.

Trademark



The trademark is registered and owned by Fibocom Wireless Inc.

Change History

Version	Author	Reviewer	Approver	Update Date	Description
V1.0.7	Guo Zhenqi	Tan Lefan		2021-05-10	Modify pin 138 refer to design description
V1.0.6	Tan Lefan	Hu Wenkai	Luke Liu	2021-03-10	Add model NL668-LA-05 and NL668-LA-10
V1.0.5	Lee Du	Hu Wenkai	Luke Liu	2020-08-10	Update product appearance
V1.0.4	Hu Wenkai	Lee Du	Luke Liu	2020-03-13	Update power consumption
V1.0.3	Lee Du	Hu Wenkai	Luke Liu	2020-01-10	Add model NL668-LA-01
V1.0.2	Tan Lefan	Hu Wenkai	Luke Liu	2019-10-09	Modify module size. Increase the requirements of boot_config1, 2, 3 pins forbidden to pull up externally.
V1.0.1	Liu Qiang	Li Xiyi	Chen Guojiang	2019-07-09	Update RF parameters
V1.0.0	Gao Ying	Tu Min	Chen Guojiang	2019-06-06	Initial version

Content

1	Introd	duction		8
	1.1	Docume	ent Introduction	8
	1.2	Safety I	Precautions	8
2	Produ	uct Overv	view	10
	2.1	Product	t Introduction	10
	2.2	Product	t Specification	10
	2.3	Functio	nal Diagram	11
	2.4	Evaluat	ion Board	12
3	Pin D	escriptio	on	13
	3.1	Pin Ass	ignment	13
	3.2	Pin Fun	nction	13
4	Elect	rical Cha	racteristics	21
	4.1	Power.		21
	4.2	Power S	Supply	21
	4.3	1.8V Ou	utput	22
	4.4	Power (Consumption	23
5	Func	tional Int	erface	26
	5.1	Control	Interface	26
	5.	1.1 Power	On/Off	26
		5.1.1.1	Power On	26
		5.1.1.2	Power Off	27
	5.	1.2 RESE	Τ	28
	5.2	Network	k Status Indicate Interface	
	5.	2.1 Interfa	ce Status Description	30
	5.3	(U)SIM	Card Interface	31
	5.	3.1 (U)SIN	1 Pin Definition	
	5.	3.2 (U)SIN	1 Interface Circuit	32
		5.3.2.1	(U)SIM Card Connector with Card Detection Signal	32
		5.3.2.2	(U)SIM Card Connector Without Detection Signal	33
	5.	3.3 (U)SIN	1 Hot Plug	33
	5.	3.4 (U)SIN	1 Design Requirements	34
	5.4	USB Int	terface	35
	5.	4.1 USB P	Pin Definition	35

	5.5	UART Interface	35
		5.5.1 UART Interface Definition	35
		5.5.2 UART Port Application	36
	5.6	ADC Interface	37
	5.7	PCM Interface	38
		5.7.1 Supported Model	38
		5.7.2 PCM Interface Definition	38
		5.7.3 PCM Interface Description	38
		5.7.4 PCM Signal Description	39
6	L٥١	w Power Consumption	41
	6.1	Airplane Mode	41
	6.2	Sleep Mode	41
		6.2.1 USB Application (Nonsupport USB Suspend, Support VBUS)	41
		6.2.2 USB Application (Nonsupport USB Suspend, Nonsupport VBUS)	42
		6.2.3 USB Application (Support USB Suspend)	42
		6.2.4 UART Application (WAKEUP_IN Pin Level Control)	42
		6.2.5 UART Application (DTR Pin Level Control)	43
		6.2.6 ATS24 Command	43
7	RF	Interface	45
	7.1	Operating Bands	45
	7.2	Output Power	45
	7.3	Receive Sensitivity	46
	7.4	GNSS Receiver	48
		7.4.1 GNSS Specification	48
		7.4.2 GNSS Observe Protocol	48
	7.5	Antenna Design	48
		7.5.1 Antenna Index	48
		7.5.2 Antenna Reference Design	50
8	Re	liability	53
	8.1	Limiting Voltage Range	53
		8.1.1 Absolute Voltage Range	53
		8.1.2 Operating Voltage Range	53
	8.2	Environment Temperature Range	53
	8.3	Environmental Reliability Requirements	54

	8.4	ESD Characteristics	.54
9	Structu	re Specification	56
	9.1	Product Appearance	.56
	9.2	Structure Dimension	.56
	9.3	PCB Soldering Pad and Stencil Design	.57
	9.4	SMT	.57
	9.5	Carrier and storage	.57
	0.0		
10	Арј	proval	58
10 11	Apj Apj	proval pendixes	58 59
10 11	Apj Apj 11.1	broval bendixes GPRS and EGPRS Encoding Scheme	58 59 .59
10 11	Apj Apj 11.1 11.2	Dendixes GPRS and EGPRS Encoding Scheme Terms and Acronyms	58 59 .59 .60
10 11	Apj Apj 11.1 11.2 11.3	Dendixes GPRS and EGPRS Encoding Scheme Terms and Acronyms Related Documents	58 59 .59 .60 .62
10 11	Apj Apj 11.1 11.2 11.3 11.4	broval bendixes	58 59 .59 .60 .62 .62

1 Introduction

1.1 Document Introduction

This document describes the electrical characteristics, RF performance, structure size, application environment, etc. of NL668-LA module. With the assistance of the document and other instructions, the developers can quickly understand the hardware functions of the NL668-LA module and develop products.

1.2 Safety Precautions

By following the safety guidelines below, you can protect the personal safety and help protect the product and work environment from potential damage. Product manufacturers need to communicate the following safety instructions to end users. In case of failure to comply with these safety rules, Fibocom Wireless will not be responsible for the consequences caused by the user's misuse.



Road safety first! When you drive, do not use the handheld devices even if it has a hand-free feature. Please stop and call!



Please turn off the mobile device before boarding. The wireless feature of the mobile device is not allowed on the aircraft to prevent interference with the aircraft communication system. Ignoring this note may result in flight safety issue or even breaking the law.

When in a hospital or health care facility, please be aware of restrictions on the use of mobile devices. Radio frequency interference may cause medical equipment to malfunction, so it may be necessary to turn off the mobile device.

The mobile device does not guarantee that an effective connection can be made under any circumstances, for example, when there is no prepayment for the mobile device or the (U)SIM is invalid. When you encounter the above situation in an emergency, remember to use an emergency call, while keeping your device turned on and in areas where signal is strong.



Your mobile device receives and transmits RF signals when it is powered on. Radio interference occurs when it is near televisions, radios, computers, or other electronic devices.





Keep the mobile device away from flammable gases. Turn off the mobile device when near gas stations, oil depots, chemical plants or explosive workplaces. There is a safety hazard in operating electronic equipment in any potentially explosive environment.

2 Product Overview

2.1 Product Introduction

The NL668-LA series wireless module is a broadband wireless terminal product applicable to various network formats and multi-bands include TDD-LTE/FDD-LTE/WCDMA/GSM.

2.2 Product Specification

Table 2-1	Product	specification
-----------	---------	---------------

Specification						
	NL668-LA	LTE FDD: Band 1, 2, 3, 4, 5, 7, 8, 12, 17, 28, 66				
Operating	NL668-LA-05	LTE TDD: Band 38, 40				
frequency	NL668-LA-10	A-10 WCDMA/HSPA+: Band 1, 2, 3, 4, 5, 8				
	NL668-LA-30	GSM/GPRS/ED0	GE: 850/900/1800/1900MHz			
			150Mbps DL/50Mbps UL (Cat 4) LTE Downlink MIMO			
		LIE FUU Nei.9	2×2, 4×2 (support part of R10)			
			130Mbps DL/30.5Mbps UL (Cat 4) LTE Downlink MIMO			
			2×2, 4×2 (support part of R10)			
Data transr	nission		UMTS: 384 kbps DL/384 kbps UL			
Data transi	11331011	WCDMA Rel.8	DC-HSDPA+: 42MbpsDL (Cat24)/HSUPA:5.76Mbps UL			
			(Cat 6)			
			GPRS: 107kbps DL/85.6kbps UL (multi-slot class 33)			
		Bel 5	EDGE(E-GPRS): 296kbps DL/236.8kbps UL (multi-slot			
			class 33)			
Power		3.3V to 4.3V (typical 3.8V)				
		Normal: -30°C to +75°C				
Temperatur	re	Extended:-40°C	to +85°C			
		Storage:-40°C to +90°C				
		Base current: < 2mA				
Power cons	sumption	Sleep mode: ≤ 4mA				
		Idle mode: < 20mA (USB sleep), < 30mA (USB wakeup)				
Physical ch	aracteristics	Package: LCC+L	-GA 144 Pin			
Physical charactenstics		Size: (32.0±0.15) mm × (29.0±0.15) mm × (2.4±0.2) mm			



	Weight: about 5.2g				
Interface					
Antenna	Antenna: MAIN, GNSS, DIV				
	(U)SIM 3.0V/1.8V				
	USB 2.0				
Functional Interface	Status Indicator				
	UART x 2, PCM, I2C, SGMII, SPI, SDIO, GPIOs				
	ADC x 2				
Software					
Protocol Stack	Embedded TCP/IP and UDP/IP protocol stack				
AT Command	3GPP TS 27.007 and 27.005, and proprietary FIBOCOM AT				
Firmware update	USB (UART does not support DOWNLOAD)				
Voice convice	VoLTE, HR, FR, EFR, AMR, DTMF, Caller ID, Call Transfer, Call Hold, Call				
	Waiting and Multi-Talk, etc.				
SMS	point-to-point MO, MT; cell broadcast; support Text and PDU modes				

Note:

When the temperature is beyond the normal operating temperature range (-30 °C to + 75 °C), the RF performance of the module may slightly exceed the 3GPP specification.

2.3 Functional Diagram

Functional diagram shows the main hardware features of the NL668-LA series module, including

baseband and RF features.

Baseband includes:

- PMIC
- MCP
- USB, (U)SIM, PCM, I2C, SPI, UART, SGMII, SDIO, GPIOs
- GSM/CDMA/EVDO/WCDMA/TD-SCDMA/LTE TDD/LTE FDD controller

RF includes:

- RF Transceiver
- RF PA
- RF filter
- Antenna



2.4 Evaluation Board

Fibocom provides EVK-GT8230-NL, ADP-NL668-LA evaluation board to convenient module's debug and use.

3 Pin Description

3.1 Pin Assignment

The NL668-LA series module is available in 144 pins. The numbers of the LCC pins are 80, and the LGA pins are 64. the top view of the pin assignment is shown as follow figure:



Figure 3-1 Pin assignment (top view diagram)



Note:

85 to 112 are thermal pins, and the module is grounded internally. It is recommended that the heat sink pad is reserved for PCB packaging and welded.

3.2 Pin Function

Table 3-1 I/O description parameters

Symbol	Description
Ю	Input/Output
DI	Digital input
DO	Digital output
Ы	Power input
PO	Power output
AI	Analog input
AO	Analog output
OD	Open drain
ос	Open collector

The pin function description of NL668-LA series module is shown as table 3-2:

Pin No.	Pin Name	I/O	Level	Description
			V⊩min=-0.3V	External device wake-up module, low
4			V⊩max=0.6V	active by default. with software
1	WAREUP_IN	1	V⊮min=1.2V	programmable option. Boot_config GPIO,
			V⊮max=2.0V	forbidden to pull-up externally.
			V⊩min=-0.3V	
0			V⊩max=0.6V	Deserved
2	AP_READY	1	V⊮min=1.2V	Reserved
			V⊮max=2.0V	
3	RESERVED	-	-	Reserved
	W_DISABLE#		V⊩min=-0.3V	Medule flight mede central pull up by
4		I	V⊩max=0.6V	default. Pull down this pin, module enter
4			V⊮min=1.2V	
			V⊮max=2.0V	
			Vo∟max=0.45V	Module network state indicate (by
5	NET_MODE	0	Vон min=1.35 V	default), Boot_config GPIO, forbidden to
				pull-up externally.
0			Volmax=0.45V	
б	NET_STATUS	0	Vон min=1.35 V	Module network state indicate
7	VDD_EXT	PO	1.8V	Module digital level, 1.8V output, 80mA
8	GND	G	-	Ground
9	GND	G	-	Ground
10	GND	G	-	Ground

Table 3-2 Pin function description



Pin No.	Pin Name	I/O	Level	Description
11	DBG_RXD	I	V⊩min=-0.3V V⊩max=0.6V V⊩min=1.2V V⊩max=2.0V	Debug serial port receive data
12	DBG_TXD	0	Vo∟max=0.45V Voнmin=1.35V	Debug serial port transmit data
13	USIM_PRESENCE	I	V⊩min=-0.3V V⊩max=0.6V V⊩min=1.2V V⊩max=2.0V	(U)SIM card hot plug detection
14	USIM_VDD	PO	For 1.8V (U)SIM: Vmax=1.9V Vmin=1.7V For 3.0V (U)SIM: Vmax=3.05V Vmin=2.7V Iomax=50mA	(U)SIM power, identify 1.8V or 3V (U)SIM card automatically
15	USIM_DATA	Ю	For 1.8V (U)SIM: VILmax=0.6V VIHmin=1.2V VoLmax=0.45V VoHmin=1.35V For 3.0V (U)SIM: VILmax=1.0V VIHmin=1.95V VoLmax=0.45V VOHmin=2.55V	(U)SIM data signal
16	USIM_CLK	0	For 1.8V (U)SIM: Volmax=0.45V Vohmin=1.35V For 3.0V (U)SIM: Volmax=0.45V Vohmin=2.55V	(U)SIM clock signal
17	USIM_RST	0	For 1.8V (U)SIM: VoLmax=0.45V Voнmin=1.35V For 3.0V (U)SIM:	(U)SIM reset signal



Pin No.	Pin Name	I/O	Level	Description
			Vo∟max=0.45V	
			Vон min=2.55 V	
18	NC	-	-	NC
19	GND	G	-	Ground
20	RESET_N	I	V⊪max=2.1V V⊩min=1.3V V⊩max=0.5V	Module reset signal, active low, no need pull up externally
21	PWRKEY	I	V⊪max=2.1V V⊪min=1.3V V⊩max=0.5V	Module power on/off signal, active low, no need pull up externally. The input is pulled up to an internal voltage minus a diode drop. As per the design, this causes the voltage of the pin is about 0.8V
22	GND	G	-	Ground
23	SD_INS_DET	I	-	Reserved
24	PCM_IN	I	V⊩min=-0.3V V⊩max=0.6V V⊩min=1.2V V⊩max=2.0V	PCM input signal
25	PCM_OUT	0	Vo∟max=0.45V Voнmin=1.35V	PCM output signal
26	PCM_SYNC	Ю	Vo∟max=0.45V Voнmin=1.35V Vi∟min=-0.3V Vi∟max=0.6V Viнmin=1.2V Viнmax=2.0V	PCM synchronization signal
27	PCM_CLK	Ю	Vo∟max=0.45V Voнmin=1.35V Vi∟min=-0.3V Vi∟max=0.6V Viнmin=1.2V Viнmax=2.0V	PCM clock signal
28	SDC2_DATA3	10	-	Reserved
29	SDC2_DATA2	10	-	Reserved
30	SDC2_DATA1	Ю	-	Reserved
31	SDC2_DATA0	Ю	-	Reserved
32	SDC2_CLK	0	-	Reserved

Pin No.	Pin Name	I/O	Level	Description
33	SDC2_CMD	IO	-	Reserved
34	VREG_L13_2P85	PO	-	Reserved
35	ANT_DIV	I	-	Diversity antenna
36	GND	-	-	Ground
37	SPI_CS_N	0	-	Reserved
38	SPI_MOSI	0	-	Reserved
39	SPI_MISO	I	-	Reserved
40	SPI_CLK	0	-	Reserved
41	I2C_SCL	OD	-	I2C interface clock signal
42	I2C_SDA	OD	-	I2C interface data signal
43	NC	-	-	NC
44	ADC1	I	-	Analog to digital converter interface1
45	ADC0	I	-	Analog to digital converter interface 0
46	GND	G	-	Ground
47	ANT_GNSS	I	-	GNSS antenna
48	GND	-	-	Ground
49	ANT_MAIN	IO	-	Main antenna
50	GND	G	-	Ground
51	GND	G	-	Ground
52	GND	G	-	Ground
53	GND	G	-	Ground
54	GND	G	-	Ground
55	NC	-	-	NC
56	GND	G	-	Ground
			Vmax=4.3V	
57	VBAT_RF	ΡI	Vmin=3.3V	RF power input (3.3V~4.3V)
			Vnorm=3.8V	
			Vmax=4.3V	
58	VBAT_RF	ΡI	Vmin=3.3V	RF power input (3.3V~4.3V)
			Vnorm=3.8V	
			Vmax=4.3V	
59	VBAT_BB	ΡI	Vmin=3.3V	Baseband power input (3.3V~4.3V)
			Vnorm=3.8V	
			Vmax=4.3V	
60	VBAT_BB	ΡI	Vmin=3.3V	Baseband Power Input (3.3V~4.3V)
			Vnorm=3.8V	



Pin No.	Pin Name	I/O	Level	Description
61	STATUS	0	Voнmin=1.35V	Module network state indicate
01	01/100	Ŭ	Vo∟max=0.45V	
62	BI	0	Vo∟max=0.45V	Module output ring indicator
02	111		Vон min=1.3 5V	Noulle output hing indicator
63		0	Vo∟max=0.45V	Module output data carrier detection
		Ŭ	Vон min=1.35 V	
64	CTS	0	Vo∟max=0.45V	Bequest to send
04	013	0	Vон min=1.35 V	
			V⊩min=-0.3V	
CE.	DTO		V⊩max=0.6V	Clear to send
65		1	V⊩min=1.2V	
			V⊪max=2.0V	
			V⊩min=-0.3V	
66	DTB		V⊩max=0.6V	Data ready. The control of the sleep mode
00		•	V⊩min=1.2V	Data ready. The control of the sleep mode
			V⊪max=2.0V	
67	TXD	0	Vo∟max=0.45V	Transmit data
07			Vон min=1.35 V	
	RXD	I	V⊩min=-0.3V	
68			V⊩max=0.6V	Receive data
00			V⊩min=1.2V	neceive dala
			V⊪max=2.0V	
			Conform to	
69	USB_DP	Ю	USB2.0 standard	USB differential data bus (+)
			specification	
			Conform to	
70	USB_DM	Ю	USB2.0 standard	USB differential data bus (-)
			specification	
			Vmax=5.25V	
71	USB_VBUS	ΡI	Vmin=3.0V	USB plug detection
			Vnorm=5.0V	
72,76	GND	G	-	Ground
73,82	RESERVED	-	-	Reserved
74,75,77~	NC	-	-	NC
81,83,84				
85~112	GND	G	-	GND
113	NC	-	-	NC



Pin No.	Pin Name	I/O	Level	Description
114	NC	-	-	NC
			V⊩min=-0.3V	
115	USB_BOOT		V⊩max=0.6V	Emergency download, active high,
115		1	V⊮min=1.2V	recommended to reserve test point
			V⊮max=2.0V	
116	NC	-	-	NC
117	RESERVED	-	-	Reserved
118	WLAN_SLP_CLK	0	-	Reserved
119	EPHY_RST_N	0	-	Reserved
120	EPHY_INT_N	Ι	-	Reserved
121	SGMII_MDATA	IO	-	Reserved
122	SGMII_MCLK	0	-	Reserved
123	SGMII_TX_M	0	-	Reserved
124	SGMII_TX_P	0	-	Reserved
125	SGMII_RX_P	I	-	Reserved
126	SGMII_RX_M	I	-	Reserved
127	PM_ENABLE	0	-	Reserved
128	VREG_L5_UIM2	PO	-	Reserved
129	SDC1_DATA3	IO	-	Reserved
130	SDC1_DATA2	Ю	-	Reserved
131	SDC1_DATA1	Ю	-	Reserved
132	SDC1_DATA0	IO	-	Reserved
133	SDC1_CLK	0		Reserved
134	SDC1_CMD	0	-	Reserved
135	WAKE_WLAN	I		Reserved
136	WLAN_EN	0	-	Reserved
137	COEX_UART_RXD	Ι	-	Reserved
				Reserved, Boot_config GPIO, forbidden
				to pull-up externally.
138		0	_	(Applicable to NL668-LA-00 and
100		Ŭ		NL668-LA-01.
				But NL668-LA-05 and NL668-LA-10 are
				not subject to this restriction)
139	BT_EN	0	-	Reserved
140	NC	-	-	NC
141	RESERVED	-	-	Reserved



Pin No.	Pin Name	I/O	Level	Description
142	RESERVED	-	-	Reserved
143	RESERVED	-	-	Reserved
144	RESERVED	-	-	Reserved



Keep the unused pins floating. The reserved pins are in development.

4 Electrical Characteristics

4.1 Power

Table 4-1 show the power interface of NL668-LA series module.

Table 4-1 Power interface

Pin Name	I/O	Pin	Description
VBAT_RF	PI	57, 58	Module power supply, 3.3V~4.3V, typical value 3.8V
VBAT_BB	PI	59, 60	Module power supply, 3.3V~4.3V, typical value 3.8V
VDD_EXT	PO	7	Module digital voltage output, 1.8V, 80mA
		8, 9, 10, 19, 22, 36, 46,	
GND	G	48, 50–54, 56, 72, 76,	All GND pins must be grounded
		85–112	

Mote:

In the rest of the document, VBAT includes VBAT_BB and VBAT_RF.

4.2 Power Supply

The NL668-LA series module needs to be powered by the VBAT pin. The recommend power design is shown in Figure 4-1:



Figure 4-1 Recommend power design



Recommended Capacitor	Application	Description
		Reduce power fluctuations during
		module operation, requiring low ESR
		Capacitor
220uF x 2	Regulating capacitor	LDO or DCDC power requires not
		less than 440uF capacitor
		Battery power can be properly
		reduced to 100uF ~ 220uF capacitor
	Disital size of a size	Filter clock and digital signal
10F, 100nF	Digital signal noise	interference
39pF, 33pF	700, 850/900 MHz bands	Filter low band RF interference
	1700/1800/1900,2100/2300,2500/	Filter middle/high band RF
18рг, 8.2рг, 6.8рг	2600MHz bands	interference

Table 4-2 Fi	ilter capacito	ors design of p	power supply

The power stability can ensure the normal operation of NL668-LA module. The power supply ripple limit for the module is no more than 300mV (the circuit ESR < $100m\Omega$) requires special attention when design circuit.

When the module is operating in GSM mode (Burst transmit), the maximum operating current can reach 3A, and the power voltage needs to be at least 3.3V. Otherwise, the module may power off or restart. The power limit is shown in Figure 4-2:





4.3 1.8V Output

The NL668-LA series module outputs a 1.8V voltage through the VDD_EXT for the use of the internal digital circuit of module. The voltage is the logic level of the module and can be used to indicate module

Power on/off, or for external low current (< 80mA) circuits. leave the signal floating if no use. The logic level of VDD_EXT is defined as follows:

Table 4-3 VDD_EXT logic level

Parameter	Minimum	Typical	Maximum	Unit
VDD_EXT	1.71	1.8	1.89	V

4.4 Power Consumption

The power consumption of NL668-LA series module measured at 3.8V power supply is shown as follow table, for USB sleep and USB wakeup AT commands please refer to 6.1.2 section:

Parameter	Mode	Condition	Average Current Typ. (mA)
loff	Power off	Module power off	0.018
	GSM	MFRMS=5 (USB sleep)	15
	631	MFRMS=5 (USB wakeup)	30
		DRX=8 (USB sleep)	15
	WODIVIA	DRX=8 (USB wakeup)	30
lidle		Paging cycle #64 frames (USB sleep)	15
Radio off		Paging cycle #64 frames (USB wakeup)	30
	LTE TDD	Paging cycle #64 frames (USB sleep)	15
		Paging cycle #64 frames (USB wakeup)	30
	Radio off	AT+CFUN=0,0 (USB sleep)	15
		AT+CFUN=0,0 (USB wakeup)	30
	GSM	MFRMS=5 (USB sleep)	3
	WCDMA	DRX=8 (USB sleep)	3
		Paging cycle #64 frames (USB sleep)	3
1.	LTE FDD	Paging cycle #128 frames (USB sleep)	3
Isleep		Paging cycle #256 frames (USB sleep)	3
		Paging cycle #64 frames (USB sleep)	3
	LTE TDD	Paging cycle #128 frames (USB sleep)	3
		Paging cycle #256 frames (USB sleep)	3

Table 4-4 Power consumption



Parameter	Mode	Condition	Average Current Typ. (mA)
	GSM	GSM850 PCL5	260
		EGSM900 PCL5	260
IGSM-RMS		DCS1800 PCL0	200
		PCS1900 PCL0	200
		GPRS Data transfer GSM850; PCL=5; 1Rx/4Tx	570
Igprs-rms	0000	GPRS Data transfer GSM900; PCL=5; 1Rx/4Tx	570
CS4	GPRS	GPRS Data transfer DCS1800; PCL=0; 1Rx/4Tx	430
		GPRS Data transfer PCS1900; PCL=0; 1Rx/4Tx	430
		EDGE Data transfer GSM850; PCL=8; 1Rx/4Tx	470
FGPBS-BMS	EDGE	EDGE Data transfer GSM900; PCL=8; 1Rx/4Tx	460
MCS9		EDGE Data transfer DCS1800; PCL=2; 1Rx/4Tx	440
		EDGE Data transfer PCS1900; PCL=2; 1Rx/4Tx	440
	WCDMA	WCDMA Data transfer Band 1 @+23.5dBm	650
		WCDMA Data transfer Band 2 @+23.5dBm	620
		WCDMA Data transfer Band 3 @+23.5dBm	700
Iwcdma-rms		WCDMA Data transfer Band 4 @+23.5dBm	700
		WCDMA Data transfer Band 5 @+23.5dBm	550
		WCDMA Data transfer Band VIII@+23.5dBm	570
		LTE FDD Data transfer Band 1 @+23dBm	650
		LTE FDD Data transfer Band 2 @+23dBm	650
I _{LTE-RMS}	LTE FDD	LTE FDD Data transfer Band 3	730
		LTE FDD Data transfer Band 4 @+23dBm	700



Parameter	Mode	Condition	Average Current Typ. (mA)
		LTE FDD Data transfer Band 5 @+23dBm	580
		LTE FDD Data transfer Band 7 @+23dBm	750
		LTE FDD Data transfer Band 8 @+23dBm	580
		LTE FDD Data transfer Band 12 @+23dBm	650
		LTE FDD Data transfer Band 17 @+23dBm	670
		LTE FDD Data transfer Band 20 @+23dBm	650
		LTE FDD Data transfer Band 28 @+23dBm	680
		LTE FDD Data transfer Band 66 @+23dBm	720
		LTE TDD Data transfer Band 38 @+23dBm	400
		LTE TDD Data transfer Band 40 @+23dBm	420

5 Functional Interface

5.1 Control Interface

Control interfaces used for module power on/off and reset operations. The pin definitions are as follows: Table 5-1 Control signal

Pin name	I/O	Pin No.	Description
RESET_N I		20	When the module in operating mode, pull down RESET_N
	1		700ms to 1s, and then release it, the module is reset.
	1	21	When module in power off mode, pull down PWRKEY 100ms
PWRKEY			to 2s, and release it, the module will power on; When module
			in operating mode, pull down PWRKEY 3s to 8s, and then
			release it, the module will power off.

5.1.1 Power On/Off

5.1.1.1 Power On

When NL668-LA series module in power off mode, pull down PWRKEY pin 100ms to 2s, the module will power on, it is recommended to use OC/OD drive circuit to control PWRKEY pin. The OC drive reference circuit is shown as follows:



Figure 5-1 OC drive power on reference circuit

The other way to control PWRKEY pin is use a button switch, a TVS should located near the button (recommended ESD9X5VL-2/TR) for ESD protection. The button switch power on reference circuit is shown as follows:



Figure 5-2 Button switch power on reference circuit

Figure 5-3 shows power on timing.





Note:

Before pull down PWRKEY pin, the Voltage of VBAT must be stable, recommended time interval between VBAT enable and pull down PWRKEY pin at least 30ms.

5.1.1.2 Power Off

The module supports three power off methods as table 5-2.



Table 5-2 Power Off

Power Off Mode	Power Off Method	Applicable Scenario
Low-voltage power off	When VBAT voltage is low or power down, the module will power off	The module does not power off through normal process, i.e. does not logout from the base station
Hardware power off	Pull down PWRKEY 3s to 8s	Hardware normal power off
AT power off	AT+ CPWROFF	Software normal power off

A

Note:

1.When module at operating mode, please do not cut off module power supply to avoid damage internal flash. Recommended by PWRKEY pin or AT commands power off module, then cut off power supply.

2.When power off by AT commands, please don't pull down PWRKEY pin, otherwise module will power on again automatically.

The power off timing is shown as follows:



5.1.2 **RESET**

The module supports two modes to reset: hardware reset and software reset.

Table 5-3 Reset

Reset Mode	Reset Method
Hardware reset	Pull down RESET_N pin 700s to 1s, then release it
Software reset	Sent AT commands AT+RESET

Reproduction forbidden without Fibocom Wireless Inc. written authorization - All Rights Reserved. FIBOCOM NL668-LA Series Hardware Guide Pag

Clients can control RESET_N pin by two modes: OC/OD drive circuits and button switch, corresponding reference circuit as Figure 5-5 and Figure 5-6:



Figure 5-5 OC driven reset reference circuit





The reset timing is shown as follows:



5.2 Network Status Indicate Interface

NL668-LA series module provides three network status indicate pins. Pin 5 is network status indicator by

default, AT commands AT+LEDCFG can switch to pin6 or pin61, table 5-4 is the pin definition.

PIN Name	I/O	PIN No.	Description
NET_MODE	0	5	Network status indicator (by default)
NET_STATUS	0	6	Network status indicator
STATUS	0	61	Network status indicator

Table 5-4 Network status indicator

5.2.1 Interface Status Description

Network status indicate pins are used to driven indicate light and describe module's network status,

NL668-LA series module network indicates light work status description as follow table:

Table 5-5 Network indicator light work status

Modo	Module Network Indicator	Indicator Light Flash/Off	Description
Mode	Pin Status	Status	Description



Mode	Module Network Indicator	Indicator Light Flash/Off	Description
	Pin Status	Status	
1	600ms High/600ms Low	Flash 600ms on/600ms off	No SIM card Request SIM PIN Registering network (T<15s) Register network failed
2	3000ms High/75ms Low	Slow flash 3000ms on/75ms off	Standby
3	75ms High/75ms Low	Speed flash 75ms on/75ms off	Data link established
4	Low	Off	Voice call
5	High	On	Sleep

NL668-LA series module network indicates light reference design circuits shown as follows:



Figure 5-8 Network indicator light reference circuits

5.3 (U)SIM Card Interface

NL668-LA series module has built-in (U)SIM card interface, and supports 1.8V and 3.0V (U)SIM card.

5.3.1 (U)SIM Pin Definition

(U)SIM pin definition is shown in the following table:

Table 5-6 (U)SIM card pin



Pin name	I/O	Pin No.	Description
USIM_PRESENCE	I	13	Detect (U)SIM card for Hot-swap
USIM_VDD	PO	14	(U)SIM Power
USIM_DATA	Ю	15	(U)SIM DATA
USIM_CLK	0	16	Clock Signal
USIM_RESET	0	17	Reset Signal

5.3.2 (U)SIM Interface Circuit

5.3.2.1 (U)SIM Card Connector with Card Detection Signal

(U)SIM circuit design requires use (U)SIM card connector, recommend chose with card detect signal that support card hot swap function (Fibocom recommend: SIM016-8P-220P).



Figure 5-9 (U)SIM card connector (SIM016-8P-220P)

SIM016-8P-220P card connector, DET and POL are short connected when the card is inserted; DET and POL are disconnected when there is no card. The following is the reference design circuit, (U)SIM card insert, USIM_PRESENCE pin is high level; (U)SIM card pull out, USIM_PRESENCE pin is low level.





Figure 5-10 (U)SIM card connector with detection signal reference circuit

5.3.2.2 (U)SIM Card Connector Without Detection Signal

If use (U)SIM card connector without detection signal USIM_ PRESENCE pin must keep floating.



Figure 5-11 (U)SIM card connector without detection signal reference circuit

5.3.3 (U)SIM Hot Plug

NL668-LA series module support (U)SIM hot plug function, it determines the insertion and removal of (U)SIM card by detect the USIM_ PRESENCE pin state.

The card hot plug function can be configured by the "AT+MSMPD" command, and the AT commands are shown in the following table:



AT Command	(U)SIM Card Hot Plug Detection	Function Description
		(U)SIM card hot plug detection is enabled by
		default.
AT+MSMPD=1	Enabled	The module determines the insertion and removal of
		(U)SIM card by detect the USIM_ PRESENCE pin
		state
AT+MSMPD=0		(U)SIM card hot plug detection function is disabled
	Disabled	The module read the (U)SIM card when module
		power on, and does not detect the
		USIM_PRESENCE state

Table 5-7 (U)SIM card hot plug function configured

After enabled the hot plug detection function of the (U)SIM card, if USIM_PRESENCE is in high level, the module will detect the (U)SIM card insertion and execute card initialization program. After reading the (U)SIM card information, the module will register network. When the USIM_PRESENCE is in low level, the module detects (U)SIM card is removed, and it will not read the (U)SIM card.

Note:

The USIM_PRESENCE pin active high by default, and can be switched to active low by AT command.

Table 5-8 USIM_PRESENCE effective level switched

AT Command	Function Description
AT+GTSET=" SIMPHASE",1	Default, high level detect
AT+GTSET=" SIMPHASE",0	Low level detect

5.3.4 (U)SIM Design Requirements

(U)SIM card circuit design shall meet EMC standards and ESD requirements, and at the same time, shall improve anti-interference ability to ensure that the (U)SIM card can work stably. The design needs to strictly observe the following rules:

- (U)SIM card connector is placed as close to the module as possible, away from the RF antenna, DCDC power, clock signal lines and other strong interference sources;
- Adopt the (U)SIM card connector with metal shield shell to improve anti-interference ability;
- The length of cable from the module to the (U)SIM card connector shall not exceed 100mm. Longer



cable reduces signal quality.

- USIM_CLK and USIM_DATA signals are ground isolated to avoid mutual interference. If it is difficult to do so, (U)SIM signal needs to be ground protected as a set;
- The filter capacitor and ESD device of (U)SIM card signal cable should place close to the (U)SIM card connector.
- Please select equivalent capacitor is 22Pf to 33pF for ESD device.
- USIM_DATA should pull up to USIM_VDD with a 10K resistor.

5.4 USB Interface

5.4.1 USB Pin Definition

Table 5-9 USB pin definition

Pin name	I/O	Pin No.	Description
USB_DP	IO	69	USB differential data bus D+
USB_DM	IO	70	USB differential data bus D-
USB_VBUS	PI	71	USB Plug detect

For more information about the USB 2.0 specification, please refer to http://www.usb.org/home

A Note:

Since the module supports USB 2.0 High-Speed, TVS tube equivalent capacitance on the USB_DM/DP differential signal cable is required to be less than 1pF, and a 0.5pF capacitance TVS is recommended.

Connect a 0Ω resistor to USB_DM / DP differential line to help analyze problems.

USB_DM and USB_DP are high-speed differential signal cables, can achieve the maximum

transmission rate of 480Mbits/s, and must follow the rules below in PCB Layout:

- USB_DM and USB_DP signal cable's control differential impedance is 90Ω.
- USB_DM and USB_DP signal cables shall be parallel and equal in length, and avoid the right-angle route.
- USB_DM and USB_DP signal cables are routed on the signal layer closest to the ground layer, and the cables shall be grounded.

5.5 UART Interface

5.5.1 UART Interface Definition

NL668-LA series module has two serial ports: the main serial port and debug serial port. The main serial

ports support 4800bps, 9600bps, 19200bps, 38400bps, 57600bps, 115200bps, 230400bps baud rate. The default baud rate is 115200bps, used for data transmission and AT command transmission. Debug serial port support 115200bps baud rate for FIBOCOM internal debug. Table 5-8 and table 5-9 are the pin definition of main serial port and debug serial port.

Pin Name	I/O	Pin No.	Description
RI	0	62	Ring indicator
DCD	0	63	Data carrier detection
CTS	0	64	Request to send
RTS	I	65	Clear to send
DTR	I	66	Data ready, sleep mode control
TXD	0	67	Module Transmit data
RXD	1	68	Module Receive data

Table 5-10 Main serial port

Table 5-11 Debug serial port

Pin Name	I/O	Pin Num	Description
DBG_RXD	1	11	Module Receive data
DBG_TXD	0	12	Module Transmit data

5.5.2 UART Port Application

The serial port level of NL668-LA series module is 1.8V, if the level of the client host system is 3.3V or other, level translator needed between the module and the host. The reference design circuit of level translator is shown as follows:



Figure 5-12 UART level translate reference 1

The other level translator circuit is shown as Figure 5-13, The rest input and output circuit design of dotted line please refer to solid line part, but pay attention to signal connection direction.



Figure 5-13 UART level translate reference 2

Note:

Level translate circuits is not suitable for applications of baud rates above 460Kbps.

5.6 ADC Interface

NL668-LA series module support two channels ADC interface. Use AT+MMAD command can read the value of ADC interface. The voltage range of ADC interface is 0.3V to VBAT_BB.



Table 5-12 ADC pin definition

PIN Name	I/O	Pin No.	Description
ADC0	I	45	Analog to digital converter interface 0
ADC1	I	44	Analog to digital converter interface 1

5.7 PCM Interface

NL668-LA series module provides a PCM interface for communication with digital audio devices such as an external CODEC.

5.7.1 Supported Model

Table 5-13 Supported model of PCM

Product model	Description
NL668-LA-00	Support
NL668-LA-01	Support
NL668-LA-05	Support
NL668-LA-10	Support

5.7.2 PCM Interface Definition

Table 5-14 PCM pin definition

Pin Name	I/O	Pin No.	Description	
PCM_IN	I	24 PCM data input		
PCM_OUT	0	25	PCM data output	
PCM_SYNC	IO	26	PCM data synchronous signal	
PCM_CLK	IO	27	PCM clock	

5.7.3 PCM Interface Description

Table 5-15 PCM interface description

Pin Name	Frequency	Duty Cycle	Coded Format		Operating Mode	Description
PCM_CLK	2.048MHz	50%				PCM CLK
PCM_OUT	-	-	16bit	liner	Module serves	PCM Output
PCM_IN	-	-	mono		as master	PCM Input
PCM_SYNC	8KHz	Short pulse				PCM Synchronous

Reproduction forbidden without Fibocom Wireless Inc. written authorization - All Rights Reserved. FIBOCOM NL668-LA Series Hardware Guide



Pin Name	Frequency	Duty Cycle	Coded Format	Operating Mode	Description
					Signal (Falling edge sampling)

NL668-LA series module adopts the above configuration by default, any adjustment please contact Fibocom Wireless technical support.

5.7.4 PCM Signal Description

The PCM signal of NL668-LA series module adopts domestic mainstream Europe E1 standard. PCM_CLK frequency is 2.048MHz clock in 16bit linear format encoding. PCM_SYNC is an 8kHz burst (488nS).







Figure 5-15 PCM_CODEC to NL668-LA timing





Figure 5-16 NL668-LA to PCM_CODEC timing

Parameter		Min	Тур.	Max	Unit
t(sync)	PCM_SYNC cycle time	_	125	_	μs
t(synca)	PCM_SYNC asserted time	_	488	_	ns
t(syncd)	PCM_SYNC deasserted time	_	124.5	_	μs
t(clk)	PCM_CLK cycle time	_	488	_	ns
t(clkh)	PCM_CLK high time	I	244	_	ns
t(clkl)	PCM_CLK low time		244	_	ns
t(susync)	PCM_SYNC offset time to PCM_CLK falling	_	122	_	ns
t(sudin)	PCM_DIN setup time to PCM_CLK falling	60	_	_	ns
t(hdin)	PCM_DIN hold time after PCM_CLK falling	10	_	_	ns
t(pdout)	Delay from PCM_CLK rising to PCM_DOUT valid	_	_	60	ns
t(zdout)	Delay from PCM_CLK falling to PCM_DOUT high impedance	_	160	_	ns

6 Low Power Consumption

6.1 Airplane Mode

W_DISABLE# Pin Description:

Table 6-1 W_DISABLE# pin description

Pin name	I/O	Pin No.	Description
W_DISABLE#	I	4	Module airplane mode control

NL668-LA series module supports two ways to enter airplane mode:

Table 6-2 Module enter	airplane	mode	ways
------------------------	----------	------	------

			First send "AT+WDISABLEEN=1" to enable W_DISABLE#
		Hardware I/O interface button	pin function. Pull high or float W_DISABLE# pin (pull high by
	1	control	default), module enter normal mode, pull it down, module
			enter airplane mode.
	2	AT	AT+CFUN=4module enter airplane mode
		AT command control	AT+CFUN=1module enter normal mode

6.2 Sleep Mode

6.2.1 USB Application (Nonsupport USB Suspend, Support VBUS)

If the host nonsupport USB suspend function, the module can enter sleep mode by disconnect

USB_VBUS from the external control circuit:

Sleep:

Send AT+GTUSBDETECTEN=1 to enable USB plug detect function.

AT+GTLPMMODE=1,X command to set the WAKEUP_IN pin's level of control module enter sleep mode.

Reset module, command effective.

(X=0, WAKEUP_IN pin is high level, module enter sleep mode;

X=1, WAKEUP_IN pin is low level, module enter sleep mode)

AT+CSCLK=1 command to enable sleep function.

AT+GTUSBSLEEPEN=1,0 command to set USB sleep mode.

Draw out the USB cable or disable the USB HUB controller, module enter sleep mode.

Wake up:

Plug in USB cable or enable the USB HUB controller can wake up the module.

6.2.2 USB Application (Nonsupport USB Suspend, Nonsupport VBUS)

If the host nonsupport USB suspend and nonsupport VBUS function, the module can enter sleep mode by disconnect USB_VBUS from the external control circuit:

Sleep:

Send AT+GTLPMMODE=1,X command to set the WAKEUP_IN pin's level of control module enter sleep mode. Reset module, command effective.

(X=0, WAKEUP_IN pin is high level, module enter sleep mode;

X=1, WAKEUP_IN pin is low level, module enter sleep mode)

AT+CSCLK=1 command to enable sleep function.

AT+GTUSBSLEEPEN=1,1 command to set USB sleep mode

Draw out the USB cable or disable the USB HUB controller, module enter sleep mode.

Wake up:

Plug in USB cable or enable the USB HUB controller can wake up the module.

6.2.3 USB Application (Support USB Suspend)

If the host support USB Suspend/Resume. Setting USB sleep in Linux system.

Sleep:

Send AT+GTLPMMODE=1,X command to set the WAKEUP_IN pin's level of control module enter sleep

mode. Reset module, command effective.

(X=0, WAKEUP_IN pin is high level, module enter sleep mode;

X=1, WAKEUP_IN pin is low level, module enter sleep mode)

AT+CSCLK=1 command to enable sleep function.

AT+GTUSBSLEEPEN=0,0 command to set USB sleep mode

In Linux system, set the level and control of USB device as auto to suspend the devices of module.

Standing the module and host about 2 seconds, the module can enter suspend mode automatically.

Wake up:

Any operation of USB can wake up the module from sleep mode.

6.2.4 UART Application (WAKEUP_IN Pin Level Control)

When host and module connected through UART, use the following steps to make the module enter **Sleep:**

Sent AT+GTLPMMODE=1,X command to set et the WAKEUP_IN pin's level of control module enter sleep mode. Reset module, command effective.

(X=0, WAKEUP_IN pin is high level, module enter sleep mode;

X=1, WAKEUP_IN pin is low level, module enter sleep mode)

AT+GTUSBSLEEPEN=2,X command to disable USB function (X can be 0 or 1)

AT+CSCLK=1 command to enable sleep function.

Wake up:

The level of WAKEUP_IN pin contrary with that when the module enters sleep mode, module allow be waked up. (X=0, WAKEUP_IN pin is low level, wake up module;

X=1, WAKEUP_IN pin is high level, wake up module)

6.2.5 UART Application (DTR Pin Level Control)

When host and module connected through UART, use the following steps can make the module enter **Sleep:**

Send AT+GTLPMMODE=2,X command to set the DTR set pin's level of control module enter sleep mode. Reset module, command effective.

(X=0, DTR pin is high level, module enter sleep mode;

X=1, DTR pin is low level, module enter sleep mode)

AT+GTUSBSLEEPEN=2,X command to disable USB function (X can be 0 or 1)

AT+CSCLK = 1 command to enable sleep function.

Wake up:

The level of DTR pin contrary with that when the module enters sleep mode, module allow be wake up.

(X=0, DTR pin is low level, wake up module; X=1, DTR pin is high level, wake up module)

6.2.6 ATS24 Command

ATS24 command can also make module enter sleep mode.

Sleep:

Send AT+GTLPMMODE=0 Reset module, command effective.

ATS24=X command to into sleep after X seconds. (X is nonzero integer)

AT+GTUSBSLEEPEN=2,X command to disable USB function (X can be 0 or 1)

Wake up:

Send the AT command fast by UART serial port can wake up the module. If don't send AT commands between X seconds, module will try to enter sleep mode.



Note:

Since the level of UART sleep power is different, power consumption of use ATS24 command to enter sleep mode is higher than that use Pin control to enter sleep mode.

When ATS24 command enter sleep mode countdown, it isn't entering sleep mode once

overtime strictly, but try to enter sleep mode. If system don't support after overtime, it will timekeeping automatically.

If you want to use the RI signal to represent the state of the module, please refer to the AT+GTWAKE command in *FIBOCOM AT Commands_Sleep*.

For more sleep command description, please refer to FIBOCOM AT Commands _Sleep

7 RF Interface

NL668-LA series module has ANT_MAIN, ANT_DIV and ANT_GNSS three antenna interfaces, its pin definition is shown as table 7-1:

Table 7-1 RF Interface

Pin Name	I/O	Pin No.	Description
ANT_DIV	1	35	Diversity antenna
ANT_GNSS	1	47	GPS antenna
ANT_MAIN	IO	49	Main antenna

7.1 Operating Bands

Table 7-2 Operating bands

Operating Band	Description	Mode	Tx (MHz)	Rx (MHz)
Band 1	IMT 2100MHz	LTE FDD/WCDMA	1920 - 1980	2110 - 2170
Band 2	IMT 1900	LTE FDD/WCDMA/GSM	1850-1910	1930-1990
Band 3	DCS 1800MHz	LTE FDD/WCDMA/GSM	1710 - 1785	1805 - 1880
Band 4	IMT 2100	LTE FDD/WCDMA	1710-1755	2110-2155
Band 5	CLR 850MHz	LTE FDD/WCDMA/GSM	824 - 849	869 - 894
Band 7	IMT 2600	LTE FDD	2500-2570	2620-2690
Band 8	E-GSM 900MHz	LTE FDD/WCDMA/GSM	880 - 915	925 - 960
Band 12	IMT 700	LTE FDD	699-716	729-746
Band 17	IMT 700	LTE FDD	704-716	734-746
Band 20	EUDD 800MHz	LTE FDD	832 - 862	791 - 821
Band 28	IMT 700	LTE FDD	703-748	758-803
Band 66	IMT 2100MHz	LTE FDD	1710-1780	2110-2200
Band 38	IMT-E 2600MHz	LTE TDD	2570 - 2620	
Band 40	IMT 2300MHz	LTE TDD	2300 - 2400	

7.2 Output Power

The Output power of NL668-LA series module show as follows:

Table 7-3 Output power

Mode	Band	Tx Power (dBm)	Note
	GSM 850	32.5±2	
COM	GSM 900	32.5±2	
GSIVI	DCS 1800	29.5±2	
	PCS 1900	29.5±2	
	Band I	23.5±2	
	Band II	23.5±2	
	Band III	23.5±2	
VVCDIVIA	Band IV	23.5±2	
	Band V	23.5±2	
	Band VIII	23.5±2	
	Band 1	23±2	10MHz Bandwidth, 1 RB
	Band 2	23±2	10MHz Bandwidth, 1 RB
	Band 3	23±2	10MHz Bandwidth, 1 RB
	Band 4	23±2	10MHz Bandwidth, 1 RB
	Band 5	23±2	10MHz Bandwidth, 1 RB
	Band 7	23±2	10MHz Bandwidth, 1 RB
	Band 8	23±2	10MHz Bandwidth, 1 RB
	Band 12	23±2	10MHz Bandwidth, 1 RB
	Band17	23±2	10MHz Bandwidth, 1 RB
	Band 20	23±2	10MHz Bandwidth, 1 RB
	Band 28	23±2	10MHz Bandwidth, 1 RB
	Band 66	23±2	10MHz Bandwidth, 1 RB
	Band 38	23±2	10MHz Bandwidth, 1 RB
	Band 40	23±2	10MHz Bandwidth, 1 RB

7.3 Receive Sensitivity

Table 7-4 Receive sensitivity

Mode	Band	Rx Sensitivity (dBm) Typ.	RxD Sensitivity (dBm)Typ.
GSM	GSM 850	-109	NA



Mode	Band	Rx Sensitivity (dBm) Typ.	RxD Sensitivity (dBm)Typ.
	GSM 900	-109	NA
	DCS 1800	-108.5	NA
	PCS 1900	-108.5	NA
	Band I	-109	NA
	Band II	-109.5	NA
WCDMA	Band III	-109.5	NA
WODMA	Band IV	-109	NA
	Band V	-110	NA
	Band VIII	-110	NA
	Band 1	-97.5	-98
	Band 2	-97.5	-98.5
	Band 3	-98	-98.5
	Band 4	-97	-98.5
	Band 5	-98.5	-99.5
	Band 7	-96	-97.5
	Band 8	-98	-99.5
	Band 12	-97.5	-98
	Band 17	-97.5	-98
	Band 20	-97	-97
	Band 28	-97.5	-97
	Band 66	-97.5	-98.5
	Band 38	-97.5	-96.5
	Band 40	-97.5	-96.5

7.4 GNSS Receiver

7.4.1 GNSS Specification

NL668-LA series module (except NL668-LA-01) supports GNSS function and adopts Qualcomm Gen8

technology, its specification show as follows:

Table 7-5 GNSS specificatio

Description		Condition	Тур.
		GNSS fixing	62mA
Power		GNSS tracking	62mA
(AI+CFUN=0)		Standby	34mA
		Cold start	45s
TTFF	GNSS	Warm start	40s
		Hot Start	5s
	Acquisition		-144dbm
Sensitivity	Tracking		-155dbm
	CN0	GNSS Signal@-130dBm	38.5 dB-Hz
Positional accuracy	CEP	GNSS Signal@-130dBm	<3.5m

7.4.2 GNSS Observe Protocol

NL668-LA series module adopts NMEA-0183 protocol.

7.5 Antenna Design

7.5.1 Antenna Index

1) Antenna efficiency

Antenna efficiency is the ratio of antenna input power to radiated power. Due to the antenna return loss, material loss, and coupling loss, the radiated power is always lower than the input power. Recommended > 40% (-4dB).

2) S11 or VSWR

S11 shows that the matching degree of the antenna's 50Ω impedance, to a certain extent, affects the antenna efficiency. VSWR test methods can be used to measure this parameter. Recommended S11 < -10dB.

3) Polarization

Polarization is the rotation direction of the electric field in the maximum radiation direction of the antenna.

It is recommended to use linear polarization.

4) Radiation pattern

Radiation pattern refers to the antenna's electromagnetic field strength in the far field in all directions.

Half-wave dipole antenna is the most suitable terminal antenna. For built-in antenna, PIFA antennas or

IFA antennas are recommended:

Antenna area: 6mm high x 10mm wide x 100mm long.

Antenna radiation direction: Omni_directional (all direction).

5) Gain and directivity

Antenna directivity refers to the electromagnetic field strength of electromagnetic wave in all directions. Gain is a collection of antenna benefits and antenna directivity.

Recommended antenna gain \leq 3dBi.

6) Interference

In addition to the antenna performance, other interferences on the PCB also affect the performance of the module. In order to ensure the high performance of the module, interference must be controlled. Suggestions: For example, LCD, CPU, FPC cable, audio circuit, power supply should be away from the antenna as far as possible, and make the appropriate isolation and shielding, or filtering on the path.

7) Antenna index requirements

Table 7-6 Main antenna requirements

NL668-LA series module main antenna requirements			
Frequency range	It must use the most suitable antenna to adapt to the relevant frequency band		
	GSM850: 70 MHz		
Bandwidth	GSM900: 80 MHz		
(GSM/EDGE)	GSM1800 (DCS): 170 MHz		
	GSM1900 (DCS): 140 MHz		
	WCDMA band 1 (2100): 250 MHz		
	WCDMA band 2 (1900): 140 MHz		
Bandwidth (MCDMA)	WCDMA band 3 (1800):170 MHz		
	WCDMA band 4 (2100): 440 MHz		
	WCDMA band 5 (800): 70 MHz		
	WCDMA band 8 (900): 80 MHz		

NL668-LA series module main antenna requirements				
	LTE band 1 (2100): 250 MHz			
	LTE band 2 (1900): 140 MHz			
	LTE Band 3 (1800): 170 MHz			
	LTE Band 4 (2100): 440 MHz			
	LTE Band 5 (850): 70 MHz			
	LTE Band 7 (2600): 190 MHz			
Randwidth (LTE)	LTE Band 8 (900): 80 MHz			
	LTE Band 12 (700): 50 MHz			
	LTE Band 17 (700): 50 MHz			
	LTE Band 20 (800): 71 MHz			
	LTE Band 28 (700): 100 MHz			
	LTE Band 66 (2100): 490 MHz			
	LTE band 38 (2600): 50 MHz			
	LTE band 40 (2300): 100 MHz			
Impedance	50Ω			
Input power	> 33dBm (2 W) peak power GSM			
	> 23dBm average power WCDMA & LTE &TD-SCDMA&CDMA&EVDO			
Standing wave ratio	< 0·1			
recommended	= 2.1			

7.5.2 Antenna Reference Design

Antenna is a sensitive device, susceptible to the external environment. For example, the size of the module, the location of the antenna, the space it occupies, and the surrounding ground all may affect antenna performance. In addition, the RF cable connect with antenna, and the location of the fixed antenna also may affect its performance. NL668-LA series module's three antenna all led by welding plate. recommended clients use the U.FL-R-SMT-1 antenna connector and corresponding match adapter cable. Figure 7-1 is reference design of main antenna and diversity antenna.





Figure 7-1 Main and diversity antenna reference circuit

Figure 7-2 is reference design of GNSS antenna.



Figure 7-2 GNSS antenna reference circuit

\Lambda Note:

- All matches must be placed close to antenna to make sure the characteristic impedance of transmission cable is 50 ohms.
- Since the antenna loss should be less than 0.3dB, keep PCB cable as short as possible.
- Keep the PCB LAYOUT straight, and reduce holes on the route to another layer; also avoid right-angle and acute-angle wiring.
- PCB cable should have a good reference ground to avoid other signal cable near the antenna.
- Recommend a complete ground level, and use this complete ground level as a reference



ground.

- Ground around antenna must be keep connect with main ground.
- For more design information please refer to *FIBOCOM Design Guide_Antenna*.

8 Reliability

8.1 Limiting Voltage Range

The limiting voltage range is maximum voltage range that power supply and digital or analog input/output interfaces can withstand.

8.1.1 Absolute Voltage Range

The absolute voltage range of NL668-LA series module is shown as table 8-1.

Table 8-1 Absolute voltage range

Parameter	description	Min	Тур.	Мах	Unit
VBAT	Power supply	-0.3	3.8	4.7	V
GPIO	Digital IO supply voltage	-0.3	1.8	2.0	V

8.1.2 Operating Voltage Range

Table 8-2 Operating Voltage Range

 V_L : logic low level; V_H : logic high level;

VL VL			V _H		
Parameter	Min	Мах	Min	Max	Unit
Digital input	-0.3	0.6	1.2	2.0	V
Digital output	-	0.45	1.35	-	V

Parameter	I/O	Min	Тур	Мах	Unit
VBAT	PI	3.3	3.8	4.3	V
USIM_VDD	PO	1.7/2.75	1.8/2.85	1.9/2.95	V

8.2 Environment Temperature Range

The recommended operating temperature range of NL668-LA series module.is -30°C to +75°C. When module operating at limited temperature range, some RF indexes may exceed standard, so module application terminal should consider temperature control measurement. The module application terminal is recommended storage in certain temperature conditions. Modules out of the temperature range may not operate or may be damaged.



Table 8-3 Environment temperature range

Temperature	Min	Тур.	Мах	Unit
Operating temperature	-30	25	75	°C
Limited operating temperature	-40		85	°C
Storage temperature	-40		90	°C

8.3 Environmental Reliability Requirements

Test Item	Test Condition		
Low temperature storage test	Temperature -40°C±3°C, 24 hours in shutdown state		
High temperature storage test	Temperature +85°C±3°	C, 24 hours in shutdown state	
Temperature shock test	In shutdown state, 0.5 hour at -40°C and +85°C environment respectively, the temperature conversion time < 3min, for 24 cycles		
High temperature and humidity test	Temperature +85°C±3°C, humidity 90–95% RH, 24 hours in shutdown state		
Low temperature operating test	Temperature -30°C±3°C, 24 hours in operating state		
High temperature operating test	Temperature +75°C±3°C, 24 hours in operating state		
	Conduct vibration test according to the requirements shown in the table below:		
Vibration test	Frequency	Random vibration ASD (Acceleration Spectral Density)	
	5–20Hz	0.96m²/s³	
	20–500Hz	0.96m ² /s ³ (20Hz), other –3dB/octave	
Connector life test	30 times of insertion/removal for RF antenna interface cable		

Table 8-4 Environmental reliability requirements

8.4 ESD Characteristics

NL668-LA series module design has considered ESD issue and provided ESD protect measurements, but take ESD issue taken by module carrier and secondary development into consideration, developers should care ESD protection of module application terminal. In addition to considering anti-static treatment

of packaging, please refer to recommended circuit of interface design in the document.

ESD allowable discharge range of NL668-LA series module show as table below:

 Table 8-5 ESD allowable discharge range

Interface	Air Discharge	Contact Discharge
GND	±10KV	±5KV
Antenna port	±8KV	±4KV
Other port	±1KV	±0.5KV

9 Structure Specification

9.1 Product Appearance

The product appearance of NL668-LA series module is shown in Figure 9-1:



Figure 9-1 Product appearance

9.2 Structure Dimension

The structure dimension of NL668-LA series module is shown as Figure 9-2:





9.3 PCB Soldering Pad and Stencil Design

PCB soldering pad and stencil design please refer to FIBOCOM NL668 LCC SMT Design Guide.

9.4 SMT

SMT production process parameters and related requirements please refer to *FIBOCOM NL668 LCC SMT Design Guide*.

9.5 Carrier and storage

Carrier and storage please refer to FIBOCOM NL668 LCC SMT Design Guide.

10 Approval

NL668-LA series module approval show as table 10-1:

Table 10-1 Approval

Certification Scheme	NL668-LA-00, NL668-LA-05, NL668-LA-10
FCC	PASS
HF	PASS
RoHS	PASS
ТВО	TBD
TBD	TBD
Certification Scheme	NL668-LA-01
FCC	PASS (ID:ZMONL668LA01)
CE	PASS
GCF	PASS
SUBTEL(Chile)	PASS
ENACOM(Argentina)	PASS
Anatel	PASS
MTC(Peru)	PASS
CRC(Colombia)	PASS
TBD	TBD
TBD	TBD

For more information, please refer to Fibocom net.

11 Appendixes

11.1 GPRS and EGPRS Encoding Scheme

Encoding method	CS-1	CS-2	CS-3	CS-4
Rate	1/2	2/3	3/4	1
USF	3	3	3	3
Pre-coded USF	3	6	6	12
Radio Block excl.USF and BCS	181	268	312	428
BCS	40	16	16	16
Tail	4	4	4	-
Coded Bits	456	588	676	456
Punctured Bits	0	132	220	-
Data rate Kb/s	9.05	13.4	15.6	21.4

Table 11-1 GPRS encoding scheme

In the GPRS standard, 29 types of GPRS multislot modes are defined for use by mobile stations. The multislot class defines the maximum rate of uplink and downlink. The expression is 3+1 or 2+2, the first number indicates the number of downlink timeslots, and the second number indicates the number of uplink timeslots. Active timeslots indicate the total number of timeslots that the GPRS device can use for both uplink and downlink communications.

Table 11-2	Multilevel	multislot	allocation
------------	------------	-----------	------------

Multislot Class	Downlink Slot	Uplink Slot	Active Slot
1	1	1	2
2	2	1	3
3	2	2	3
4	3	1	4
5	2	2	4
6	3	2	4
7	3	3	4
8	4	1	5



Multislot Class	Downlink Slot	Uplink Slot	Active Slot
9	3	2	5
10	4	2	5
11	4	3	5
12	4	4	5
33	5	4	6

Table 11-3 EGPRS modulation and encoding method

Coding Scheme	Modulation	Coding Family	1 Timeslot	2 Timeslot	4 Timeslot
CS-1	GMSK	/	9.05kbps	18.1kbps	36.2kbps
CS-2	GMSK	/	13.4kbps	26.8kbps	53.6kbps
CS-3	GMSK	/	15.6kbps	31.2kbps	62.4kbps
CS-4	GMSK	/	21.4kbps	42.8kbps	85.6kbps
MCS-1	GMSK	С	8.80kbps	17.6kbps	35.2kbps
MCS-2	GMSK	В	11.2kbps	22.4kbps	44.8kbps
MCS-3	GMSK	А	14.8kbps	29.6kbps	59.2kbps
MCS-4	GMSK	С	17.6kbps	35.2kbps	70.4kbps
MCS-5	8-PSK	В	22.4kbps	44.8kbps	89.6kbps
MCS-6	8-PSK	А	29.6kbps	59.2kbps	118.4kbps
MCS-7	8-PSK	В	44.8kbps	89.6kbps	179.2kbps
MCS-8	8-PSK	Α	54.4kbps	108.8kbps	217.6kbps
MCS-9	8-PSK	Α	59.2kbps	118.4kbps	236.8kbps

11.2 Terms and Acronyms

Term	Definition
AMR	Adaptive Multi-rate
bps	Bits Per Second
CS	Coding Scheme
DRX	Discontinuous Reception
EGSM	Extended GSM900 Band
FDD	Frequency Division Duplexing

Table 11-4 Terms and acronyms

Term	Definition
GMSK	Gaussian Minimum Shift Keying
GSM	Global System for Mobile Communications
HSDPA	High Speed Down Link Packet Access
IMEI	International Mobile Equipment Identity
Imax	Maximum Load Current
LED	Light Emitting Diode
LSB	Least Significant Bit
LTE	Long Term Evolution
СА	Carrier Aggregation
DLCA	Downlink Carrier Aggregation
SCell	Secondary Cell for CA
ME	Mobile Equipment
MS	Mobile Station
MT	Mobile Terminated
PCB	Printed Circuit Board
PDU	Protocol Data Unit
PSK	Phase Shift Keying
QAM	Quadrature Amplitude Modulation
QPSK	Quadrature Phase Shift Keying
RF	Radio Frequency
RHCP	Right Hand Circularly Polarized RMS
RMS	Root Mean Square
RTC	Real Time Clock
Rx	Receive
SMS	Short Message Service
TDMA	Time Division Multiple Access
TE	Terminal Equipment
ТХ	Transmitting Direction
TDD	Time Division Duplexing
UART	Universal Asynchronous Receiver & Transmitter
UMTS	Universal Mobile Telecommunications System
URC	Unsolicited Result Code

Term	Definition
(U)SIM	(Universal) Subscriber Identity Module
USSD	Unstructured Supplementary Service Data
Vmax	Maximum Voltage Value
Vnorm	Normal Voltage Value
Vmin	Minimum Voltage Value
VIHmax	Maximum Input High Level Voltage Value
VIHmin	Minimum Input High Level Voltage Value
VILmax	Maximum Input Low Level Voltage Value
VILmin	Minimum Input Low Level Voltage Value
VImax	Absolute Maximum Input Voltage Value
VImin	Absolute Minimum Input Voltage Value
VOHmax	Maximum Output High Level Voltage Value
VOHmin	Minimum Output High Level Voltage Value
VOLmax	Maximum Output Low Level Voltage Value
VOLmin	Minimum Output Low Level Voltage Value
VSWR	Voltage Standing Wave Ratio
WCDMA	Wideband Code Division Multiple Access

11.3 Related Documents

- FIBOCOM EVK-GT8230-NL User Guide
- FIBOCOM ADP-NL668-LA Evaluation Board Instructions
- FIBOCOM NL668 LCC SMT Design Guide
- FIBOCOM Design Guide_RF Antenna
- FIBOCOM NL668 AT Commands

11.4 Reference Standards

The design of the product complies with the following standards:

- 3GPP TS 51.010-1 V10.5.0: Mobile Station (MS) conformance specification; Part 1: Conformance specification
- 3GPP TS 34.121-1 V10.8.0: User Equipment (UE) conformance specification; Radio transmission and reception (FDD); Part 1: Conformance specification
- 3GPP TS 34.122 V10.1.0: Technical Specification Group Radio Access Network; Radio transmission and reception (TDD)

- 3GPP TS 36.521-1 V10.6.0: User Equipment (UE) conformance specification; Radio transmission and reception; Part 1: Conformance testing
- 3GPP TS 21.111 V10.0.0: USIM and IC card requirements
- 3GPP TS 51.011 V4.15.0: Specification of the Subscriber Identity Module -Mobile Equipment (SIM-ME) interface
- 3GPP TS 31.102 V10.11.0: Characteristics of the Universal Subscriber Identity Module (USIM) application
- 3GPP TS 31.11 V10.16.0: Universal Subscriber Identity Module (USIM) Application Toolkit (USAT)
- 3GPP TS 36.124 V10.3.0: Electro Magnetic Compatibility (EMC) requirements for mobile terminals and ancillary equipment
- 3GPP TS 27.007 V10.0.8: AT command set for User Equipment (UE)
- 3GPP TS 27.005 V10.0.1: Use of Data Terminal Equipment Data Circuit terminating Equipment (DTE DCE) interface for Short Message Service (SMS) and Cell Broadcast Service (CBS)

12 FCC Conformance information

Important Notice to OEM integrators

1. This module is limited to OEM installation ONLY.

2. This module is limited to installation in mobile applications, according to Part 2.1091(b).

3. The separate approval is required for all other operating configurations, including portable configurations with respect to Part 2.1093 and different antenna configurations

4. For FCC Part 15.31 (h) and (k): The host manufacturer is responsible for additional testing to verify compliance as a composite system. When testing the host device for compliance with Part 15 Subpart B, the host manufacturer is required to show compliance with Part 15 Subpart B while the transmitter module(s) are installed and operating. The modules should be transmitting and the evaluation should confirm that the module's intentional emissions are compliant (i.e. fundamental and out of band emissions). The host manufacturer must verify that there are no additional unintentional emissions other than what is permitted in Part 15 Subpart B or emissions are complaint with the transmitter(s) rule(s). The Grantee will provide guidance to the host manufacturer for Part 15 B requirements if needed.

Important Note

notice that any deviation(s) from the defined parameters of the antenna trace, as described by the instructions, require that the host product manufacturer must notify to Fibocom Wireless Inc. that they wish to change the antenna trace design. In this case, a Class II permissive change application is required to be filed by the USI, or the host manufacturer can take responsibility through the change in FCC ID (new application) procedure followed by a Class II permissive change application.

End Product Labeling

When the module is installed in the host device, the FCC ID label must be visible through a window on the final device or it must be visible when an access panel, door or cover is easily re-moved. If not, a second label must be placed on the outside of the final device that contains the following text: "Contains FCC ID: ZMONL668LA05"

The FCC ID can be used only when all FCC compliance requirements are met.

Antenna Installation

(1) The antenna must be installed such that 20 cm is maintained between the antenna and users,

(2) The transmitter module may not be co-located with any other transmitter or antenna.

(3) Only antennas of the same type and with equal or less gains as shown below may be used with this module. Other types of antennas and/or higher gain antennas may require additional authorization for operation.

In the event that these conditions cannot be met (for example certain laptop configurations or co-location with another transmitter), then the FCC authorization is no longer considered valid and the FCC ID/IC ID cannot be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate FCC authorization. if host antenna gain exceeds that of guidance provided. the integrator that additional compliance testing would be required

Manual Information to the End User

The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user's manual of the end product which integrates this module. The end user manual shall include all required regulatory information/warning as show in this manual.

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

List of applicable FCC rules

This module has been tested and found to comply with part 22, part 24, part 27, part 90, part 96, part 15B requirements for Modular Approval.

The modular transmitter is only FCC authorized for the specific rule parts (i.e., FCC transmitter rules) listed on the grant, and that the host product manufacturer is responsible for compliance to any other FCC rules that apply to the host not covered by the modular transmitter grant of certification. If the grantee markets their product as being Part 15 Subpart B compliant (when it also contains unintentional-radiator digital circuity), then the grantee shall provide a notice stating that the final host product still requires Part 15 Subpart B compliance testing with the modular transmitter installed.

This device is intended only for OEM integrators under the following conditions: (For module device use)

The antenna must be installed such that 20 cm is maintained between the antenna and users, and
 The transmitter module may not be co-located with any other transmitter or antenna.
 As long as 2 conditions above are met, further transmitter test will not be required. However, the
 OEM integrator is still responsible for testing their end-product for any additional compliance
 requirements required with this module installed.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.