2.4Ghz Wireless & Bluetooth Barcode Scanner

USER MANUAL

Packing list	. 1
Factory Default & Version	1
Battery & Charging	1
Operation Guide	1
1. Wired Mode	1
2. 2.4GHz Wireless Mode - Pairing	2
3. Bluetooth Mode	2
3.1 HID Mode - Pairing	3
3.2 SPP Mode - Pairing	3
3.3 BLE Mode - Pairing	3
3.4 Special Setting for HID Mode	4
4. Scanning Mode	5
5. General Settings	5
5.1 Real Time Mode	5
5.2 Storage Mode	5
5.3 Sound	6
5.4 Sound Frequency	6
5.5 Sleep Timer Setting	6
5.6 Data Format	7
5.7 Keyboard Language Setting	7
5.8 Case Setting	10
5.9 GS Replacement	10
5.10 Cancel GS Replacement	11
5.11 Add Custom Prefix	11
5.12 Clear Custom Prefix	12
5.13 Add Custom Suffix	12
5.14 Clear Custom Suffix	13
5.15 Hide First or Last Characters	13

Contents

Appendix - ASCII Character Form	34
Appendix - Control Character List	32
6. Barcode Parameter Setting	16
5.18 Character Escaping Setting	15
5.17 Terminator Setting	15
5.16 Do Not Hide Any Characters	14

Packing list

- Barcode scanner*1
- USB Cable*1

- Instruction Manual*1
- Dongle *1

Factory Default & Version



Factory Default

Version

Battery & Charging

The scanner is powered by 2200mAh chargeable battery. The battery level will be displayed when scanning "Battery Level" barcode.



Battery Level

Charging:

A Note:

The Barcode Scanner is suggested to charge with USB 3.0 interface of computer.

Please use Power Adapter with DC 5V 1A.

DO NOT use Power Adapter which is greater than 5V 1A.

DO NOT use for fast charge to avoid damaging the Barcode Scanner.

The battery level is suggested to save 60% - 80% when not in use.

Please power off the Barcode Scanner when fully charged.

Operation Guide

There are three communication modes, which are wired mode, 2.4G wireless mode and Bluetooth mode.

1. Wired Mode

Connecting barcode scanner and computer with USB Cable.

2. 2.4G Wireless Mode - Pairing

2.4G Wireless Mode is used for XP, Win7, Win8, Win10, MAC OS, etc. Step 1: Scan the setup code below.



Step 2: Scan the setup code below.



Step 2

Step 3: Plug in dongle.

3. Bluetooth Mode

Virtual Bluetooth Mode is used for XP. Win7. Win8. Win10. MAC OS. etc. HID, SPP and BLE are used for Phone, tablet computer, etc.

3.1 HID Mode - Pairing

Step 1: Scan the setup code below.



Step 1

Step 2: Scan the setup code below.



Step 3: Find "BarCode Bluetooth HID" in Bluetooth device. Step 4: Click it to pair.

3.2 SPP Mode - Pairing

Step 1: Scan the setup code below.



Step 1

Step 2: Find "BarCode Bluetooth SPP" in SPP Software. Step 3: Click it to pair.

3.3 BLE Mode - Pairing

Step 1: Scan the setup code below.



Step 2: Find "BarCode Bluetooth BLE" in BLE Software. Step 3: Click it to pair.

3.4 Special Setting for HID Mode

On

3.4.1 Press and hold for 8s to enter HID pairing mode



3.4.2 HID Virtual Keyboard Settings for IOS System



Show / Hide IOS Keyboard

3.4.3 Show / Hide IOS Keyboard with double click



3.4.4 HID Virtual Keyboard Settings for Android System

Please turn on the virtual keyboard in the Android system setting.

3.4.5 Transmission speed under HID mode



-



Slow



Off

Medium



Very Slow





5. General Settings

5.1 Instant Mode

The data will be transmitted immediately under this mode.



Instant Mode

5.2 Storage Mode

The data will not be transmitted immediately under this mode. It will be stored in the scanner. The data can be uploaded with scanning setup code.





Storage Mode



Upload Total Records

Upload All Stored Data



Clear All Stored Data







Mute







30 mins





Sleep Immediately

5.6 Data Format





Unicode

5.7 Keyboard Language Setting





German



Spanish



Japanese

5.4 Sound Frequency





2730MHz

5.5 Sleep Timer Setting



30s



2 mins



1 min



5 mins



French



Italian



Belgian French



Portuguese



British English



Brazilian Portuguese



Czech



Turkey Q



Sweden / Finland



German IOS keyboard



Russian



Italy 142



Turkey F



Mexican Spanish



Denmark



Croatian/Serbian



Written Norwegian



Swiss German



Swiss French



Dutch



Hungarian





Canadian French



Slovak



Argentina (Latin American)



International keyboard

5.8 Case Setting



5.9 GS Replacement

GS is invisible character. It can be replaced with other visible characters.

Step 1: Scan the setup code below.



Step 2: Scan the new characters from ACSII Character Form.

Example: Replace GS with #.

Step 1: Scan the setup code below.



Step 2: Scan the setup code of # from ASCII Character Form.





Cancel GS Replacement

5.11 Add Custom Prefix

Step 1: Scan the setup code below.



Add Custom Prefix

Step 2: Scan the characters which need to be added from ASCII

Character Form.

Example: Add # as prefix. Step 1: Scan the setup code below.



Add Custom Prefix

Step 2: Scan the setup code of # from ASCII Character Form.



5.12 Clear Custom Prefix

Step 1: Scan the setup code below.



5.13 Add Custom Suffix

Step 1: Scan the setup code below.



Add Custom Suffix

Step 2: Scan the characters which need to be added from ASCII Character Form.

Example: Add # as suffix.

Step 1: Scan the setup code below.



Add Custom Suffix

Step 2: Scan the setup code of # from ASCII Character Form.



#

5.14 Clear Custom Suffix

Step 1: Scan the setup code below.



Step 1

Step 2: Scan the setup code below.



5.15 Hide First or Last Characters

Up to 16 characters can be hidden.

Step 1: Scan "Hide First Characters" or "Hide Last Characters".





Hide First Characters

Hide Last Characters



5.16 Do Not Hide Any Characters

Hide 3 Characters

Step 1: Scan "Hide First Characters" or "Hide Last Characters".





Hide 4 Characters

Step 2: Scan the setup code below.



14





5.18 Character Escaping Setting

NONE

Please refer to the "Appendix - Control Character List" for details.





Character Set 0



Character Set 3

Character Set 2



Character Set 4

6. Barcode Parameter Setting





Leading Character

QR URL













Off















Code 11

Code 32



Check Character



1 Check Digit

2 Check Digits





Industrial 2 of 5

2 Check Digits On



Digits On





Do not Transmit



On





Off

MSI Plessey



Off

Check Character





1 MOD 10 Check Digit On

Telepen



On

Off

Telepen Type



Number + Letter

Number Only

Febraban



Off (ITF25 Type)







Appendix – Control Character List

HEX	Decimal	ASCII	character set 0	character set 1	character set 2	character set 3	character set 4
01	01	SOH	NULL	Home	Ctrl+A	Alt+001	Enter on the keypad
02	02	STX	Ctrl+B	End	Ctrl+B	Alt+002	Cap Lock
03	03	ETX	Ctrl+C	Up Arrow	Ctrl+C	Alt+003	Right Arrow
04	04	EOT	NULL	Down Arrow	Ctrl+D	Alt+004	Up Arrow
05	05	ENQ	NULL	Left Arrow	Ctrl+E	Alt+005	NULL
06	06	ACK	NULL	Right Arrow	Ctrl+F	Alt+006	NULL
07	07	BEL	NULL	Shift+Tab	Ctrl+G	Alt+007	Enter

0.0	00	DC	Back	Back	Back	44.000	
00	00	53	Space	Space	Space	Alt+008	Left Arrow
09	09	нт	Tab	Tab	Tab	Alt+009	Tab
0A	10	LF	Enter	Enter	Ctrl+P	Alt+010	Down Arrow
0B	11	VT	NULL	NULL	Ctrl+Q	Alt+011	Tab
0C	12	FF	NULL	NULL	Ctrl+R	Alt+012	delete
0D	13	CR	Enter	Enter	Enter	Alt+013	Enter
0E	14	S0	F1	Page Up	Ctrl+N	Alt+014	Insert
0F	15	S1	F2	Page Down	Ctrl+O	Alt+015	Esc
10	16	DLE	F3	F11	Ctrl+P	Alt+016	F11
11	17	DC1	F4	NULL	Ctrl+Q	Alt+017	Home
12	18	DC2	F5	NULL	Ctrl+R	Alt+018	Print Screen
13	19	DC3	F6	NULL	Ctrl+S	Alt+019	Back Space
14	20	DC4	F7	NULL	Ctrl+T	Alt+020	Shift tab
15	21	NAK	F8	F12	Ctrl+U	Alt+021	F12
16	22	SYN	F9	F1	Ctrl+V	Alt+022	F1
17	23	ТВ	F10	F2	Ctrl+W	Alt+023	F2
18	24	CAN	F11	F3	Ctrl+X	Alt+024	F3
19	25	EM	F12	F4	Ctrl+Y	Alt+025	F4
1A	26	SUB	NULL	F5	Ctrl+Z	Alt+026	F5
1B	27	Esc	Esc	F6	Ctrl+[Alt+027	F6
1C	28	FS	ALT+028	F7	Ctrl+\	Alt+028	F7
1D	29	GS	ALT+029	F8	Ctrl+]	Alt+029	F8
1E	30	RS	NULL	F9	Ctrl+^	Alt+030	F9
1F	31	US	NULL	F10	Ctrl+_	Alt+031	F10

Appendix - ASCII Character Form

Hexadecimal	ASCII	Character	1D setup code
01	01	SOH	
02	02	STX	
03	03	ETX	
04	04	EOT	
05	05	ENQ	
06	06	ACK	

07	07	BEL	
08	08	BS	
09	09	HT	
0A	10	LF	
0В	11	VT	
0C	12	FF	

0D	13	CR	
0E	14	S0	
0F	15	S1	
10	16	DLE	
11	17	DC1	
12	18	DC2	

13	19	DC3	
14	20	DC4	
15	21	NAK	
16	22	SYN	
17	23	ТВ	
18	24	CAN	

19	25	EM	
1A	26	SUB	
1B	27	Esc	
1C	28	FS	
1D	29	GS	
1E	30	RS	

1F	31	US	
20	32	SP	
21	33	!	
22	34	'n	
23	35	#	
24	36	\$	

25	37	%	
26	38	&	
27	39		
28	40	(
29	41)	
2A	42	*	

2B	43	+	
2C	44	,	
2D	45	-	
2E	46		
2F	47	1	
30	48	0	

31	49	1	
32	50	2	
33	51	3	
34	52	4	
35	53	5	
36	54	6	

37	55	7	
38	56	8	
39	57	9	
ЗA	58	:	
3В	59	;	
3C	60	<	

3D	61	=	
3E	62	>	
3F	63	?	
40	64	@	
41	65	A	
42	66	В	

43	67	С	
44	68	D	
45	69	E	
46	70	F	
47	71	G	
48	72	н	

			1
49	73	I	
4A	74	J	
4B	75	к	
4C	76	L	
4D	77	М	
4E	78	N	

4F	79	0	
50	80	Ρ	
51	81	Q	
52	82	R	
53	83	S	
54	84	т	

55	85	U	
56	86	v	
57	87	w	
58	88	x	
59	89	Y	
5A	90	Z	

5B	91	[
5C	92	١	
5D	93]	
5E	94	۸	
5F	95	_	
60	96		

61	97	а	
62	98	b	
63	99	с	
64	100	d	
65	101	e	
66	102	f	

67	103	g	
68	104	h	
69	105	i	
6A	106	j	
6B	107	k	
6C	108	I	

6D	109	m	
6E	110	n	
6F	111	0	
70	112	р	
71	113	q	
72	114	r	

73	115	S	
74	116	t	
75	117	u	
76	118	v	
77	119	w	
78	120	x	

79	121	У	
7A	122	Z	
7B	123	{	
7C	124	I	
7D	125	}	
7E	126	~	

7F	127	DEL	
C7	199	Ç	
E7	231	ç	

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: •Reorient or relocate the receiving antenna.

•Increase the separation between the equipment and receiver.

•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

•Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.