(2022.03.07)

Eurofins Electrical and Electronic Testing NA, Inc. 914 West Patapsco Avenue Baltimore, MD 21230

FCC ID: 2A4K9-PROU10

Software security questions and answers per KDB 594280 D02:

	Software Security description – General Description				
1	Describe how any software/firmware update will	We do not release the firmware on			
	be obtained, downloaded, and installed. Software	our website for downloading. Our			
	that is accessed through manufacturer's website	direct host manufacturer (OEM) can			
	or device's management system, must describe	request the firmware from us and it			
	the different levels of security.	will be made available via secure			
		server.			
2	Describe all the radio frequency parameters that	Radio frequency parameters are			
	are modified by any software/firmware without	limited by US regulatory domain			
	any hardware changes. Are these parameters in	and country code to limit frequency			
	some way limited, such that, it will not exceed	and transmit power levels. These			
	the authorized parameters?	limits are stored in non-volatile			
		memory by the module			
		manufacturer at the time of			
		production. They will not exceed			
		the authorized values.			
3	Describe in detail the authentication protocols	The firmware is installed on each			
	that are in place to ensure that the source of the	single module during			
	software/firmware is legitimate. Describe in	manufacturing process. The correct			
	detail how the software is protected against	firmware is verified and installed by			
	modification	the module manufacturer.			
		In addition, the firmware binary is			
		encrypted using open SSL			
		encryption and the firmware			
		updates can only be stored in			
		non-volatile memory when the			
		firmware is authenticated.			
		The encryption key is known by the			
		module manufacturer only.			
4	Describe in detail the verification protocols in	The process to flash a new firmware			
	place to ensure that installed software/firmware is	is using a secret key to decrypt the			
	legitimate	firmware, only correct decrypted			
		firmware is stored in non-volatile			
		memory (see #3).			
5	For a device that can be configured as a master	The device ensures the compliance			

	and client (with active or passive scanning),	by checking the configured	
	explain how the device ensures compliance for	parameter and operation values	
	each mode? In particular if the device acts as	according to the regulatory domain	
	master in some band of operation and client in	and country code in each band.	
	another; how is compliance ensured in each band	The device configured as a client	
	of operation?	without radar detection capability	
	Software Security description – Third-P		
1	Explain if any third parties have the capability to	No, third parties don't have the	
1		_	
	operate a US sold device on any other regulatory domain, frequencies, or in any manner that is in	capability to access and change radio parameters. US sold modules	
	violation of the certification.	_	
2		are factory configured to US.	
2	Describe, if the device permits third-party software or firmware installation, what	IN/A	
	,		
	mechanisms are provided by the manufacturer to		
	permit integration of such functions while		
	ensuring that the RF parameters of the device		
	cannot be operated outside its authorization for		
	operation in the U.S. In the description include		
	what controls and/or agreements are in place with		
	providers of third-party functionality to ensure		
	the devices' underlying RF parameters are		
	unchanged and how the manufacturer verifies the		
	functionality.		
3	For Certified Transmitter modular devices,	N/A	
	describe how the module grantee ensures that		
	host manufacturers fully comply with these		
	software security requirements for U-NII devices.		
	If the module is controlled through driver		
	software loaded in the host, describe how the		
	drivers are controlled and managed such that the		
	modular transmitter RF parameters are not		
	modified outside the grant of authorization.		
	Software Security description – USER COI		
1	Describe the user configurations permitted	There is no user configuration GUI.	
	through the UI. If different levels of access are		
	permitted for professional installers, system		
	integrators or end-users, describe the differences.		
	a. What parameters are viewable and	There is no user configuration GUI.	
	configurable by different parties?		
	b. What parameters are accessible or modifiable	This device is not subject to	
	to the professional installer?	professional installation	
	i. Are the parameters in some way		
	limited, so that the installers will not		
	enter parameters that exceed those		

				1		
			authorized?			
		ii.	What controls exist that the user			
			cannot operate the device outside its			
			authorization in the U.S.?			
	c. What configuration options are available to			The end user is not able to		
	the end-user?		d-user?	configure any parameters related to		
				the devices radio		
		i.	Are the parameters in some way	The parameters can only be		
			limited, so that the installers will not	changed remotely within the limits		
			enter parameters that exceed those	of country code US.		
			authorized?			
		ii.	What controls exist that the user	The country code and regulatory		
			cannot operate the device outside its	domain control do limit all the		
			authorization in the U.S.?	parameters set		
	d.	Is the	country code factory set? Can it be	The country code is factory set and		
		change	ed in the UI?	is never changed by UI.		
		i.	If so, what controls exist to ensure	The country code is factory set and		
		1.	that the device can only operate	is never changed by UI		
			within its authorization in the U.S.?	is never enanged by br		
	e. What are the default parameters when the			At each boot up the country code		
	device is restarted?			and the antenna gain are read from		
				the non-volatile memory, those		
				values are configured during		
				production.		
2	Can the radio be configured in bridge or mesh			Not supported		
	mode? If yes, an attestation may be required.					
	Fur	ther in	formation is available in KDB			
	Pul	olicatio	n 905462 D02.			
3	For a device that can be configured as a master Not Supported					
	and	l client	(with active or passive scanning), if			
	this	s is use	r configurable, describe what controls			
	exist, within the UI, to ensure compliance for					
	eac	h mode	e. If the device acts as a master in some			
	bar	nds and	client in others, how is this configured			
			compliance?			
4	For	a devi	ce that can be configured as different	The device does not support these		
	typ	es of a	ccess points, such as point-to-point or	modes/features.		
	poi	nt-to-m	nultipoint, and use different types of			
	1		1 1 1 1			
	ant	ennas,	describe what controls exist to ensure			

antenna is used for each mode of operation. See Section 15.407(a).

Sincerely,

George

Name / Title: George.wang / Certification Engineer Company Name: YABER TECHNOLOGIES CO.,LIMITED Address: Address: Room 406, 4 Floor, B Building, BanTian International Center, HuanCheng South Road, BanTian Street, LongGang District, Shenzhen, China Tel: 15012496795 Fax: 15012496795 E-Mail: George_puture@aliyun.com