




USE AND CARE GUIDE

25SV24690 6.5 ft Grave & Bones
ANIMATED App Controlled Ultra Skelly



To get started, Please hold the “MODE” button for 7 seconds to take the item out of demo mode.

Note: There may be slight differences between the App and Instruction manual. Please refer to the App for the actual interface. Please download the latest version of the app.

Video assembly instructions available online

Please scan QR code to download APP. Please refer to the App instruction manual for details.

Questions, problems, missing parts? Before returning to the store, please have a copy of your receipt ready and email the SVI customer experience team (customerservice@svius.com) within 90 days of the date of purchase or call Home Accents Holiday Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HOLIDAY (1-855-434-6543)
HOMEDEPOT.COM


PARTS LIST

- A. Base x 1
- B. Left Foot x 1
- C. Right Foot x 1
- D. Left Support Pole x 1
- E. Right Support Pole x 1
- F. Left Shin x 1
- G. Right Shin x 1
- H. Left Femur x 1
- I. Right Femur x 1
- J. Pelvis x 1
- K. Ribcage x 1
- L. Head x 1
- M. Left Forearm x 1
- N. Right Forearm x 1
- O. Stakes x 4
- P. Adapter* x 1

Power Adapter * Spec
Input: 120V~60Hz
Output: 5.9V === 3.0A
Wattage: 17.7W




NOTE: Throughout the instructions, Right and Left are from the character's point of view.




1.1





NOTE: Slide the (D) Left Support Pole into the (F) Left Shin and the (E) Right Support Pole into the (G) Right Shin before attaching to the (A) Base. You will need a small Phillips head screwdriver (not included).



1.2





1.3



OPERATION INSTRUCTIONS:

1. To change from Demo Mode to Regular Mode, press and hold the “MODE” button for 7 seconds.
2. Settings:

 Bluetooth	Press the MODE button to switch to "Bluetooth" Mode. Please refer to the APP Operation Instructions.
LIGHTS ONLY / ÉCLAIRAGE UNIQUEMENT / SÓLO LUCES	This switch mode will activate only the LCD eyes and lights of the item indefinitely until the switch mode is changed from the lights only setting.
OFF • STEP PAD / ARRÊT • TAPIS ÉLECTRONIQUE / APAGAR • ALMOHADILLA DE PASO	This switch mode allows the item to be activated only if triggered by using a Step Pad or Try Me Button (Not Included). The item will operate for one activity cycle with each Step Pad or Try Me activation. Otherwise, the item will stay off.
TIMER • SENSOR / MINUTEUR • DÉTECTEUR / TEMPORIZADOR • SENSOR	This switch mode will activate SENSOR mode for 6 hours followed by a deactivated period of 18 hours. This cycle will continue indefinitely unless the setting is changed. During the 6-hour active period, the Infra-red (IR) sensor can be triggered. If the Infra-red (IR) sensor is activated, the Animated APP Controlled Ultra Skelly will activate for one activity cycle (animation and sound). The infra-red (IR) sensor has a range of up to 4 m/13 ft and will activate when someone comes within an 80-degree angle from left to right as well as from above or below.
	Raise or lower the volume using the volume control turn dial, turn all the way down to turn the volume off .

WARNING

This item is not a toy and should be used for decoration only. This item contains small parts that can be a choking hazard. Keep all plastic and wire parts away from children.

1. Please use the adapter supplied by manufacturer.

2. Please assemble item according to instructions. Connect all wires according to matching color.

3. Children should be supervised by adults. Item should not be grabbed, as it becomes a tipping hazard. Keep flammables away from the adapter, as it heats up during operation.

Please view all instructions carefully before assembling. Save this instruction sheet for future reference.


CARE AND STORAGE INSTRUCTIONS

For best performance operate your item indoors. When not in use, store this product in its original packing. Keep away from heat and moisture.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).Operation is subject to the following two conditions:

1. This device may not cause interference.

2. This device must accept any interference, including interference that may cause undesired operation of the device.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna, Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.

CAN ICES (B) / NMB (B)

IMPORTANT TIPS:

- Ensure that the adapter is properly connected at the Function Control Box and is plugged into a live outlet.
- Ensure that the prop is on the desired setting.
- If not functioning properly (ex: Arm, mouth, body and eyes don't move), ensure that cables are connected to their corresponding cable as shown in the instruction sheet.
- Be sure nothing is blocking movement or caught in moving parts.
- Ensure that the floor or surface that the item sits on is flat and level.
- If your product has any issues or you would like to reset it to factory settings, please open the APP and select “Reset to Default” to return the product to Demo Mode.
- If you are only seeing one pre-recorded sound in your APP, please hold the “Mode” button for 7 seconds to take your item out of Demo Mode
- For clearer sound in "Live Mode", please speak into your device from ~35ft away.
- IF ANY PART IS MISSING OR BROKEN, DO NOT ATTEMPT TO ASSEMBLE THE PRODUCT AND CALL HOME ACCENTS HOLIDAY CUSTOMER SERVICE FROM MON-FRI 8:00AM TO 7:00PM AND SAT 9:00 AM TO 6:00 PM EST AT 1-855-HDHOLIDAY (1-855-434-6543).

Questions, problems, missing parts? Before returning to the store, Please have a copy of your receipt ready and email the SVI customer experience team (customerservice@svius.com) within 90 days of the date of purchase or call Home Accents Holiday Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HOLIDAY (1-855-434-6543)
HOMEDEPOT.COM