

# FCC ID:2ADK3XY-EB020



1. True Wireless Earbuds
2. String
3. Charging Case
4. Type-C input port

## Charging:

**\*\* The battery isolator on both earbuds need to be removed in order to be charged. Be sure to charge the devices completely before initial use. \*\***

### 1. Charging the earbuds

- Magnetic contact recharging, once placed into the charging case earbuds will begin to charge automatically.
- Solid Red LED on earbuds and solid Blue LED on charging case when charging.
- LEDs on both earbuds and charging case will turn off when earbuds are fully charged.
- The earbuds with quick charge function, it will take 30 minutes to charge the earbuds from 0 to 100%. Earbuds that are fully charged have a playback time 4-5hrs at max volume.

### 2. Charging the power case

- Use the Type-C cable to connect to an adapter or computer to charge the power case.
- When charging the power case LED light will flash red.
- Once fully charged, the power case LED will turn solid red.

## Pairing Both Earbuds:

### 1. Pairing: First time

- Remove both earbuds from the power case or long touch (3 seconds) the earbud multi-function touch control to power on the earbuds. You'll hear a voice prompt saying "Power On".
- Once you hear both earbuds beep the earbuds are now synced to each other. If done successfully the main earbud will flash Red & Blue while the secondary Earbud slowly flashes Blue.

### 2. Connecting to Bluetooth:

- Go into your Bluetooth options and select the pairing name "Solekick TWS".
- If done successfully you will hear the voice prompt "Connected". Both earbuds will slowly flash Blue.

- You can now enjoy your favorite Audio..
- Previously connected earbuds will connect automatically after they're powered ON.
- If you don't connect to the earbuds within 3 minutes the earbuds will automatically power OFF..

### **3.Power ON**

Remove your earbuds from the charging case or touch and hold the multi-function button for 3 seconds. You'll hear the voice prompt "Power On".

### **4.Power OFF**

To turn off your earbuds place them both back into the power case. You can also power off your earbuds by holding the multi-function button on both earbuds until you hear the voice prompt "Power Off".

### **5.Calling with the Earbuds**

#### **\*Answering/End Call:**

Touch the multi-function button once to answer an incoming call, and again to end the call.

#### **\*Reject a Call:**

When receiving a call, touch the multi-function button 2 seconds to reject the call.

### **6.Playing Audio**

\* Touch the Multi-function button on the Right or Left Earbud to play/pause your audio.

\* If you want to change the volume you must use the connected device.

\*Double touch the right ear multi-function button to go to the next track and double touch the left button to go to the previous track.

### **7. Activate Voice Assistant**

- Triple touch any button to activate your voice assistance,you will hear a beep prompt to indicate that your voice Assistant/Siri is "Activated"and waiting your commands.

### **8. Transparency Mode**

- Press and hold the multi-function button for 2 seconds, you will hear the voice prompt "Transparency on ",it amplifies the surrounding sounds so that you're able to maintain some when exercising or when you're in a busy environment.
- Press the multi-function button for 2 seconds again to turn off Transparency.You will hear a voice prompt "Transparency off".

**Resetting your earbuds:**

\*If you're having trouble pairing your earbuds forget the pairing name "Solekick TWS" from the list of connected devices. Now turn off your Bluetooth.

\*Place both earbuds back into the charged power case.

\*Now remove the earbuds and follow the instructions under "Pairing Both Earbuds".

**You can use each earbud separately.**

**Earbud Tech Specifications**

Items	Specifications
Charging time	30 minutes(from 0-100)
Play time	4-5 hrs
Bluetooth Range	10m

**Power Case Tech Specifications**

Items	Specifications
Charging time	1.5 hrs (from 0-100)

The Power Case can charge the earbuds 3-4x(from 0-100).

Mobile devices cannot connect with the earbuds if the earbuds are not in pairing mode.

If the earbuds are unable to connect to a mobile device via Bluetooth for 3+ minutes, the earbuds will power off automatically.

**Trouble shooting**

Issue	Reason	Solution
Start-up failure	Low battery	Charge earbuds and power case
No sound when paired	Wrong pairing	Re-pairing
No indication during charging	Earbuds aren't securely inserted	Check earbuds and try again
Automatic shutdown	Low battery	Charge earbuds and power case
Noise during calls	Mobile device is too far away	Bring mobile device closer
Low volume	Earbuds are turned down low	Adjust earbuds to required comfort and sound
Signal interrupted	Environmental disturbance, distance too far from mobile device	Bring the mobile device closer to the earbuds

**Warning:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

**FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

FCC ID: 2ADK3XY-EB020