



Wi-Fi Module		
Parameters		Functions
Power Supply	DC5V	<p>The main purpose of Wi-Fi module is AI camera calibration and parameter setting. This module connects with AI camera through USB2.0 interface, and then a Wi-Fi hotspot will be generated. After connecting with Wi-Fi hotspot via mobile phone and entering the specified browser webpage, AI camera calibration and parameter setting can be conducted.</p> <p>Note: This tool is designed and tested to work on the camera end only.</p> 
Power Dissipation(5V IN)	230mA	
IMS Band	2.4G	
Reserving System	IEEE 802.11b/g/n standard	
Communication Interface	USB 2.0	
Wire Length	90mm	
Operating Temperature	-20 ~ +70℃	
Storage Temperature	-30 ~ +80℃	
Dimension	102 x 47 x 11 (mm)	
Weight	25g	
Shell Colour	Black	
		
FCC Warning		
<p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none">—Reorient or relocate the receiving antenna.—Increase the separation between the equipment and receiver.—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.—Consult the dealer or an experienced radio/TV technician for help. <p>This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.</p> <p>NOTE 2: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p>		