

# M557 multi-function wireless doorbell manual

## Product introduction:


This wireless doorbell adopts advanced wireless transceiver technology, powerful microcomputer control system, large-capacity and high-quality voice processing technology, integrates up to 32 music, stable and reliable performance, wireless learning type code matching of the doorbell and transmitter, doorbell, anti-theft , Welcoming guests, suitable for villas, clubs, leisure centers, shops, hotels, guesthouses, families, office buildings, meeting rooms and other occasions.

## Product Features:

- 1) 32 songs optional
- 2) Doorbell/Alarm and welcome multi-modes inside
- 3) You can learn up to 30 transmitters without losing power
- 4) Support accessories of 1527/2262 encoding
- 5) The volume can be adjusted by 4 levels

## Operating instructions

### 1. Product diagram:



2. Select song: Press the [Select] key to select a doorbell ring after power on.

3. Volume Adjustment: Press [Volume] key to adjust volume, 4 levels optional.

### 4. Add detector:

**Add doorbell transmitter:** After powering on, press [Select] and [Volume] at the same time, and the LED will light up. At this time, please trigger the doorbell transmitter to transmit a signal. After the doorbell receives the signal, the LED flashes once, indicating that the learning is correct. If you want to learn Multiple doorbell transmitters, continue to trigger other doorbell transmitters, after learning, press the [Volume] key once to exit the learning. After exiting, you can trigger the transmitter you just learned to test whether the learning is correct, learning infrared is the welcome mode, and learning door sensor is the alarm mode.

**Delete doorbell transmitter:** After powering on, press and hold the [Select] button and [Volume] button for 6 seconds at the same time, the doorbell transmitter has been deleted, and the learning state is exited.

## Notice

1. Back to the first song with largest voice upon power failure.

2. Non-professionals are not allowed to repair without authorization, if there is any problem, please contact the seller.
3. This product has been patented, counterfeiting must be investigated.

### **Technical Parameter:**

1. Working Voltage: AC 100-240V
2. Working Current: <100mA
3. Wireless Frequency: 433mHz
4. Working Temperature: -10° C - 50° C
5. Wireless Distance: 150meters (Open area)

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.