User's Manual for Portable Launch Monitor

Product Description

Portable Launch Monitor is one of Best Launch monitors with the high-speed camera.

With a portable and floor type design, it's easy to carry and install.

Moreover, it supports both indoor and outdoor.

Finally, it can be connected to both mobile apps and PC terminal for use.

Portable Launch Monitor includes the following product models:GDS PRO.

Product introduction

1.Launch monitor



Status light:

The Launch monitor appears blue flashing during startup (<15 seconds);

After the startup is completed, the blue light is constantly on;

When connecting to APPs or PC software, it would turn to green light after recognizing the ball.



After the ball is shot, green turns to blue.

Infrared light

1ST step, after successfully connecting to the APP or PC terminal, the first gear is always on (only visible with a mobile camera)


2nd step, after recognizing the ball (with a green status light),

the second gear is always on (visible to the naked eye).

Camera

It is one of most important functional modules positioning balls.

It should not be obstructed during the process of hitting balls and the exterior of the lens should be kept clean and tidy for a long time.



Instruction:

Laser positioner mounting slot: The laser is attached to the mounting slot through a bottom Magnet.

(Battery indicator):

(Power on and off button):

Power on and off button

Short press the on/off button to turn on/off the monitor.

After turning on, the on/off button indicator light will always light blue;

When the monitor is turned on, press and hold the On/Off button (>5 seconds) to reset the device IP (IP returns to factory mode: 192.168.1.147).

The monitor reset process involves flashing the on/off indicator light 3 times before the monitor restarts.

Charging port: To charge the monitor, it connects to a 24V adapter.

Ethernet port: Connecting a gigabit network cable and a network port for monitor calibration and playing golf.



Instruction:

Battery: Power the monitor

Battery cover:

Buckle both sides inward and pull outward to remove the battery.

2. Laser Positioner



Instruction:

Battery cover: Open the battery cover, and the inside is a 12V battery with a "23A" rating.

Switch button:

Press the switch button to shoot a "cross" laser line from the laser port.



Laser emission port:

The laser port emits a "cross" shaped laser line for monitor calibration.

Magnetic base: Connect to the laser installation slot for fixation

3. Protective cover





Instruction:

- It includes a protective cover and a height adjustment base;
 The two are connected through the bottom center connection port, and then the base is fixed by rotating it 90 °.
- 2. The height adjustment base has three levels of height adjustment, corresponding to an increase of 1cm, 2cm, and 4cm.

Placement position





Instruction:

Requirement: The placement position of monitor and Tee should be on the same horizontal plane (with an error of less than 0.5 cm).

- 1. As shown in the figure, the point of the laser "cross" is the Tee point, and the X-axis direction is the hitting direction.
- 2. If launch monitor placed below the Tee position, the height adjustment base can be used to adjust launch monitor to the same horizontal plane as Tee position.

User Guide

- 1. Connect to APP for use (mobile or IPAD)
- 1. Download "Golfjoy lite" from the official website of Golfjoy, or Apple Store or Android Store, and then register.
- 2.After monitor is turned on, open the "Golfjoy lite" app and search for the Bluetooth to connection.

After successful binding, you can enter various modes in the app to play golf, as shown in the following video tutorial.

- 2. Connecting to PC simulator for use
- 1. Use a gigabit network cable to directly connect the monitor to PC computer network port (gigabit), and connect the PC network port IP to the moniotor IP (factory default 192.168.1.147) in the same network segment (192.168.1. X).

- 2. Modify simulator configuration: Change the IP in the simulator configuration file to the monitor IP (192.168.1.147), and configure the type of Launch monitor to GDSPLUS.
- 3. Open the simulator for playing golf. See the following video tutorial

Upgrading

When there are new features added to the monitor, a new firmware version will be iteratively upgraded. There are 2 ways to upgrade: one is to self upgrade through the APP; The second is to upgrade through self-service prompts on the PC terminal.

The 2 upgrade methods are shown in the following video tutorial.

FCC STATEM ENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This projector complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device should be installed and operated with a minimum distance of 20cm between the radiator and user body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC WARNING: This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

This remote has been evaluated to meet general RF exposure requirement.

This remote can be used in portable exposure condition without restriction.

ISED Statement

- English: This device complies with Industry Canada license - exempt RSS standard(s). Operation is subject to the following

two conditions: (1) This device may not cause

interference, and (2) This device must accept any interference, including interference that may cause u ndesired operation of the device.

The digital apparatus complies with Canadian CAN ICES -3 (B)/NMB -3(B).

- French: Le présentappareilestconforme aux CNR d'Industrie

Canada applicables aux appareils radio exempts de licence. L'

exploitationestautorisée aux deux conditions suivantes: (1) l'

appareilne doit pas produire de brouillage, et (2) l'utilisateur de l'appareildoit accepter tout brouilla geradi oélectriquesubi , mêmesi le

brouillageest susceptible d'encompromettre le

fonctionnement. l'appareil numérique du ciem conforme canadien

peut - 3 (b) / nmb - 3 (b).

This device meets the exemption from the routine evaluation

limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadia

information on RF exposure and compliance.

cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du cnr

- 102 et conformité avec

rss 102 de l'exposition aux rf, lesutilisateurs peuvent obtenir des données canadiennes sur l'expositi on aux champs rf et la

conformité.

This equipment complies with Canada radiation exposure limits

set forth for an uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux

rayonnements du Canada établies pour un environnement non

contrôlé.

This equipment should be installed and operated with minimum distance 20cm between the radiato r & your body.

Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et v otre corps.