


QUICK-START GUIDE • GUIDE DE DÉMARRAGE RAPIDE




A Connect the USB cable to the adapter and dongle.



B Plug the cable into your computer.




C Move the switch from the OFF position to turn on the mouse.



1 CHARGING THE BATTERY

Charge the battery via the USB cable.
The indicator light shows charging status.




2 BATTERY LEVEL

To check the battery level, press and hold both side buttons + left click for 3 seconds. The color of the indicator light shows the current battery level.



- < 25%
- < 50%
- < 75%
- < 100%




3 CPI (MOUSE SENSITIVITY)

Set the switch into CPI mode. Then press the bottom button repeatedly to adjust the mouse sensitivity. The color of the indicator light shows the current setting.

● 400 ● 800 ● 1200 ● 1600 ● 3200
● 400 ● 7200 ● 26000

OFF
CPI
PR
DT




4 POLLING RATE

Set the switch into PR mode. Then press the bottom button repeatedly to adjust the polling rate.

● 125 Hz ● 250 Hz ● 500 Hz ● 1000 Hz

OFF
CPI
PR
DT




5 DEBOUNCE TIME

Set the switch into DT mode. Then press the bottom button repeatedly to adjust the debounce time.

● 2 ms ● 4 ms ● 8 ms ● 12 ms


OFF
CPI
PR
DT



6 LIFT-OFF DISTANCE

Press and hold both side buttons + left and right click to change the lift-off distance.


● 1 mm ● 2 mm



7 MOTION SYNC


Press and hold both side buttons + scroll click to turn motion sync on or off.

● OFF ● ON



9 FACTORY RESET

Press and hold both side buttons + right click to reset all settings.





CHARGE THE MOUSE VIA COMPUTER USB PORT ONLY.



FRA

1 CHARGING THE BATTERY

Charge the battery via the USB cable. The indicator light shows charging status.

2 BATTERY LEVEL

To check the battery level, press and hold both side buttons + left click for 3 seconds. The color of the indicator light shows the current battery level.

3 CPI (MOUSE SENSITIVITY)

Set the switch into CPI mode. Then press the bottom button repeatedly to adjust the mouse sensitivity. The color of the indicator light shows the current setting.

4 POLLING RATE

Set the switch into PR mode. Then press the bottom button repeatedly to adjust the polling rate.

5 DEBOUNCE TIME

Set the switch into DT mode. Then press the bottom button repeatedly to adjust the debounce time.

6 LIFT-OFF DISTANCE

Press and hold both side buttons + left and right click to change the lift-off distance.

7 MOTION SYNC

Press and hold both side buttons + scroll click to turn motion sync on or off.

9 FACTORY RESET

Press and hold both side buttons + right click to reset all settings.

REST OF TRANSLATIONS

FCC warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction