



Quick Start Guide





Appearance



Number	Function
1	Power key: Hold down until the tablet powers on.
	Hold down until options appear, then select power off.
2	Volume key
34	Speaker
56	Microphone
7	USB port
8	Headset
9	SD slot

Insert SD card



Charging



Home screen




Back Home Recent apps

Name	Function
Google Search	Touch 1 to enter text search screen. Touch 2 to enter voice search screen.
Back	Touch to go back to last screen.
Home	Touch to return to the Home screen
Recent apps	Touch to view recent apps.
All Apps	Swipe upward from the Home screen to view the App list.

5 Kidomi

To use Kidomi:


 When you configur the setup wizard in the device for the first time, The Kidomi login screen will appear, If you are already connected to a Wi-Fi network, you can continue. Otherwise, you need to pull down the status bar twice to find Setting icon, and then connect to a Wi-Fi network. (Refer to section "J Getting connected"



- From Kidomi login screen, Touch Get started to create an account or touch Sign in to access your account.
- Customize your kids playlist by selecting your child's categories of interest and age range.
- Enter your kids first name and then set up a PIN for yourself.
- After completing the setup. your kids can use the device while in the Kidomi learning and gaming environment.
- To access the parent area press the menu key located at the top right of the home screen. Here you can access parent features and exit Kidomi by entering your PIN code.

Please note: If there is network exception when you are in kidomi application, you need to exit kidomi to reconnect network

Stand



7 Getting connected

To connect to the Internet with this device, you will need to have an internet connection via Wi-Fi.

To turn Wi-Fi on and connect to a Wi-Fi network

- •Go to Settings > Network & Internet > Wi-Fi.
- Touch a Wi-Fi network to connect. If the network you selected is a secured network, you will need to enter a password or other credentials. When finished, touch CONNECT.

S Eye Comfort Mode

Eye comfort mode: Decreases the level of blue light emitted from the screen to make viewing more comfortable for your eyes.

Your device is compliant with the TÜV Rheinland's "Low Blue Light Content" standard when the Eye comfort mode is turned on.

To turn Eve comfort mode on:

- From the Home screen, touch Settings > Display > Eye comfort mode.
- Touch TURN ON NOW, then slide the icon left or right to increase/decrease the level of the blue light.

Or

- From the Home screen, twice drag down the Status bar to open the Quick Settings panel.
- Slide the Quick Settings panel screen left to find Eye comfort mode.
- Touch Eye comfort mode to turn it on.

To protect your eyes:

· Break time

Users should take some time away from the screen. It is recommended to take short breaks 5 mins after half of one hour.

Looking at Distant Objects

Users often blink less when in front of monitor screen. To minimize eye strain and dryness, users should rest the eye periodically by focusing on objects that are far away.

Eye and Neck Exercises

Certain exercise reduces eye strain and prevent early onset of musculo-skeletal disorders.

- Exercises for the eye:
 - Alternate looking up and looking down while keeping the body and head upright.
 - 2. Slowly roll your eyes to look to the left and right.
 - Roll eyes to look at objects on the upper right corner and then on lower right. Do same thing to look at objects on the upper left and lower left.