


Harvey

Wireless Power Bank User Guide



Illustration

1. ON/OFF Button
2. Type-C Input/Output
3. LED Indicator
4. Wireless Charging Pad

What's Included

- 1 x Harvey Wireless Power Bank
- 1 x USB-A to Type-C Charging Cable
- 1 x Instruction Manual

Specifications

- Capacity: 5000mAh/3.85V/19.25Wh
- Type C input: 5V/2.6A 9V/2A 12V/1.5A(18W)
- Type C output: 5V3A/9V2.22A/12V1.67A(20W)
- Wireless output: 5W/7.5W/10W/15W

LED Indicators

- Press the Power bank ON/OFF Button ① once to view the remaining power percentage.
- Press the button twice to turn it OFF.

LED On	○○○○	○○○	○○	○
Power percentage	100%	75%	50%	25%

INSTRUCTIONS

1. Charging the Power Bank

- Charge the power bank fully before the usage.
- Connect the provided charging cable USB-A to a power source and the Type-C to the power bank Input ②.
- Once connected the LED Indicator ③ begins to flash white color when charging.
- Once fully charged, the indicator stops flashing.

2. Charging Devices With a Type-C Cable

- Connect your device's original cable to your device.
- Connect the Type-C tip of the cable to Type-C Output ②; the LED Indicator will illuminate WHITE when charging.
- Remove the charging cable from your device after fully charged.

3. Charging Devices with the Wireless Charging

- Pressing the power bank ON/OFF button ①, the first LED indicator ③ will flash RED & GREEN three times and then glow RED once. The power bank is in wireless charging standby mode.
- Place your wireless-charging-enabled device on the Wireless Charging Pad ④. The device will be charged, the first LED indicator glowing GREEN.
- Remove your device from the power bank once fully charged.
- If your device has built-in magnet, it will align and attach itself to the Magnetic Circle ⑤ for a secured and optimized wireless charging.

**** Note:** If the first LED indicator flashing RED and GREEN alternately, an unknown object is being detected between the wireless charging pad and the device. (The device will not begin to charge until the object is removed.)

SAFETY PRECAUTIONS

- WARNING-**When using this product, basic precautions should always be followed:
 1. Read all the instructions before use.
 2. Never store or use this product in temperatures below 32°F (0°C) or above 115°F (45°C).
 3. Do not overcharge your device. The unit may become hot after excessive use. Remove your device once fully charged. Never charge your device for over 7 hours at a time.
 4. The unit can achieve full performance only after 2 or 3 full charge and discharge cycles.
 5. To reduce the risk of injury, close supervision is required when the product is used near children.
 6. Do not expose the device to moisture.
 7. Do not use the device in excess of its output rating. Overload outputs above the rating may result in a risk of fire or injury.
 8. Do not use the device if damaged or modified.
 9. Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury.
 10. Do not disassemble the device. For repairs, seek a qualified professional. Incorrect reassembly may result in a risk of fire or injury.
 11. Do not expose the product to fire or excessive temperatures. Exposure to fire or temperatures above 104°F (40°C) may result in explosion.
 12. To ensure product safety, ensure that qualified professionals use only identical replacement parts.

13. Attachments on the back of your phone can reduce the effectiveness of the wireless charging, and might lead to overheating.
14. The magnetic fields of neodymium magnets can damage items such as television, computer monitors, credit cards, debit cards, computers, diskettes and other data carriers, video tapes, mechanical watches, hearing aids, loud speakers and VCRs. Pace-makers may be damaged or switch to "Test Mode" in the presence of a strong magnetic force. If a pace-maker or other electrical body implant is in use, keep the power bank a minimum of 3 feet distance.



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.