


Quick Start Guide


Smart Wireless Battery Camera




Welcome

Thank you for choosing our smart camera.
Getting started is easy.


What is Included




Security Camera




32GB Micro SD Card



Type-C




Quick Start Guide




Wall Mount Screw Sets

Product Details



- Indicator light
- White light
- Microphone Lens
- PIR




- Type-C
- Reset Button
- On/off button
- SD Card Slot

Indicator light status

NO.	Mode	Status
1	Working mode	Blue
2	Sleep mode	Off
3	Charging mode	Yellow
4	Fully charged mode	Green

1. Connection Preparation

Bring the camera and phone within 1 to 3 feet (30 to 100 centimeters) of the router.






Camera 30cm~100cm Smartphone

Note: Make sure smart phone is connected with your wireless router. Please note the camera is only working under 2.4G Wi-Fi, not support 5G Wi-Fi.

2. Get the APP and Account

For the best experience, please download the "Vichome" APP to your smartphone from App Store or Google Play, store or you can also scan the QR code below, the APP icon will be displayed after installed successfully.




Download App Vichome

Scan QR code or go to the link to download and install the App: <https://www.vichome.io/download/>

Launch the app from your smartphone and click the Sign Up button. Follow the on-screen instructions.


3. Insert the Micro SD card

Insert the Micro SD card gently on the side edge of camera.



4. Connect the power to the camera

Connect the power to the camera by Type-C Power Adapter.(DC 5V/2A)










5. Power on/off and network configuration

- Long press the power button for 3s to power on/off the device.

6. Set up the camera

- Double click the power button to enter the network configurationmode after the prompt tone.
- When connecting the camera for the first time, use the App and follow the instruction to configure the camera network.

<ul style="list-style-type: none"> • To ensure a longer distance connection, the camera only supports the 2.4Ghz Wi-Fi with stronger wall penetration capability and does not support Wi-Fi for enterprise-level authentication currently. Please ensure that the entered Wi-Fi meets the requirements. After completion, click "Continue" to generate the QR code for pairing the camera. 	<ul style="list-style-type: none"> • After pressing the camera switch for 3 seconds, the camera will turn on. The camera will emit the scanning sound "DingDong Ding Dong" after it is turned on (if you do not hear it, please double click the power button). 	<ul style="list-style-type: none"> • After a while, the camera will give out a prompt sound of a successful connection. At this moment, please set the name for the device on the App and select the location you want to place the device. Click "Continue" to complete the pairing. 	<p>❶ Possible problems with binding:</p> <ul style="list-style-type: none"> • When you hear the "Wi-Fi Password Error", please check whether the Wi-Fi password you entered in the App is correct; • When you hear the "Authentication error", please ensure that your Wi-Fi network is not an enterprise-level network, and the device supports only the network with the security level below WPA-2; • When you hear the "Wi-Fi not found", please check whether you select or enter the correct Wi-Fi name, and place the device near the Wi-Fi router and ensure that the router is powered on. Please note that 5Ghz Wi-Fi cannot be searched by the device; • When you hear the "Retrieving IP timeout", it indicates that the number of devices connected to the router in your home is too many to connect more devices. Please remove some of the connected devices that are not commonly used or restart the router to clear the unconnected devices. You may need to contact the router administrator; • When you hear the "Cloud service connection fail" please check whether your router is connected properly to the external network. When you hear this error prompt, it is common on the condition of network disconnection or that the selected router in your home is a local area network server. Please ensure that the network connection is normal, and try to temporarily turn off the firewall to connect again. 	<p>6. Place or Mount Your Camera</p> <p>You can place your camera on a shelf or other flat surface, or you can mount it to the wall.</p> <p>To mount your camera to the wall:</p> <ul style="list-style-type: none"> • Fasten the mounting screw into the wall, and then mount the camera from the screw. • If you're mounting the camera to drywall, be sure the plastic drywall anchors that are provided. 	<p>7. Support</p> <p>Lifetime Support and 24-hour customer service Email: support@itymol.com</p> <p>Contact us by Amazon for a Replacement or Refund if you receive the defective item. We apologize for any inconvenience caused and will provide you with 100% assistance.</p>	<p>CE FC RoHS</p> <p>All trademarks are used for reference purposes only. Thanks again for choosing our smart camera! Make life safe in your hands! Boost security mobility in your smartphone!</p>
	<p>Power button</p>  <ul style="list-style-type: none"> • Take the lens of the camera facing the QR code generated on VicoHome about 20 cm (7 inches) until you hear a "Ding" sound. 				<p>You're done! Congratulations! Your camera is set up and ready to go.</p> 	

尺 寸 公 差			要求		品名	IPC EL04301 艾索思 折页 说明书		比例	1:1	日 期 DATE	2024.04.10
位 数	尺 寸	角 度	100g书纸 双面单黑 色印刷. 共14P 风琴 折 ROHS.								
x/x.x	±1mm	±1°									
		±1°									
					料号	40610000013044	设 计 DESIGNED	夏媛媛	审 核 CHECKED	曾庆梅	
					版 本 FORMAT	A	制 图 DRAWN		批 准 APPROVED		
					深圳奥尼电子股份有限公司 SHENZHEN AONI ELECTRONIC CO., LTD						
记 事			变更NO.	年/月/日							

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.