

Wireless fence instructions

Transmitter


- 1、 Plug in the power supply DC 5V。
- 2、 Press 。
- 3、 Gear adjustment: the on/off key is also the gear adjuster, which is adjusted clockwise, the gear is adjusted from small to large, and the gear is adjusted counterclockwise from large to small。
- 4、 The table of performance parameters is as follows:

Gear position	Distance (m)
10	30
20	45
30	60
40	80
50	100
60	140
70	180
80	220
90	260
100	300

- 5、 The receiver warns the dog when he steps out of range of the

transmitter.


Warning Mode: Vibration for 3-5 seconds, then shock for 3-5 seconds, after two cycles, the receiver will always send out a warning sound to remind the dog to return to the active area.



Receiver

Receiver operation

- 1、 Press Start and the light will come on。
- 2、 Press turn off when not in use, the indicator light is off。
- 3 、 Charge and insert DC5V. Flash indicator. The indicator light always comes on when the battery is fully charged。
- 4、 When the power is out, the indicator lights flash slowly。



FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.