



Shenzhen SHANSHUI POWER Technology Co.Ltd

1003, Biwan building, intersection of Baoyuan road and Biwan Road, Xixiang street, Bao'an District, Shenzhen

Telephone: 0755-85296365 After-sale service hotline: 18025324651

Website: www.szssdl.com

Intelligent Analysis Oscilloscope Instruction for Usage



Product Appearance

Catalogue

Product Appearance	1
Product Configuration	2
I.General Popurse Oscilloscope Function	5
II.Automotive Oscilloscope Function	6
III.Waveform Data Review	11
IV.Waveform Transmission	13
V.CAN Analysis	19
VI.CAN Data Review	23
VII.Settings Instruction	23

1.Front of machine

Power switch/Reset button (Long press for 20 seconds to







Product Configuration



3.Back of machine



≤ 由水动力 6





Cigarette lighter (male and female)1 pair

Host machine 1PCS

Charger 1PCS







Oscilloscope probe 4 PCS

P-wires 11 PCS

4.Bottom of machine



Instruction for Usage

1.Connection approaches for data collection

Approach 1

1. Prepare the required accessories: A: Oscilloscope probes: B: Earth wire:

1PCS As shown on the right:

2PCS



Oscilloscope probe

Earth wire



2. Long press the switch button for about 3 seconds, release the button when a drop sound is produced, the host automatically start, as shown on the right:



Switch button

3.Connect one end of the earth wire to the grounding port of the host, and connect the alligator clip to the earth wire of the engine, that is, the engine housing.





4.Connect the oscilloscope probe to the host, as shown in Figure 1 connect the oscilloscope probe to the target circuit, as shown in Figure 2: The oscilloscope probe has 2 gears: X1, X10, please be sure to put the button on the gear of the X1, as shown in Figure 3 (probe has been locked in the position of the X1 when it was manufactured, if you have no special needs, please do not open)



Approach 2

1. Connect quick plug principal line of the oscilloscope to the host, and the quick plug (Y-shaped wire) is connected to the quick plug principal line, as shown in the following figure:



2. The Male of quick connector(Yshaped head) is connected to the camshaft/crankshaft sensor's harness end, and the Female connector is connected to the camshaft/crankshaft sensor. As is shown in the figure on the right:





General Purpose Oscilloscope Function

Click on the g	general purpose	oscilloscop	e		Enter	the interf	face
≤ Ш水动力 № ААСНЦУГЕНИЕВ		🚿 🎟 🚺	다년 100mV/裕	(100mV/络	CHB 100mV/指	00mV/85	
			24.3V/24.3V 频率 5000Hz 占空比17%	周期100ms 簡率 5000Hz 占空比17%	243V/243V 频率 5000Hz 占空比17%	24.3V/24.3V 邮車 5000Hz 占虫比17%	开始
							保存
通用示波器	波形发送 CAN解析	ø	,				触发
			•				标尺
车用示波器	波形查看 CAN数据查 ● • •	看					参数
			🥐 快速移动	D 0 100r	nS/档 Q		٦

Stop

: Enter the interface, waveform is collected in real time. Click the button and the oscilloscope stops collection of signal and shows the oscillogram, and the button change into button. Start

Rapid moving: Waveform acquisition is completed, in order to quickly review waveform, please click the bottom left of the screen to move the progress bar rapidly. The waveform can betemporarily acquisited by quickly sliding to the left or right.





: Enter the document name (CapsLk and numeric symbols are available).

Click the "Confirm" button to show that the waveform has been saved successfully.





Trigger adjustment method:

The position of the trigger level is adjusted so that the waveform is stably displayed at the trigger point, which is usually set at the obvious feature points of the waveform, such as the rising or falling edge.

Automatic mode: Oscilloscope automatically finds trigger events, suitable for use when the signal features are not clear.

Normal mode: The scan is generated only

when the trigger conditions are met, suitable for detailed observation of intricate signals.



One-shot mode: Scan only once when the trigger conditions are met, suitable for capturing a single or nonperiodic signal.





The scale is divided into time scale and voltage scale.

100mV/# 24.3V/24.3V	(第2100mV/核)加速100ms	100mV/#8 24.3V/24.3V	100mV/IS 24.3V/24.3V	
频率 5000Hz 占空比17%	li li	时间标尺	75	
	ų	1.压标尺		(m) 17 (m) 17
	通道 매	CH2 CH3	CH4	标尺
	确认	मर तो		参数
			T2-T1=50ms	Ĺ

Time scale: It is used to measure time-dependent parameters of the waveform, such as cycle, frequency, pulse width, rise time, fall time, etc.

Voltage scale: It is used to measure voltage related parameters of waveform, such as amplitude, peak-to-peak value, RMS value, DC bias, etc.

CH1 100mV/85	642 100mV/IS	C+B 100mV/f5	CH4 100mV/IS		CH1 100mV/#8	(100mV/I答	(100mV/将5	044 100mV/85	
24.3V/24.3V 频率 5000Hz 占空比17%	周期100ms 総年5000Ha 占空比17%	24.3V/24.3V #바루5000Hz 참도바는17%	24.3V/24.3V 細率 5000Hz 占空比17%	停止	24.3V/24.3V 频率 5000Hz 占空比17%	周期100ms 船车5000Hz 占空七17%	24.3V/24.3V 邮中5000Hz 占空比17%	24.3V/24.3V 間率 5000Hz 占空比17%	停止
0				保存	1				保存
2 3				触发	2)			······································	触发
0				标尺	4			•	标尺
			T2-T1 = 50 ms	参数					参数
🥏 快速移动	Q	mS/格 Q 状态	5: 氯氧传感器信号	5			mS/格 Q		E

Parameters

Adjust the cycle, frequency, peak-to-peak value and duty cycle of CH1-4 respectively.

Cycle: It is used to measure the speed of signal change, referring to the time required for the signal to complete a full cycle.

Frequency: It indicates the number of times the signal completes cycle change per unit time, and is reciprocal to the cycle.



Peak-to-peak value: It refers to the voltage difference of the signal waveform from the peak to the trough, which can reflect the voltage variation range of the signal. It plays an important role in the evaluation of signal strength and amplitude modulation.

Duty cycle: It is used to describe the ratio of the duration of a high level in a pulse signal to the entire cycle.



: Click this button to stop the oscilloscope and exit the oscilloscope interface back to the initial interface.



: After the oscilloscope settings are changed, there may be abnormal display or inaccurate measurement, etc., you can quickly restore all the parameters to the known, calibrated initial value to ensure another correct measurement and observation.

Time adjustment:

Change the time length of each scale of the timeline in the horizontal direction, that is, the length of time represented by each scale. For example, change from the defaulted 1 ms per scale to10 ms per scale.



Waveform adjustment:

As for CH (1-4) waveform adjustment, click on the button CH (1-4) in the same way. Take CH1 for example, in terms of the rest of the channel, please refer to CH1:



Enter the interface



Waveform display: The CH1 waveform can be turned off or displayed.

Waveform invertion: Oscilloscope waveform invertion refers to the phase difference between the displayed waveform and the actual input signal is 180 $^{\circ}$, that is the waveform invertion.

CH1 100mV/档	CH2 100mV/指	CH3 100mV/裕	CH4 100mV/格	
波形 显示 <mark>开启</mark> 英团	周期100ms 感知5000Hz 占空比17%	24.3V/24.3V 频率 5000Hz 占空比17%	24.3V/24.3V 频率 5000Hz 占空比17%	开始
波形 开启 关闭		-		保存
耦合 直護 <mark>交流</mark>		**********	******	
探头 x1 [x10] x100				触发
低直 设置 💽 500mv 🭳				标尺
(快速移动 🛑	D 2 100m	5/格		_

Automotive Oscilloscope Function

1.Collection and saving

Click on the general purpose oscilloscope

🗾 山水动力		*	CHT 100mV/裕	100mV/#8	CHB 100mV/fg	CH4 100mV/88	
			24.3V/24.3V 期率 5000Hz 占空比17%	周期100ms 编率 5000Hz 占空比17%	24.3V/24.3V 規率5000Hz 占空比17%	24.3V/24.3V 期率 5000Hz 占空比17%	开始
			1				保存
通用示波器	波形发送 CAN解析	ø	D				分析
			0				选项
Julain	波形查看 CAN数据查看	9 9					参数
车用示波器	•••	A 3	(注题)	Q 100	ImS/格 Q 秋さ	5: 氮氧传感器信号	5

Coupling settings:

DC coupling (DC) : The oscilloscope will display the DC AND AC of the input signal, truly reflecting the original form of the signal, including the DC bias voltage and AC change, suitable for observing signals with DC.

AC coupling (AC) :The oscilloscope will block the DC of the input signal through the capacitor and only display the AC. It can remove the DC bias in the signal and make the oscilloscope more focused on the AC features of the signal.

Probe attenuation: The oscilloscope probe usually has different attenuation coefficients, such as 1:1, 10:1, 100:1, etc. Taking the 10:1 probe as an example, it will attenuate the amplitude of the input signal to 1/10 of the original, and then send it to the oscilloscope for measurement and display.

Vertical settings: It is used to set the voltage value represented by each scale in the vertical direction of the oscilloscope, which can be adjusted according to the amplitude of the input signal, so that the waveform can be fully displayed in the vertical direction, and it is easy to observe and measure the details of the signal.



: Enter the interface, waveform is collected in real time. Click the button and the oscilloscope stops collection of signal and shows the oscillogram, and the button change into \underbrace{Start} button.



: Enter the document name (CapsLk and numeric symbols are available). It is recommended to name based on the engine model.

Click the "Confirm" button to show that the waveform has been saved successfully.

Rapid moving : Waveform acquisition is completed, in order to quickly review waveform, please click the bottom left of the screen to move the progress bar rapidly. The waveform can

be temporarily collected by quickly sliding to the left or right .

2. Waveform analysis method

Step 1: Click Analysis button to show manual comparison and automatic analysis.

Manual comparison: Click this button to enter the waveform comparison function, in which data of SHANSHUI and oscillogram saved by users can be found for comparison with the previous oscillogram.

CH1 100miV/81	100mV/85	(H3) 100mV/ł8	100mV/H	
24.3V/24.3V 前年5000Hz 占空比17%	/例例100ms 約年5000Hz 占约比17%	24.3V/24.3V 800 50004z 61551;17%	24.3V/24.3V 前用 5000Hz 古空社(17%	开始
				保存
,			人工分析	分析
			目初分析	选项
				<u> </u>
12.345.05		ImS/łã 🔾 😻	志: 氯氧传感器信号	III 5

Step 2:

Click to save data or data of SHANSHUI according to customers' requirements



Self-saved data : Waveform collected and saved for the user

: Image reference data provided for SHANSHUI POWER.

Step 3:

Data of

SHANSHUI

24	21/24 21/	Parti 100ene	24 20/24 20	
-	\$ 5000Hz	6014 5000Hz	#1#1 5000Hz	留甲 5000Hz
				占至比17%
1			朝柴	
8-	BF6M2012-		大柴	自保存数据
	BF6M2012		德国曼	• 山水数据
			电装日野	
			红岩	

Click on the engine brand, for example click on the "H3CW28TC" menu, and the reference image will be displayed below the current image for comparison with the image above.

通道一 10.0V/-6.0V 732Hz 50%	通道二 4.4V/0.0V 0Hz 0%
H3_CW2_8T c. bin	氏 开始
H 5_CW 4D20 B. bin	
V	大柴 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
1	唐 国曼 自保 存数据
	电 装田野 山水 数据
	5 风 选项
上一页 下一页	上一页 下一页
通道一 5V/格 1ms/格 通道二	5V/格 1ms/格 正时波形监测 退 出
	12





: Click this button, and the machine will show the testable sensor or actuator. Choose this menu to perform testing, with no time and voltage adjustments required.



: For cycle, frequency, peak-to-peak value, duty cycle function description, please refer to general purpose oscilloscope.

3.1.Waveform zoom in/zoom out method (Button-based adjustment)



As shown in the above, on the screen of the waveform acquisition, waveform review, click on the up, down, left and right keys of the button, namely 🛛 🔽 🚺 to zoom in or zoom out the waveform time base and vertical voltage for observation acquisition.

As shown in Figure 1 on the right, click , and waveform is displayed as such.

As shown in Figure 2 on the right, click , and the waveform is displayed as such.

As shown in Figure 3 on the right, click , and the waveform is displayed as such.

As shown in Figure 3 on the right, click , and the waveform is displayed as such.

CH1 100mV//8	CH2 100mV//8	CH3 100mV//8	CH4 100mV/指	
24.3V/24.3V 频率 5000Hz 占空比17%	周期100ms 频率 5000Hz 占空比17%	24.3V/24.3V 频率5000Hz 占空比17%	24.3V/24.3V 续率 5000Hz 占空比17%	F
	\mathcal{N}			
2				Î
3				[#
3				1
(快速移动)	D 0 100r	nS/偕 Q		

100mV/指 24.3V/24.3V 銀時 5000Hz 赤空料217%	100mV/格 周期100ms 病率 5000H2 点中社17%	24.3V/24.3V 89655000Hz 4591E1726	CH4 100mV/指 24.3V/24.3V 映市5000Hz 人で相当7%	开始
	\mathcal{N}	\mathcal{M}		保存
2				触发
D				参数
使速移动 🔵	D Q 100m	s/偕 🔍		<u></u>

CH1 100mV/指	CH2 100mV/指	CH3 100mV/łä	CH4 100mV/łä	
24.3V/24.3V 鉄座 5000Hz 占空比17%	周期100ms 频率5000Hz 占空比17%	24.3V/24.3V 频率5000Hz 占空比17%	24.3V/24.3V 频率 5000Hz 占空比17%	开始
	\mathcal{N}	\mathcal{M}	WWW	保存
2				触发
D				标尺
B				参数
(快速移动)	0 100m	5/楷 0		



3.2 .Waveform zoom in/zoom out method (Gesture adjustment method)

A:Vertically zoom in/zoom out gesture

Press and hold the screen with two fingers, and the two fingers are separated up and down to both sides at the same time. Channel 1 and channel 2 will be zoomed in vertically at the same time (Similar to the zoom-in of the screen of mobile phone) as shown in the following figure:

CH1 100mV/档	CH2 100mV/#5	CHS 100mV/85	CH4 100mV/85		CHI 100mV/łg	100mV/8	(H3) 100mV/7%	0H4 100m9V/fg	
24.3V/24.3V 频率 5000Hz 占空比17%	/規則100ms 始年5000Hz 占空北176	24.3V/24.3V 魏阳5000Hz 占空比17%	24.3V/24.3V 밝후 5000Hz 금모比(17%	开始	24.3V/24.3V 標準 5000Hz 占空比17%	周期100ms 續率5000Hz 占空比17%	24.3V/24.3V 續寄 5000Hz 占空比17%	24.3V/24.3V 维泰 5000Hz 占空比17%	开始
				保存					保存
8			يسيعه	触发					触发
D				标尺					标尺
0				参数	3				参数
(R#83)	D 0 100m	s/m		٦	(快速服动 🔵	 100m	IS/18		٦

Normal display

Channel 1 After vertically zoom in

Press and hold the screen with two fingers, and move the two fingers up and down inward at the same time, and channel 1 and channel 2 will be zoomed out vertically at the same time (Similar to the zoom-out of the screen of mobile phone) as shown in the following figure:

CH1 100mV/85	CH2 100mV/#	CH3 100mV/f2	CH4 100mV/Ith		QH1 100mV/档	00mV/#	CH3 100mV/ft	0044 100mV/85	
24.3V/24.3V 旗母 5000Hz 占空比17%	7回期100ms 銀線5000Hz 占空比17	24.3V/24.3V 熱影 5000Hz 占555比17%	24.3V/24.3V 58년 5000년2 占오比기7%	开始	24.3V/24.3V 誤事 5000Hz 占空比17%	周期100ms 競亭5000Hz 占空比17%	24.3V/24.3V 集中 5000Hz 占空比17%	24.3V/24.3V 姚泰 5000Hz 古空比17%	开始
******				保存			~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~		保存
2				触发	2				触发
8				标尺	D				标尺
D				参数	3				参数
(RH83 🔵	0 100ms			٦	(1948a)		m\$/ł8 Q		ß

Normal display

Channel 1 After vertically zoom out

B:Horizontally zoom in/zoom out gesture

Press and hold the screen with two fingers, move the two fingers left and right at the same time, and channel 1 and channel 2 will be zoomed in/out horizontally at the same time (**Similar to the zoom-in/out of the screen of mobile phone**) as shown in the following figure:





Normal display

Channel 1 After horizontally zoom in

触发标尺

参数

ŋ

4.Waveform adjustment: Click the CH (1-4) button to adjust the CH (1-4) waveform. The methods for CH (1-4) are the same. CH1 can be used as a reference for the remaining channels.

CH1 100mV/格	CH2 100mV/格	CH3 100mV/格	CH4 100mV/格	
波形 显示 <mark>开启</mark> 关闭	周期100ms 频率 5000Hz 占空比17%	24.3V/24.3V 频率5000Hz 占空比17%	24.3V/24.3V 频率 5000Hz 占空比17%	开始
波形 开启 关闭			www.www.www	保存
耦合 直流 交流 设置 「二」				
衰減 x1 <u>x10</u> x100 垂直 ⊕ 500my ⊙				
				参数
快速移动	① ① ①	S/格 Q		L D

Waveform display, waveform invertion, coupling settings, probe attenuation, vertical settings function, please refer to the general purpose oscilloscope.

Waveform Data Review

Step 1:



Step 2:

Click

reviewed or deleted.

These data are general purpose

oscilloscope menu, and images saved by users. The waveform can be



Figure 1



Figure 2

Step 3:

In figure 2, click , and the manufacturers data image and the image collected by users will be displayed.







"Images collected by users" This data is the waveform collected and saved by users in the automatic oscilloscope. You can open to review or delete the saved files, as shown in the figure:

Step 4: Automotive oscilloscope data review select engine brand manufacturers, such as Changcheng



> 波形查看 > 用	戶自采集	
挖机	提示	
收割机 -		
搅拌机		A
客车	请选择对文件的操作	P
大巴		
小挖土机	一般除したが正式	
推土机		

Step 5



Step 6: Click and enter to review



The voltage can be adjusted by moving the two fingers up and down at the same time (**Similar to the zoom-in of the screen of mobile phone**) as shown in the following figure:



Time can be adjusted by moving the two fingers left and right at the same time, (Similar to the zoom-in of the screen of mobile phone) as shown in the right figure:



Waveform Transmission

This function is designed to provide a timing signal for the ECU of the engine, so that the ECU can work normally to check whether the engine timing signal is normal. The timing signal transmitted by this product is not the real timing position of the engine, but only an analog signal, so it is strictly prohibited to start the vehicle when using this function. Please follow the instruction for usage strictly.

I. Connection methods for Hall and Magnetoelectric sensor

Prepare the required accessories: 2 oscilloscope probes, 1 earth wire; Or 2 quick plug cables and 2 quick plug principal lines, as shown in the following figure:



1.Hall sensor connection

Step 1: Please connect one end of the earth wire to the ground port of the host machine, and connect the alligator clamp to the ground wire of the engine, that is, the engine housing.







Step 2:

Connect the oscilloscope probe to the host, as shown in Figure 1 Connect the oscilloscope probe to the signal line of the Female connector of the timing sensor, as shown in Figure 2

The oscilloscope probe has 2 gears: X1, X10, please be sure to put the button on the gear of the X1, as shown in Figure 3 (probe has been locked in the position of the X1 when it was manufactured, if you have no special needs, please do not open)



2.Hall sensor quick plug connection

Step 1: Connect the quick plug principal line of the oscilloscope to the host, and the quick connector is connected to the quick plug principal line.



Step 2:

Connect the Male of the quick connector (Y-shaped wire) to the harness end of the camshaft sensor. The Female connector is vacant and does not need to be connected.



Line 6 is a universal jumper wire, which is used when all connectors do not match.

The black line of the jumper wire with is connected to the ground wire of the Female connector of the harness end, while the red line is connected to the signal line of the Female connector of the harness end. (Please avoid reverse connection.)



3. Method for Magnetoelectric sensor connection when signal is transmitted

1. Connect the oscilloscope probe to the host, as shown in Figure 1.

2. Connect the oscilloscope probe to one line of the Female connector of the timing sensor, and connect the earth wire to the other line (No distinction between left and right), as shown in Figure 2.

3. The oscilloscope probe has two gears: X1 and X10, please be sure to put the button on the gear of X1, as shown in Figure 3 (The probe has been locked in the position of X1 when it was manufactured. If you have no special needs, please do not open).

🗾 由水动力





4. Quick plug connection method for Magnetoelectric sensor

Connect the oscilloscope quick plug principal line to the host machine, and the Step1: quick connector is connected to the quick plug principal line.





end. (No distinction between left and right)

How to use Line 6 plug

Line 6 is a universal jumper wire, which is used when all plugs do

The black line of the jumper wire with is connected to one of the

lines of the Female connector of the harness end, while the red line

is connected to another line of the Female connector of the harness

Step 2:

Connect the Male of the quick connector (Y-shaped wire) to the harness end of the camshaft sensor. The Female connector is vacant and does not need to be connected



22

not match.

II.Signal transmission method





Transmission is not available in general purpose oscilloscope.

(Standard data collected by SHANSHUI POWER)

Step 3:

Or

- Click 5
 - (Oscillogram collected and saved by users from oscilloscope) *

Step 4:

Select engine brand manufacturers, such as Changcheng



CAN 通用示波器 波形发送 CAN解析 1.11 CAN 由形态于 CAN数据查看 车用示波器 ... > 波形发送 Ð 通用示波器 车用示波器



Step 4

Select: H3-CW2-8TC.bin





Step 5:

Please read the prompts carefully and click "Confirm".

Note: Violation of this operation may cause engine to be seriously damaged. Our company shall not bear any legal responsibility for the damage caused by this.



故形发送 > 车用示波器 > 厂家数据图像 > 长城

请将示波器通道按以下方式连接

1500

300

通道1连接车辆曲轴传感器口 通道2连接车辆凸轮轴传感器口



Step 6:



The channel 1 is connected with the camshaft, and channel 2 is connected to crankshaft, click Confirm.

Step 7:

Start to transmit the waveform, you can select different engine speed, if the crankshaft or camshaft sensor harness is reversely connected, and it is failed to be identified by the vehicle, you can adjust the camshaft inverting voltage through the lower right camshaft invertion.

1500





Pre-invertion



CAN Analysis Function

Step 1:

Prepare the CAN analysis harness and connect the OBD connector of the vehicle. The terminal core ground cable, CAN+, and CAN- are respectively connected to the OBD port.



Connect the cable harness to the DB15 port on the host, connect the CH1 cable harness to the CH1 port on the host machine, and connect the CH2 cable harness to the CH2 port on the host.

24



Step 2:



CAN Analysis to enter the data collection interface.



CAN Analysis data collection interface

1.Baud rate: According to the data transmission rate of the vehicle CAN bus, select the unused baud rate of 250K, 500K or the customized rate.

2.DBC: Select J1939 or ISO15765

3.— can be used for zoom-in/out of the time base of the waveform, and for the convenience of observation.



5.Click the bottom right (2) and enter the full-screen data display Interface, as shown in the right figure.

序号							数据
800000	发送	1234567	成功	0x0000122	标准帧	0x08	11 22 33 44 55 66 77 88
000008	发送	1234567	成功	0x0000122	标准帧	0x08	11 22 33 44 55 66 77 88
000008	发送	1234567	成功	0x0000122	标准帧	0x08	11 22 33 44 55 66 77 88
000008	发送	1234567	成功	0x0000122	标准帧	0x08	11 22 33 44 55 66 77 88
800000	发送	1234567	成功	0x0000122	标准帧	0x08	11 22 33 44 55 66 77 88
000008	发送	1234567	成功	0x0000122	标准帧	0x08	11 22 33 44 55 66 77 88
800000	发送	1234567	nt C	×00001	示准帧		11 22 33 44 55 66 7

6.Click

to pop up dialog box "please enter the serial number", click "Confirm" to search. The serial number must be within the range of the current settings, otherwise the data may be failed to be queried.





to pop up and save dialog box, enter the document name and click "Confirm" to save the data in the machine



8.Click data information to display all the frame details and the frame data can be edited. For example, click 0x18FD2000 as shown in the following figure.

CAN	据分析	ĥ							> CAN數	据分析)
序号	方向	时间 ms	状态	ID	类型	DLC	数据	1	序号				官息提示					Î
					标准帧			88	000008	序号	方向	时间ms	状态	格式	类型	DLC	77 88	
8000	发送	1234567	成功	0×0000122	标准帧	0x08	11 22 33 44 55 66 77	88	000008	000008	发送 0x00001	2000.123	成功	数据帧	标准帧	0x08	77 88	
80000	发送	1234567	成功	0x0000122	标准帧	0x08	11 22 33 44 55 66 77	88	800000	数据	11 22 33	44 55 66 77	88				77 88	
80000	发送	1234567	成功	0x0000122	标准帧	0x08	11 22 33 44 55 66 77	88	800000	数据分析	統演1000統	复复5V开路	依法计器单	完小于400mA			77 88	L
80000	发送	1234567	成功	0x0000122	标准帧	0x08	11 22 33 44 55 66 77	/ 88	000008	实际轨	压小于50ba	r.且持续时间>2	S		2		77 88	1
80000	发送	1234567	成功	0x0000122	标准帧	0x08	11 22 33 44 55 66 77	/ 88	800000			10 15 10 40		at fet			77 88	1
80000	发送	1234567	_成 O	0x00001	示准帧	H	11 22 33 44 55 66 📈	2	000008			2411-2411-0					P	Ī.
					_						_	20			_			



9. Click to select "edit" and enter the "edit" interface, then the frame ID, type, data, interval can be modified.

· ·	21112/0-	1 7	12	-/~~

1 enter the "edit"	> CAN	数据分	析							
, type, data,	序号	方向	时间 ms	状态	ID	类型	DLC		数据	Î
	000008	发送	1234567	成功	0x00001	22 标准帧	0x08	11 22 33 4	4 55 66 7	7 88
	000008	发送	1234567	成功	0x00001	22 标准帧	0x08	11 22 33 4	4 55 66 7	7 88
	000008	发送	1234567	成功	0×00001	22 标准帧	0x08	11 22 33 4	4 55 66 7	7 88
	▼	选择	ID		类型	数据			波特率	250K
	99	V	0x0000122	Ť	展帧 ▼	11 22 33 44	55 66	77 88	次数	单次 ▼
	99	1	0x0000122	Ť	展帧 ▼	11 22 33 44	55 66	77 88		
E dition interform	99	1	0x0000122	扩	展帧 ▼	11 22 33 44	55 66	77 88		(7)
Editing interface	4 6							×	-	<u> </u>

12. Click on the Data option to edit the current data. For example, enter FO 24 FF 3C 24 FF FF FF, and click "Confirm" to modify the ID address.



10. Click the ID option to edit the current ID. For example, enter 0x18FD2111 and click "Confirm" to modify the ID address.

> CAN	数据分	析									> CAN	放据分析	沂								
序号					类型			数据			序号	方向	时间ms	状态	i	D	类型	DLC		数据	
000008	3 发送	1234567	成功	0x0000122	标准帧	0x08	11 22 33 4	14 55 1	56 77 88		000008	发送	12345	序号	35	编辑	帧ID		2 3	3 44 55 (66 77 88
000008	3 发送	1234567	成功		标准帧		11 22 33 4		56 77 88		000008	发送	12345	0x	0000)122			2 3		66 77 88
000008	3 发送	1234567	成功	0x000012	标准帧	0x08	11 22 33 4		56 77 88		000008	发送	12345		确认			化剂	2 3	3 44 55 1	56 77 88
•						_			_	⊳ ĭ	4	_		-							
序号	选择			类型	数据			波特	率 250	К		14/	E	Ð	т	V	111			D	Delete
99	$\overline{\mathbf{v}}$	0x0000122	扩	展帧 ▼ 1	1 22 33 44	55 66	77 88	次	数 单次	-	Q	vv		R	-	T	U	100	0	P	Delete
											100	2*	•	0			E (EF .	1	/ 1
99	\checkmark	0x0000122	扩	展帧 ▼ 1	1 22 33 44	55 66	77 88				123	,:	A	5				9		J	\ L
99	1	0x0000122	扩	展帧 ▼ 1	1 22 33 44	55 66	77 88				ABC	: a	bc .	Z	X	С	V	В	N	М	Enter
-							•								10						

13. Click Time option to edit the current time



11. Click Category option, and the current frame "category can be edited, with standard frame or extend frame for options



14. Click Number of Times to select single or circular transmission of data.





山水动力 ANSHULPOWE 11 22 33 44 55 66 77 88 button, and enter the document name to save 16、Click 11 22 33 44 55 66 77 88 the data in the machine. 帧格式 波特率 250K button to transmit selected data. 次 数 单次 🔻 17、Click 数据帧 6 Î H 数据帧 6 6 数据帧 to return to previous menu. 18、Click

2. Click one of the file names to delete or open the file. For example, Open the "1234" file, the data frame information is displayed.



can be used to query data, the serial number entered must be within the range of the current settings,

3. Under the CAN data review file screen, there are

otherwise the data may be failed to be queried.







to review the saved CAN data file name.





 \bigcirc

Click this button to select the number of times and baud rate, you can open the entire file to send out.





Here you can save the open file with another file name.

4. You can also select data or modify the data for transmission.





System Upgrade

🗾 山水动力

Step 1:

Connect the machine to the charger to prevent power outage during upgrade.

Click to enter upgrade interface.



Step 2:

Click the WIFI settings to connect to the network. For example, enter the password of the WIFI'CMCC - ZQRX'' to connect to the network.



Step 3:

Click version upgrade and version update. Wait patiently until the version is successfully upgraded, and the machine will automatically restart. About (3-5 minutes).



Settings Function

1. System information

Click "System Information" to view the software version, hardware version, serial number, activation code, and release time.

2. Shut-down time

You can set the automatic shutdown time. If no operation is performed, the host machine will automatically shut down.



> 设置	1 > 系统信息	🚿 🎟
fit	系统信息	
டு	关机时间	
	蜂鸣设置	
۲	语言设置	
	示波自检	



3. Buzzer settings

Click "Buzzer Settings" to open the buzzer. Click the screen to produce a "drip" sound.



4. Language settings

This product interface menu can be switched between Chinese and English.



5. Oscilloscope self-inspection

This function is mainly used to check whether the oscilloscope is in normal service:

- 1. Check whether the test pin of oscilloscope is damaged.
- 2. Check whether the four channels of the oscilloscope host are intact.



Step 1: Click"Oscilloscope self-inspection"

Step 2:

Connect a test pin at channel 1 (CH1), and then insert the test pin into the ground port, then the screen displays "Channel 1 is successfully inspected" indicating that channel 1 is normal. The inspections for Channel (CH2), (CH3), the above (CH4) are same as above.



Step 3:

If the host and the test pin of the oscilloscope are not damaged, the machine screen will indicate that the self-inspections of channel 1, channel 2, channel 3, and channel 4 are successful.



FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.