

Basic parameters

Product name: FITPOLO Smart Wristband
Operation temperature: -20°C ~ 45°C
Battery type: Polymer li-ion battery
Waterproof level: IP67
Battery capacity: 100mAh
Wireless connections: Bluetooth 4.0 BLE
OS requirements: Android 4.3 and IOS 8.3 or above versions are supported.

*All performance is subject to actual performance


Package

Fitness tracker, USB charger clip, instruction manual.



Wearing

To better use our product, please wear fitness tracker on your non-dominant hand 2cm above your wrist, and keep your wrist clean and dry.



Install the App

Get the "Fitpolo" APP from APP Store or Google Play.



For Chinese Android user, please download from Myapp.




If the download fails, please scan the following QR Code



<https://www.fitpolo.net/app/fitpolo.apk>


Power on

1. Fitness tracker is set to hibernation mode. For the first time using, please long press touch key on screen for 10 seconds or charge battery to activate device, then screen will light up.
2. If fitness tracker doesn't start up after pressing 10s, please adjust and press touch key again or charge fitness tracker.




Start using

1. First, pair with App, enter 4 code into APP pairing page(long press touch key 10s, you will get the code). Please make sure fitness tracker nearby mobile phone, after pairing succeed, fitness tracker will automatically synchronize mobile phone time.
2. Fitness tracker will record your heart rate, exercise and sleep. Lift wrist to light up screen, press the touch key to view the recorded data.



Charging

When screen displaying low power, please charge fitness tracker soon. Make USB contact fellers clip with three points on the back of fitness tracker, then connect the power supply to charge battery.



Ps: When power use out, fitness tracker screen will blink with battery icon at intervals of 3-5 seconds while charging. This is a normal phenomenon. After 5-10 minutes, the battery icon will continue to be displayed automatically.

FAQ

Q: Install App

- A: 1. iPhone: APP Store.
2. Android: Google Play, China: Application of treasure .

Q: Fitness tracker connect with App

A: Long press touch key for 10s, fitness tracker will display 4 code, make sure bluetooth of mobile phone is opened, and enter these 4 code to complete pairing in APP.

Q: Fitness tracker can not connect with mobile phone

- A: 1. Make sure fitness tracker has not connected with other mobile phone.
2. Make sure fitness tracker not power off.
3. Make sure you have installed APP.

Q: Heart rate not accurate / not work

- A: 1. Make sure fitness tracker is properly worn.
2. Make sure fitness tracker is not worn too loosely, and keep it close to your skin while wearing.

Q: How to set time date, alarm ?

A: Click the left menu of APP, and set them according to your requests.

Q: No have sleep data, steps data and heart rate data

- A: 1. Make sure fitness tracker is properly connected to the phone.
2. Click left menu - "About"- "Feedback", Send log to engineer mailbox to solve the problem, engineer will reply you with solutions by e-mail straightly.

Q: APP Sync failed

- A: 1. Make sure fitness tracker is properly connected to the phone .
2. Put tracker close to mobile phone while synchronizing .

Q: No data after sync

- A: 1. Make sure fitness tracker is properly connected to the phone .
2. Make sure fitness tracker is properly worn .

Q: Suddenly quit

- A: 1. Compatible: Android 4.3 & iOS8.3 or above.
2. APP supports both English and Chinese languages, if your mobile phone language is not these two, it may lead to APP suddenly

Q: Upgrading failed

- A: 1. Put fitness tracker nearby mobile phone, don't move fitness tracker or mobile phone while upgrading.
2. Click left menu--"Band Information"-Manually click to upgrade.

Q: No notifications reminder

- A: 1. Make sure fitness tracker is properly connected to the phone .
2. Make sure keep the APP running in the background when using .
3. Android mobile phone : When the fitness tracker is paired with mobile phone , open the notification permission , iPhone : make sure APP has the notification reminder function : "left menu" - "Notification setting" .

Q: The data stored on fitness trackers has been deleted, after fitness tracker synchronized with APP

A: Before using fitness tracker, please synchronize time with APP first, otherwise it may cause data loss.

Warning

1. IP67 waterproof is limited to normal activities in the daily life(include wash hands, take shower, swim). Do not wear it while diving and other underwater activities, don't keep it soaking for more than 20 minutes.
2. Keep fitness tracker away from fire and avoid high temperature.
3. Do not disassemble fitness tracker without professional guidance.

Defects range

1. Can't power on
 2. Can't charge
 3. Pages not complete
 4. Functions can't work based on correct operating
 5. Appearance defects
- Warranty 1 year, except human defects.

Usage instructions

1. Please read instruction manual carefully before using fitness tracker. To avoid unnecessary distress, please use fitness tracker correctly according to instruction manual.
2. This manual is based on default setting of fitness tracker.
3. All performance is subject to actual performance.

FITPOLO Smart Wristband

User Guide



CREATE A HEALTHY LIFESTYLE

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.