

5G IP Camera	Document Version	Pages
User Manual	V1.1.0	25

5G IP Camera XTEE50216 User Manual



Provided by Xingtera Inc. Santa Clara USA

Qualcomm Smart City Accelerator Program Member



FCC statements:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Federal Communication Commission (FCC) Radiation Exposure Statement When using the product, maintain a distance of 20cm from the body to ensure compliance with RF exposure requirements.



CONTENT

Chapte	r 1 Brief Introduction of Product	1
1.1	General	1
1.2	Word Definition	2
Chapte	r 2 IP Camera System	3
2.1	Features	3
2.1.1	Network	3
2.1.2	Svstem	3
2.1.3	External Interface	3
2.1.4	Cloud Platform	3
2.1.5	Other Web Functions	4
2.2	Performance	4
2.2.1	Streaming Concurrency	4
2.3.1	Video Storage	4
Chapte	r 3 Operating Environment	5
3.1	Computer requirement	5
3.2	Connection	5
3.2.1	Equipment power supply	5
3.2.2	Network connection	7
3.2.3	Access to devices	7
3.2.4	Device login	9
Chapte	r 4 MainFunction1	1
4.1	Local Web Management Portal 1	1
4.1.1	Login 1	1
4.1.2	Configuration 1	2
4.1.3	Display Setting 1	2
4.1.4	Video Setting 1	3
4.1.5	Real-time Video 1	3
4.1.6	Video Playback 1	8
4.1.7	Video Record Schedule 1	9
4.1.8	Alarm2	0
4.1.9	Storage Configuration	0
4.1.10	Network Configuration2	1



5G IP Camera User Manual

4.2	Video Stream RTSP Connection	. 25
4.1.15	Device Upgrade	. 24
4.1.14	RTMP Configuration	. 24
4.1.13	SMTP	. 23
4.1.12	Cloud Platform Configuration	. 22
4.1.11	4G/5G Configuration	. 22



Chapter 1 Brief Introduction of Product

1.1 General

IP Camera series provides a comprehensive range of security and surveillance solution to meet users' requirement. The cameras can be set up in a network and controlled or managed locally and remotely. Users can use it as an independent monitoring camera or connect to an NVR to build a surveillance system. With the APP and cloud platform, users will be able to access the camera on a mobile phone and other computer devices.

IP cameras use the high-performance CPU and other industrial-grade units, with the embedded real-time operating system as the software support platform. The cameras support H.265/H.264/MJPEG video compression algorithm and industry-leading HD dual-stream technology to achieve the highest level of video image quality under the limited network resources. It is fully functional, supporting for flexible and comprehensive alarm linkage mechanism, day and night auto switch, smart PTZ control and privacy masking, etc.*

The product has been widely used in the M2M industry of the IoT industrial chain, such as smart grid, intelligent transportation, smart home, finance, mobile POS terminals, supply chain automation, industrial automation, intelligent building, fire protection, public safety, environmental protection, meteorology, digital medical, telemetry, agriculture, forestry, water, coal, petrochemical and other related fields.



1.2 Word Definition

Word	Explanation
IPC	IP Camera
	Advanced Video Coding (MPEG-4 AVC) is a block-oriented
П.204	motion-compensation-based video compression standard.
	High Efficiency Video Coding(HEVC), also known
	as H.265 and MPEG-H Part 2, is a video compression
П.205	standard, designed as a successor to the widely used AVC
	(H.264 or MPEG-4 Part 10).
	Motion JPEG (M-JPEG or MJPEG) is a video compression
MIREC	format in which each video frame or interlaced field of a
MJFEG	digital video sequence is compressed separately as a JPEG
	image.
	The Session Initiation Protocol (SIP) is a signaling protocol
SID	used for initiating, maintaining, and terminating real-time
SIF	sessions that include voice, video and messaging
	applications.
	Wide Dynamic Range (WDR) is a term used in the
WDR	surveillance camera industry to refer to high-dynamic-range
	imaging.
	The Real Time Streaming Protocol (RTSP) is a network
RTSP	control protocol designed for use in entertainment and
	communications systems to control streaming media servers.



Chapter 2 IP Camera System

2.1 Features

2.1.1 Network

- Ethernet: 1*RJ45 10M/100M Ethernet Port
- ✤ Network Storage: NFS、CIFS/SMB
- Protocol: IPv4/IPv6, TCP, UDP, RTP, RTSP, RTCP, HTTP, HTTPS, DNS, DDNS, DHCP, FTP, NTP, SMTP

2.1.2 System

- Storage: Support Micro SD/SDHC/SDXC Card Local Storage, up to 128G
- Advanced Function: Motion Detection, Privacy Masking, Backlight Compensation, HLC, 2D DNR, 3D DNR, ROI, Anti-fog, White Balance, EIS, IP Address Filtering
- Event Trigger: Motion Detection, Network Disconnection, External Input, Audio Alarm, etc.
- Event Action: FTP Upload/SMTP Upload/SD Card Record or Snapshot
- System Compatibility: Onvif Profile S, GB/T28181

2.1.3 External Interface

- Power: DC-12v or POE
- ✤ Audio: 1*
- ✤ Alarm: 1 Alarm In+1 Alarm Out (Port can Drive 12V or 5V Relay)*
- Relay Out: 1 Relay OUT*
- ✤ ADC In: 1 8bit IN*
- UART Port: TTL@115200bps Or Expansion for RS485*
- * = Optional

2.1.4 Cloud Platform



 Remote web server device management cloud platform for user to doremote status monitoring, configuration and update, etc.

2.1.5 Other Web Functions

- Local web server for device configuration, system maintenance, storage management, video monitoring, etc.
- Video Playback: Support video playback on web browser
- NTP: NTP with RTC, support timed reboot, scheduled power on or off
- ✤ Internet: Support IPv4 & IPv6, including static IP and DHCP.
- External PTZ: RS232/RS485 + Pelco-D

2.2 Performance

2.2.1 Streaming Concurrency

Support maximum 10 ways video real-time streaming when all 3 stream types are on. (Primary, Secondary and Tertiary stream. 2 ways 1080P, 1 way D1 30fps, using H264/H265/MJPEG)

2.3.1 Video Storage

Support 1 way SD card scheduled video recording & image capture, multi-way SD card alarm recording & capture.



Chapter 3 Operating Environment

3.1 Computer requirement

- Recommended Windows 8 and above.
- IE 11 or above.

3.2 Connection

3.2.1 Equipment power supply

IP camera supports PoE power supply and DC 9-60V wide voltage power supply. Users can choose one of the power supply modes to power the equipment. The power supply and network interface can be seen at the end of the camera after the screws around the cover plate are removed.



• Power interface diagram:



• Terminal Interface:



When the device is normally powered on, the infrared light at the front of the camera will flash quickly, and there will be a slight clicking sound inside the lens. At the same time, when the back cover is opened, it can be seen that there are lights inside.





3.2.2 Network connection

The camera can be connected to the computer for debugging and configuration in the following ways:

1. Direct computer connection



2. Connect through a switch or router



3.2.3 Access to devices

Factory default configuration page address of IPC is http://192.168.1.100. Default user name is admin, the password is admin. If the computer and the camera are in a different network segment so that customer cannot directly access the camera from the computer.

In the case of a direct computer connection, it is necessary to set a fixed IP address for the computer first. The specific operation is as follows:

1. Open the Network Connections page of the computer and right-click the Ethernet and choose properties.





2. Modify IPv4.

Ethemet Prope	rtes	6
Networking State		
Cornet using		
🖉 Radati PC	In FE Family Controller	
The connection of	ass the following store:	Codyse
R B Chet for C Vibure R C No and P C C No	Macaash Networks, Bridge Protocol Protein Braing for Microard Kell Scheeluler Network: Adapter Matpie LLDP Protocol Driver	n Tatunka ar Palacai v
e late		3 117/6-117/01
Description Transmission Cr wide area netwo	untral Protocols Internet. Pro ork: protocol: High provides	stocal. The default
ACTOR OVERALL	Literative concernence internative	



3. Set the COMPUTER IP to any address in 192.168.1.x network segment.

Internet Plotocol Version 4 (3CP/9)	v4) Properties >
General	
Tou can get IP ontings assigned as fail capatility, Otherwise, you nee for the appropriate IP ontings.	donotically if your metsion's supports d'to ask your metsion's administrator
O gaton at 2F address automat	colty .
i∰ tige the following P address:	
P athese	192 . 100 . 1 3
Sylevel wash:	299 -209 -209 - 0
Online Company	182-168 - 1 - 1
Open Ord an address a	health
Use the following DNS arrow in	all water
(Eventernet DNS aurore)	1.1.1.1.1
gibernabi ChiS server:	1 + + + +
(widowe settings upon and	Adjancat
	OK Center
00. 1. 4 2012 100111	25 I 105.00

4. Try to access the IP camera configuration web page http://192.168.1.100 from Internet Explorer.

3.2.4 Device login

- 1. Open IE browser (IE 8.0 or above) and enter the IP address of IPC.
- 2. Enter ID and password to login.

Notice:

1. Initial account of standard version: admin; Password: admin.

xingtera		
	and and a second distance of the second dista	
	Partiel (Inverse) investigation of the second	



2. The user needs to install the video plug-in when the user login to IE for the first time.

Click and download the video player plug-in.



3. After finish downloading, install the video plug-in.



4. After finish installing the video plug-in, refresh the IE. Users can check real-time video monitoring on IE and user can operate different functions of IPC on this web interface.





Chapter 4 Main Function 4.1 Local Web Management Portal

We recommend using Windows Internet Explorer to get the best user experience. You may require installing some plug-ins before you use the web portal.

4.1.1 Login

The default login credential is printed on a tag on your camera. The login IP address is 192.168.1.100, username is admin, and password is admin unless you have changed them before.

Type in the address and user info, click login to enter the management portal.

	1.4) [het].	(A) = 10 ·
kongterb.		(1000 · · · · · · · · · · · · · · · · · ·
	anter-	
	The last strategy last a last strategy	

4.001 + ...



4.1.2 Configuration

Click the 'Configuration' tab on the top menu, user can manage the IPC from the following page.

The side menu has list out all the items that user can configure. User can do detail configuration on the right side of the side menu after clicking the related item.



4.1.3 Display Setting

Support web video image adjustment, including Basic Settings, Day & Night Switch, OSD, Private Mask, ROI, etc.





4.1.4 Video Setting

Video Audio

Support video configuration, including Stream Type, Video Format, Resolution, Quality, Time, Bit Rate, CBR/VBR Type, etc.

A REAL PROPERTY AND A REAL	a liner Clanel.	Primary 701441	4
	01000	4.314	
Condition 110 1	Haladadam.	N SAL LOUP HALL	
THE TOP OF	Coding Companity	Normal	-
	Manual Para Aste (Sec	25	- V
	1-fairs interval (frame in still)	(a)	
	BUILDNE STORE	2048	
	Kee Too:	CON	-

4.1.5 Real-time Video

Real-time video is supported in IPC web interface and user can control the IPC remotely at the same time.

Processes:

1. Login the IPC web interface.

Table 4



2. Click preview option on the top of the menu. At the lower right corner, user can remote control IPC such as play/stop live video, snapshots, video recording. Some cameras can support lens zoom, focus and other features.



3. On the video preview interface, the recording videos and snapshot are stored on the local disk. After finish record the video or snapshot, the system will automatically pop up the local disk window of the recording video/snapshot so that users can view it at the same time.





4. User can setting the record video storage path on the IPC web interface.

0)- S-			A were B have
C2 (964)	Strephene Strephene All Step Stort	trank trank the	1
12 mm	Manager Tax, or get	(team)	
2 Aug	Handah Figu Figu.	a state of the second s	
11.0000 2	Protect Parts	times ()	
() Tabart			
And Addresses			
River Cont.			



Buttons of image setting:



Button	Description	
to	Primary stream	
20	Secondary stream	
25	Window size	
23	Real size	
8 3 6 3	Full scream size	
100 -	Protocol setting	
	Play	
	Stop	
0	Snapshot	
	Brightness	
O	Contrast	
-	Sharpness	
Д.	Noise reduction level	
C	Default	
*	Video recording	
۲	Saturation	



Buttons of IPC remote control:



Button	Description
	Len
	configuration
Q	Zoom in
Q	Zoom out
đ	Focus increase
0	Focus reduce
0	Iris increase
0	Iris reduce
S	Focus speed
	Lens
Ο	initialization
	Auxiliary focus
0	Auto iris

4.1.6 Video Playback

The IPC web interface supports video playback function. User can use the IPC web interface to play the recorded video from the IPC storage directly. You may require to install plug-ins before you use this function.

Processes:

- 1. Click the playback on the top of menu.
- 2. Select the date and time on the right side.
- 3. Click the play button to playback the video.



4.1.7 Video Record Schedule

User can set the recording schedule so that the IP camera can record automatically at regular intervals.

Processes:

- 1. Click the configuration on the top of menu.
- 2. Select the storage option on the left side.
- 3. Choose record schedule on the top.
- 4. Enable the record schedule.
- 5. Choose the disk.
- 6. Select the recording day & time period and save.





4.1.8 Alarm

The product supports various event alarm functions, by setting up some trigger conditions and the related actions to inform user to check and take action.

Molice Dataction			
		Sans Action > Associated	Configuration > Schedule Settings
Asses	ICENTRAL COMPANY	theter.	(C)
-	March Street, or other	Secultivity	
	N =	Eradok Alemi Necurz	
	122 TO A	grape Aam Inaphic	17
And the second se	and the second se	Shange One Notten	Unit 8 (UD Card) =
		Lighteen Via 204779	0
	and the second se		
	Chart H. Chan H.		

4.1.9 Storage Configuration

The product support storage management, storage configuration, file search, scheduled recording, scheduled image capture, etc.

1	Date No.	Catality	Remaining	1999.00	Term	Protectla	Construction Contractor		
		18.430	4.000	TASTTUE	60 C#4	100	Carrynt Daw o information	1000	
							untile colmou?	4 290	
							Image Distaining Space	4,000	
							Encord Capacity	9.755	
							Record Remaining Space	# 200	
							Capture Storage Percentage:	<u>ж</u>	
							Record Blocoge Percertiage:	31	



4.1.10 Network Configuration

The communication port used by the device to transmit data can be configured on the port setting page. The default port numbers used by http/https/rtsp are 80/443/554.

VETER Post (1 discuss) Are	
WTTER POT IT ADDITION	

If you want to use RTSP to connect, please try to fill in the target address in the following format,

rtsp://user:pass@192.168.1.100:554/main

(user:pass needs to be replaced with the username and password of the system. Default admin:admin)

The IPC device supports two types of IP address configuration methods: fixed IP, or DHCP Client. The configuration interface is shown in the figure below.

Port Settings	TCP/IP	HTTPS	SMTP	Cloud	FTP/SFTP	4G/5G	GBT Settings	Online Reporting	RTMP
					IPvé Setings:				
					IPv4 Mode:		Fixed IP	V	
					Device IP Add	1695	172 . 17	. 18 . 130	Test
					IPv4 Subnet N	fasic	295 . 265	. 255 . 0	
					IPv4 Default 0	lateway.	172 . 17	. 18 . 1	
					IPv6 Setings:				
					IPv6 Mode:		Fixed IP	v	
					Device IPvS A	ddress:			
					IPv6 Mask: (3	127)			
					IPv6 Default 0	alleway.			
					Other Setting	9C			
					DNS Server.		8.8	. 8 . 8	
					Network Polic	r.	1. WHFI V	4G Dial V 3. Wired 1	
					Auto Select N	etwork:	0		
							Save		



4.1.11 4G/5G Configuration

1. Insert the SIM card to the IPC. Click the 'Network' option on the left side of the IPC Web interface and choose 4G/5G on the top of the menu. Enable the 4G/5G

Notice:

1. Make sure the network state is connected, has an IP address and the signal value is above 15.

2. The network state is at least 4G or LTE.

ER some Perfectus statement of	ally yand constant and introduce framely state from
El enge	tota B
di isan	Tarnet Lowerber Cameloo
	en final arc.as
	Types Tangin IN
C Tenant	Control Industry wanted
E Astronom	Section Type: Million v
1 Den. 11	Notice Press
	Communication energy Statistics in
2 mm	(Aust Improv

	A14
	110
	offering (3
	mag come team Place 1
	Control Tourier IP

4.1.12 Cloud Platform Configuration

1. Click the 'Cloud' on the top of the menu, enable it and save. Check the status and copy the device registration ID. (The cloud server address and server port may change by the customer's local server and local port)

Notice: This Cloud Platform Configuration is just for Xingtera private cloud platform.



4.1.13 SMTP

ort Settings	ТСР/ІР	HTTPS	SMTP Cloud	
			Sender Settings:	
			Sender Email Address:	ff_testipcamera@163.com
			SMTP Server.	smtp.163.com
			SMTP Port:	25
			Encryption:	Not encrypted V
			Server Authentication:	
			User Name:	ff_testipcamera
			Password:	•••••
			Recipients Address:	
			Recipient Email Address1:	
			Recipient Email Address2:	
			Recipient Email Address3:	

4.1.14 RTMP Configuration

- 1. Setup RTMP client related parameters, include IP Address / Port / Stream Name / Stream Path. Click Enable and then save configuration.
- 2. The current connection status of RTMP can be displayed on the current page.

FTP/SFTP	4G/5G	GBT Settings	Online Reporti	ng	RTMP	Route
Enable:		0				
Current Connect Status:	tion	Disconnect				
IP Address:		192 . 168 . 1	. 199			
Port: (1-65535)		8888				
Stream Path:		live				
Stream Name:		0				
Configuration Pr	rompt:	rtmp://IP Address:Port/S	tream Path/Stream	Name		

4.1.15 Device Upgrade

3. Remote Upgrade: Upload the new firmware through the cloud server API, click the upgrade button on the related web page. The cloud server will automatically send the firmware to the IPC to finish the upgrade. After the upgrade, it will return the result to the web server.

4. Local Upgrade: Select the new firmware from the local web portal, the web page will send the firmware to the IPC to finish the upgrade. After the upgrade, it will return the result to the page.



Version Information:		
tariftwarir Vanskan:	10.1.0.2.48	
Hardware Version	V1.0	
Bystam Operation.		
Rebot the Device	Particular .	
Device Parameter Reset. (Resp. Bei IP Configuration)	And a	
Factory Default	Percent	
Profile Operation		
Export Config Fale:	Super Darks	
Import Config File:	Telectro.	14mil
Update Operation:		
Farroware File:	Same Tree	
Reset after Upgrading		
Note: Please do not han off the power, it is	vill restart automatically after t	w upprade is

4.2 Video Stream RTSP Connection

IPC system provides RTSP protocol to streaming video through network. By typing the RTSP address and port, verify the username and password, user will be able to watch the real-time video streaming on web page, VLC or network video players.

If you want to use RTSP to connect, please try to fill in the target address in the following format,

rtsp://user:pass@192.168.1.100:554/main

(user:pass needs to be replaced with the username and password of the IPC system. Default admin:admin)

It also supports video streaming through cloud server or from APP. Contact your sales for cloud server license.