


User Guide

Smart Bracelet



ID115Plus Color HR
Thanks for choosing our device, please read
the user guide carefully before using.

Setting

Use VeryFitPro on iOS or Android smart phone to set
the wristband as follows:
**Note: hardware and system of devices should meet the
requirements:**



1. Download VeryFitPro

Search and download

Search and download "VeryFitPro" from the Apple Store or
Android App store .

Scan the QR code and download

It probably has a problem to open the link with WeChat or other
scan tools, please copy the link and open it through browser.



01

2. Product activation and installation

The product must be activated by charging before initial use, and then
charge the product to ensure normal power supply. The hand ring will
automatically power on.


Take out: Pull open the strap and take out the bracelet body




Charge the battery: Insert the chip-mounted end of the bracelet body
into the USB interface to activate the product by charging (be cautious
not to reverse the polarity, and comply with the required voltage and
current: 5V / 500mA)



Installation: Mount the bracelet body into the slot of the wrist strap.




Wear on: Adjust the length of the wrist strap until it is appropriate to
wear on the wrist.



02

3. Touch key

Single click the touch key:
Interface switch
Press and hold the touch key:
Enter



4. Make sure the Bluetooth of smart phone is ON,
open app"VeryFitPro"



When selecting the right band from the
search list, please slide the screen of
wristband to wake up the device and
then complete connecting.

Know your Device

1. Wearing Method

Wear the device on your wrist horizontally, about 2cm to carpal, the
same method as wearing watches.

2. Heart Rate Monitoring

To monitor Heart Rate more accurately, please wear the device on the
upper position of your wrist and a bit tighter than usual when you are
taking exercise.

3. Heart Rate Monitoring

Automatic heart rate Monitoring is ON as default, monitor Heart Rate
all the day automatically.


03

4. Working Time

Continuously working for 8 days under normal conditions

5. Interface


Click the touch key to display successively



Function Introduction


1.1 Time Mode

Instructions
Time dial can be switched as follows:
APP Devices Mode>More
[Click the touch key] to enter the next mode:
Data Mode
(you can customize the shortcut through the app)




1.2 Data Mode

[Click the touch key] to enter the next mode:
Heart Rate Mode
[Press and hold the touch key for 2s]
to enter the sub-mode of "Data Reading"




04

1.2.1 Data Reading Sub-Mode



[Click the touch key] to enter the next
sub-mode

Note: To go back to the Data Reading
Mode by clicking the touch key on the
final interface of Data Reading Sub-Mode




Before Data
Is Displayed

After Data
Is Displayed

Change in 0.5s

Note: Upon staying at the Heart Rate interface for 1s, start to monitor the
heart rate, and a fig. like "168" is displayed before the correct data is
monitored, and upon the correct data being monitored, data is displayed.
[Click the touch key] to enter the next mode: Alarm Clock Mode








Note: Alarm clock function should be turned
on in App for the alarm clock to be displayed.



05

1.5 Sports Mode

[Press and hold the touch key for 2s] to enter the
Sports Mode
[Click the touch key] to enter the next sports mode; and in
case there are no other sports modes, it will go back to the
time mode.
Note: Types of Sports mode can be selected in App (App
can handle 4 types of track recording sports and 10 types
of other activities)







Note: The speed and distance of riding can be displayed, but App need
to be connected and the riding and App needs to start at the same time.



06

1.5.1 Sports Start Mode

[Click the touch key] to enter the next sub-mode of
"Sports Underway"[Press and hold the touch key for 2s]
to start/close alarm clock









Note: The reminder will occur when a user tried to start
the sports mode with the battery of device is in low.



07

1.5.2 Sports Underway Mode

[Click the touch key] to enter the next sub-mode of
"Sports Underway"[Press and hold the touch key for 2s]
to start/close alarm clock








Note: The reminder will occur when a user tried to start
the sports mode with the battery of device is in low.



08

1.5.3 Sports Stop Mode

[Click the touch key] to enter the next sub-mode of
"Sports Underway"[Press and hold the touch key for 2s]
to start/close alarm clock








Note: The reminder will occur when a user tried to start
the sports mode with the battery of device is in low.



09

1.5.4 Event Reminder in Sports Mode

[Click the touch key] to enter the next sports data display mode, and the
single click of the final interface will go back to the first interface of sports
mode.








Note: The reminder will occur when a user tried to start
the sports mode with the battery of device is in low.



10

1.5.5 Abnormal operations during activity

[Click the touch key] to enter the next sports data display mode, and the
single click of the final interface will go back to the first interface of sports
mode.









Note: The reminder will occur when a user tried to start
the sports mode with the battery of device is in low.



11

1.5.6 Abnormal operations during activity

[Click the touch key] to enter the next sports data display mode, and the
single click of the final interface will go back to the first interface of sports
mode.








Note: The reminder will occur when a user tried to start
the sports mode with the battery of device is in low.



12

1.5.7 Abnormal operations during activity

[Click the touch key] to enter the next sports data display mode, and the
single click of the final interface will go back to the first interface of sports
mode.








Note: The reminder will occur when a user tried to start
the sports mode with the battery of device is in low.



13

1.5.8 Abnormal operations during activity

[Click the touch key] to enter the next sports data display mode, and the
single click of the final interface will go back to the first interface of sports
mode.



Note: The reminder will occur when a user tried to start
the sports mode with the battery of device is in low.



14

1.5.9 Abnormal operations during activity

[Click the touch key] to enter the next sports data display mode, and the
single click of the final interface will go back to the first interface of sports
mode.








Note: The reminder will occur when a user tried to start
the sports mode with the battery of device is in low.



15

1.5.10 Abnormal operations during activity

[Click the touch key] to enter the next sports data display mode, and the
single click of the final interface will go back to the first interface of sports
mode.







Note: The reminder will occur when a user tried to start
the sports mode with the battery of device is in low.



16

1.5.11 Abnormal operations during activity

[Click the touch key] to enter the next sports data display mode, and the
single click of the final interface will go back to the first interface of sports
mode.









Note: The reminder will occur when a user tried to start
the sports mode with the battery of device is in low.



17

1.5.12 Abnormal operations during activity

[Click the touch key] to enter the next sports data display mode, and the
single click of the final interface will go back to the first interface of sports
mode.









Note: The reminder will occur when a user tried to start
the sports mode with the battery of device is in low.



18

1.5.13 Abnormal operations during activity

[Click the touch key] to enter the next sports data display mode, and the
single click of the final interface will go back to the first interface of sports
mode.



Note: The reminder will occur when a user tried to start
the sports mode with the battery of device is in low.



19

1.5.14 Abnormal operations during activity

[Click the touch key] to enter the next sports data display mode, and the
single click of the final interface will go back to the first interface of sports
mode.



Note: The reminder will occur when a user tried to start
the sports mode with the battery of device is in low.



20

1.5.15 Abnormal operations during activity

[Click the touch key] to enter the next sports data display mode, and the
single click of the final interface will go back to the first interface of sports
mode.



Note: The reminder will occur when a user tried to start
the sports mode with the battery of device is in low.

