

Trade Name : T60N871

802.11b/g Wireless LAN MiniPCI module

User Manual



1. Wireless LAN Configuration Utility

Introduction

The Wireless LAN Configuration Utility is a powerful application that helps you to configure FOXCONN WLAN card and monitor the statistics of the communication status. Unlike the standard method of configuring the card via the operating system utilities, this application permits the dynamic modification of the configuration parameters while the card is operating. It also offers more configuration options.

FOXCONN offers the Wireless LAN Configuration Utility for Windows 95/98/Me/2000/XP.



1.1 How to install the driver and Wireless LAN Configuration Utility

Double click the "setup" located in "\WLAN_Utility\"



The program will automatically proceed with installing. Press "Next" to continue.



Fig 1-2

Foxconn[®] Network System Group

Press "I accept the terms in the license agreement" to continue the install shield. Or press "I do not accept the terms in the license agreement" quit install process. Then, press "Next" to continue.

| 🤯 IPN2220 Wlan Driver and Utility - InstallShield | Wizard 🔀 |
|--|---|
| License Agreement Please read the following license agreement carefully. | |
| INPROCOMIM Installation System License A | greement |
| IMPORTANT - READ CAREFULLY: This Single Developer Unlimited Installation Sy ("Agreement") is a legal agreement between you single entity) and Inprocomm, Inc., a Taiwan No.93, Shuei-Yuan St., Hsinchu, 300 Taiwan, for INPROCOMM's BETA computer softwar (collectively, the "Licensed Software"). By con- | vstem License Agreement ou (either an individual or a corporation located at 9F, , R.O.C. ("INPROCOMM") re and associated media ntinuing to use the Licensed |
| I accept the terms in the license agreement I do not accept the terms in the license agreement | |
| InstallShield < Back | Next > Cancel |



Press "Install" to continue installing





Install Shield is processing

| 🔂 IPN2220 | Wlan Driver and Utility - InstallShield Wizard 📃 🗖 🔀 |
|--|---|
| Installing The prog | IPN2220 Wlan Driver and Utility gram features you selected are being installed. |
| i de la companya de l | Please wait while the InstallShield Wizard installs IPN2220 Wlan Driver and Utility. This may take several minutes. Status: |
| InstallShield – | < Back Next > Cancel |

Fig 1-5

Choose "Finish" to complete the installation





The usage of Wireless LAN Configuration Utility

2.1 Introduction

The Wireless LAN Configuration Utility appears as an icon on the system tray of Windows while the card is running. You can open it by double clinking the icon (*Fig* 2-1) to show full screen of WLAN Utility.



Fig 2-1 icon on the system tray

While the station is in infrastructure mode and **not** associated to an Access Point, the color of the icon is "White (blank)"(*Fig* 2-2).



Fig 2-2 No Connection

As soon as the station associates to an Access Point, the icon color automatically turns to "Green", "Yellow" or "Red". Which indicates the receiving signal strength from Access Point. "Green" (*Fig* 2-3) indicates the signal is "Good". "Yellow" (*Fig* 2-4) indicates the signal is "Fair". "Red" (*Fig* 2-5) indicates the signal is "Poor".



Fig 2-4 Fair Connection



Fig 2-5 Poor Connection

The Wireless LAN Configuration Utility is a powerful and highly integrated application include the following options (tabs),

- Status
- Site Survey
- Statistics
- About

FOXCONN® Network System Group

2.2.1 Status

A typical screen of the application in Infrastructure mode is shown in *Fig* 2-6. The Wireless LAN Configuration Utility contains the following information for Wireless LAN.

- Profile: The profile name which user selected. If there is no profile selected, it would show "default".
- **SSID:** The Network Service Set Identification provided by Access Point.
- Link Status: The MAC address of Access Point.
- Network Type: Infrastructure or Ad-Hoc.
- **Channel:** Operation channel provided by Access Point.
- **Tx (Transmit ion) Rate:** Current transmit ion rate.
- Signal Strength: The Signal level of Wireless Network.
- Link Quality: The Signal Quality of Wireless Network.
- Network Address: shows the current Network status such as MAC address (Wireless Card), DHCP (Enable or not), IP address, Subnet Mask address, Gateway Address and DNS server address.

| INPROCOMM IPN2220 Wire | eless LAN Card #4 | | | | | |
|--|--|--|--|--|--|--|
| Status Site Survey Statistics About | | | | | | |
| Profile: 11g_router SSID: 11g_route | r ?r | | | | | |
| Link Status: Connected | 1: 00-06-25-D9-ED-47 ture | | | | | |
| Channel: 1 Tx Rate: 54 Mbps | | | | | | |
| Signal Strength | Network Address DHCP Enabled | | | | | |
| Link Quality 99 % | MAC 00-08-22-00-03-D3 IP 192.168.1.100 Gateway 192.168.1.175 Subnet 255.255.255.0 Mask DNS 192.168.1.175 | | | | | |
| INPROCOMM | OK | | | | | |

Fig 2-6 Typical screen of the Wireless LAN Configuration Utility in Infrastructure mode.

Users can change the configuration by clicking the "Configuration" Button.



2.2.2 Configuration

Users can edit Wireless Network setting by pressing "**Configuration**" button. There are 3 tabs in "Configuration".

- General
- Encryption
- Advance



2.2.2.1 General Page

General Page include the following options, (See Fig 2-7)

- Profile Name: Name of Selected Profile. (Default profile name: default). If users want to change settings of profile, please refer to Edit Profile option in "Site Survey" page.
- Network Type: User can choose either Infrastructure or Ad-Hoc mode.
- SSID: Define the SSID.
- Channel: Provided by Access Point in Infrastructure mode. User can only define when choose Ad-Hoc mode in Network Type option.
- Desired Rate: User can choose the desired rate from 1Mbps~11Mbps (associated with 802.11b Access Point) and 1Mbps~54Mbps (associated with 802.11g Access Point). (Default Setting: Automatic).

| ¢ | Configuration | |
|---|--|-------|
| | General Encryption Advanced | |
| | Profile Name: 11g_router Network Type: Infrastructure SSUD: 11g_router | |
| | Channel: 1 | |
| | Desired Rate: Automatic | |
| | | |
| | | |
| | Apply Ca | ancel |

Fig 2-7



2.2.2.2 Encryption Page

IPN2220 WLAN Utility provides powerful and intelligent setting of WEP Key. The Encryption page include the following options, (see *Fig* 2-8)

- Encryption Mode: User can choose WEP On or None WEP for the Network. This option will be automatically defined after "Site Survey".
- Authentication: There are 2 modes of Authentication of 802.11b/g Wireless Network. Open System and Share Key. These are defined by Access Point. IPN2220 WLAN Utility provides the "Auto Switch" option for easy to use. This option can be also automatically defined after "Site Survey".
- WEP Key Entry (hex): Users have 4 sets of WEP to use. Each will need to be defined by user according to Access Point. The Key value is in Hex format (from 0~9, a~f).
- Encryption Key Length: User can choose 64bits, 128bits or 152bits encryption for the network according Access Point.

| c | Configuration | × | | | | | |
|---|---|---|--|--|--|--|--|
| | General Encryption Advanced | | | | | | |
| | Encryption Mode: WEP | | | | | | |
| | Authentication Open system 💌 | | | | | | |
| | WEP Key Entry (hex) | | | | | | |
| | Default Key: | | | | | | |
| | • Key 1: 1234567890 | | | | | | |
| | ○ Key 2: | | | | | | |
| | C Key 3: | | | | | | |
| | C Key 4: | | | | | | |
| | Encryption Key Length © 64-bits © 128-bits © 152-bit | | | | | | |
| | Apply Cancel | | | | | | |
| | | | | | | | |

Fig 2-8



2.2.2.3 Advance Page

Advance Page provides more advanced options for Wireless Network. This include the followings, (See *Fig* 2-9)

- **Power Saving:** Enable or Disable the Power Saving Mode. (Default: Disable)
- Preamble Type: User can choose Long Preamble or Short Preamble type according to Access Point. IPN2220 provides "Auto" setting for choosing "Preamble Type".
- Fragment Threshold:
- RTS Threshold:
- Receive Antenna:

| Configuration | | X |
|---------------------------|------------|----|
| General Encryption Advanc | ed | |
| | | |
| Power Saving: | Disable | |
| Preamble Type: | Auto | |
| Fragment Threshold: | 2346 | |
| RTS Threshold: | 2347 | |
| Receive Antenna: | Primary 💌 | |
| | | |
| | | |
| | | |
| | | |
| | Apply Canc | el |
| | ApplyCanc | el |

Fig 2-9



2.2.3 Site Survey

IPN2220 WLAN Utility provides the easy to link "Site Survey" option. This will allow users to connect to Access Point intelligently. By choosing the *Site Survey* option, you can scan all the channels to find all the Access Points within the range of card. The list includes information about the BSSID and SSID of the access point(s), the Mode (Network Type), whether or not WEP encryption is used, Channel, Signal Strength and Support Rate. In order to update this list, press the **"Rescan"** button.

The "Site Survey" page include, (See Fig 2-10)

- Available Networks: Users can press "Rescan" button to Scan/Rescan the environment for all existing Access Points. User can move the cursor on the desired Access Point to join.
- Profiles: Users can click the "New", "Delete" and "Edit" button to configure the selected profile and/or create new profile.

| INPROC | OMM Wirele | ss LAN Con | figurati | ion Uti | lity | | × |
|------------|----------------------------------|-----------------------|----------|------------|---|----------|--------------|
| INPR | OCOMM IPN2: | 220 Wireless L | AN Card | l #4 | | 7 | |
| Status | Site Survey | Statistics A | bout | | | | _ |
| Avail | able Networks | | | | | | |
| BS | ID | SSID | Mode | WEP | CH Sig | | |
| 00-0 | 16-25-d9-ed-47 10-4b-08-0f-a3 | 11g_router wpghome | AP AP | Off Off | $ \begin{array}{c} 1 \\ 6 \\ 20 \end{array} $ | Rescan | N |
| | | | | | | | \mathbf{A} |
| | | | | | | 4 | |
| | | | | | | | |
| < | | | | | > | | |
| Profi | es | | | | | | |
| 11g WPg | router home | | | | | New | |
| | | | | | | | |
| | | | | | | Delete | |
| | | | | | | Edit | |
| | | | | | | ' | |
| | | | | | | <u> </u> | |
| INPR | осомм | | | | L | ОК | |
| | | Fic | 2-10 | | | | |

If you want to associate with any of the access point(s) listed after pressing "**Rescan**", Double-clicking on your choice and the system will take you back to the **Configuration** page showing you the parameters of the connection newly established. Then user can give a Profile Name for the connection. System will save all changes and options automatically.

After connecting to Access Point, system will create a Profile in the "**Profiles**" screen. Users can create a "**New**" profile, "**Delete**" profile and/or "**Edit**" profile by pressing the button on the right of screen. When users press the "New" and "Edit" button, system will also pop up the **Configuration** page to enter the desired settings.



2.2.4 Statistics

This page includes the Statistics for the Wireless Network. (See *Fig* 2-11)

| INPROCO | MM Wireless LAN Configu | ration Utility 👘 | × |
|---------|------------------------------|------------------|----------|
| INPRO | COMM IPN2220 Wireless LAN (| Card #4 | * |
| Status | Site Survey Statistics About | | |
| | Tx Statistics | | |
| | Tx Success: | 0 | |
| | Tx Error: | 0 | |
| | Tx Throughput (Kbps): | 0.00 | |
| | Rx Statistics | | |
| | Rx Success: | 0 | |
| | Rx CRC Success: | 6 | |
| | Rx CRC Error: | 1 | |
| | Rx Throughput (Kbps): | 0.00 | |
| | L | Reset |] |
| INPRO | сомм | | ок |

Fig 2-11



2.2.5 About

This page shows the software information for IPN2220. The Version of Driver and Utility are subject to change by FOXCONN. (See *Fig* 2-12)

| INPROCOMM Wireless LAN Configuration Utility | × |
|--|------|
| INPROCOMM IPN2220 Wireless LAN Card #4 | |
| Status Site Survey Statistics About | |
| | 1 |
| | |
| Version | |
| Driver: 1.22.01.2004 | |
| Utility: 2.38.01.2004 | |
| | |
| Link | |
| INPROCOMM Homepage | |
| INPROCOMM E-mail | |
| | |
| (C) 2002-2004. Inprocomm, Inc. | |
| | |
| | |
| INPROCOMM | ок (|
| | |

Fig 2-12



2.3 Quick Launch

IPN2220 WLAN Utility also gives users the quick way to set up Wireless Network and recall the profiles. (See *Fig* 2-13 and *Fig* 2-14)

By "Right- Clicking" the icon in system tray then choose "Connect" for proper profile list or turn-on/off the "Radio" while in same restricted area. Also can click on the "Open" to open the full screen of Utility and "Minimize" to hide the Utility. Or press the "Exit" to quit the Utility from system tray.



FCC Warning Notice

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does caus harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: To assure continued compliance, (example - use only shielded interface cables when connecting to computer or peripheral devices) any changes or modifications not expressl approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.