
# Ozone Wireless Charging Pad with Dual Outputs

Instruction Manual AB0028



- 1. Charging Pad Surface 2. USB Output Port (2)
- 3 LED Indicator
- 4. Micro-USB Input Port

#### What's included:

- 1 x Wireless Charging Pad
- 1 x USB to Micro-USB Charging Cable
- 1 x Instruction Manual

### **Tech Specifications**

- Input power: DC 5V/2000 mA · Output power: 5W
- Product size: 98x 98 mm
- Dual USB Outputs: DC 5V 1A/1A
- 30 cm standard Micro-LISB cable

#### INSTRUCTIONS:

- 1. Use A Certified USB Plug Adapter:
- a. Connect the provided Micro-USB cable to
- b. Connect the Micro-USB tip to the input port on the charging pad.
- 2. Charging Mobile Devices:

the USB plug adapter.

- a. Ensure that your phone or tablet supports wireless charging. It will be listed in the manufacturer's specifications.
- b. Place the enabled device on the surface. of the wireless charging pad. The device should display charging indicator.
- c. When completely charged, remove the device from the charging pad.
- d. Or Insert corresponding charging cable into the Charging Pad USB port to charge your devices normally.
- Note: To charge devices, use only the accessory cable or the cable included with your own device by the manufacturer.

### SAFETY PRECAUTIONS:

Read all the instructions before using the product.

- WARNING-When using this product, basic precautions should always be followed:
- 1. Read all the instructions before use.
- 2. Never store or use this product in temperatures below 32°F (0°C) or above 115°F (45°C).

- 3. Do not overcharge your phone. The unit may become hot under excessive use. Remove your phone once it is fully charged. Never charge your phone for more than 7 hours at a time.
- 4. To reduce the risk of injury, close supervision is required when the product is used near children
- Do not expose the device to moisture.
- 6 Do not use the device in excess of its.
- output rating. Overload outputs above the rating may result in a risk of fire or injury. Do not use the device if damaged or
- modified 8. Damaged or modified batteries may exhibit
- unpredictable behaviour resulting in fire. explosion or risk of injury. 9. Do not disassemble the device. For repairs.
- seek a qualified service professional. Incorrect reassembly may result in a risk of fire or injury. 10. Do not expose the device to fire or
- excessive temperatures. Exposure to fire or temperatures above 104°F (40°C) may result in explosion.
- 11. To ensure product safety, ensure that qualified service professionals use only identical replacement parts.
- 12. Attachments on the back of your phone can impede the effectiveness of the wireless charger, and lead to overheating. Please remove attachments from the phone before charging on this device.

## FOC Statement:

- · This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- \* Warning:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Warning Statement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- - Consult the dealer or an experienced radio/TV technician for help.

