

[illegible]

Safety Precautions	Warranty Statement	Five Year Warranty
<p>When using your Product, basic safety precautions should always be followed including:</p> <ol style="list-style-type: none"> 1. READ ALL INSTRUCTIONS BEFORE USING YOUR PRODUCT. 2. Do not submerge product in water. Do not place product in water. 3. Only allow water to come in, with soft. 4. Do not allow children to play with this product. This product contains small parts that can be a choking hazard. Parental supervision is advised. 5. Do not use near open flame or heat. 6. Do not immerse product in liquids or hot temperatures to avoid battery damage. 7. Do not attempt to repair this product yourself. Contact a qualified service center if the problem is not of warranty. 8. Do not use, repair, or attempt the product to replace physical fluid. 9. Do not charge while product is connected with water, as electric shock may occur. 10. Unplug charging cable when not in use or during thunderstorms. 	<p>Warranty Statement</p> <p>Changes or modifications not expressly approved by the party responsible for compliance with this warranty will void the warranty.</p> <p>This device complies with Part 33 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful radio frequency, and (2) it must not accept any interference received, including interference that may cause undesired operation.</p> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to a residential installation. This equipment generates, uses, and can radiate radio frequency energy, which if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that the device will not cause a particular interference.</p> <p>If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> -Reorient or relocate the receiving antenna. -Increase the space between the equipment and receiver. -Connect the equipment into a circuit different from that for which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. 	<p>This warranty covers the original consumer purchaser only and not resellers.</p> <p>This warranty covers products that fall to function properly, UNDER NORMAL USE, due to defects in material or workmanship. Your product will not be required to be replaced at the expense of the party for cause for a period of one year.</p> <p>What Is Not Covered by Warranty</p> <p>Damage or wear caused by: use, misuse, neglect, accident, fire, liquid or water damage or other causes or malfunctions from other than normal use, including but not limited to, repair by unauthorized parties, tampering, modifications or accident.</p> <p>To Obtain A Free Repair or Replacement of Your Product:</p> <p>Call 1-800-991-9624 or visit our website at www.sony.com</p> <p>To receive warranty service along with the name and address of an authorized product service center, the original consumer purchaser must return us for product replacement, either similar or same type product. Proof of purchase in the form of a bill of sale or receipt is required, indicating that the product is within the applicable (five year) period(s). Other proof of purchase is required for the replacement service to be your responsibility for any damage and/or any defective products along with a dated copy of a receipt, a written explanation of the problem, and a valid return address for the authorized service center at all times. Does not include any other type of accessories or the defective product. Any product repaired by the authorized service center that we not covered by warranty will not be returned authorized.</p> <p>For Consumers in Australia Only</p> <p>Every product shall have a minimum period of parts of years, requiring proof of purchase for a full product warranty.</p> <p>Goods generally warranted that remain available under the basic local Consumer Sale. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage.</p> <p>You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the repair does not amount to a major failure.</p> <p>For All Technical Support in Australia please call 1-800-991-9624</p>