

OTIC Smart Card



Works with

Apple Find My



MODEL: BS-3514AA

USER MANUAL

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.


The device has been evaluated to meet general RF exposure requirement.

OVERVIEW

IN THE BOX

- 1 × OTIC Smart Card (IP67 waterproof & dustproof)
- 1 × User Manual

FRONT



REAR



CHARGING THE CARD

Before using this card for the first time, make sure to fully charge the smart card by using a wireless charger (not included). While charging, the indicator will light orange and green. When it is fully charged, the indicator will only light green, then you should remove the card from the wireless charger.

The battery can be used for up to 10 months, but recommended to recharge the card within every 3 months depending on the condition of use.

Note: Please overlap the wireless charging area of smart card with the center of the wireless charger to charge it.



※ (This image is for reference only.)

OPERATION

Before you put this card in your wallet or attach to other important items with keyring (not included), let's get it connected to the Apple Find My app. And what you need to do on your phone are as follow:

- Find My app turned on.
- Bluetooth turned on.
- A strong WiFi or mobile connection.
- Location Services turned on:

Go to Settings > Privacy > Location Services.

To see the most accurate location for your smart card, turn on Location Access for Find My app.

Power On/Off

1. Press the Power button to power on the card.
A series of short audible beeps will sound with a flash of blue light.
2. Press and hold the Power button for about 5 seconds to power off.
An audible beep will sound with a flash of blue light.

Note: If there is no response when pressing the Power button, press the Power button twice in succession, it will flash blue light with a beep, it means the smart card is powered on.

Apple Find My App

1. On your Apple iPhone, iPad, iPod touch, Apple Watch or iMac update to the latest version of iOS.
2. Allow notifications from the App.

Smart Card Setup

1. Press the Power button to power on your smart card.
 2. Within the Find My App, select the 'Items' tab and tap 'Add Item', followed by 'Other supported item'.
 3. Once the name "Smart Card" has been found, tap 'connect'.
 4. Choose and enter a recognizable name and emoji for your card, these will appear on the Map on your Apple device.
 5. You will be asked to confirm that the card links to your Apple ID with supporting information about itself. And then tap 'Agree'.
 6. A map will appear displaying the chosen emoji for your smart card. Tap 'Finish'.
 7. Your smart card is now set up and ready to be attached to whatever item you wish to locate, e.g. your house or purse.
- ⌘ (You can operate as the following figures which is for reference only.)

Note: If there is no connection to any Apple device, the card will switch off automatically after 3 minutes.





Find Your Card When It Is Nearby

1. Open the Find My app on your Apple device and select the 'Items' tab.
2. Tap on your named smart card from the list shown and tap 'Play Sound'.
3. Your smart card will beep.
4. Tap on 'Stop Sound' to stop the beeps.

Find Your Card's Last Known Location

1. Open the Find My app on your Apple device and select the 'Items' tab.
2. Tap on your named card from the list shown.
3. Your card's last known location will be shown on the map in a emoji way.
4. To navigate to your card's last known location, tap 'Directions' to open the Maps app and tap 'Go'.
5. Tap 'End Route' when you have located your card.

Notify When Left Behind

1. Open the Find My app on your Apple device and select the 'Items' tab.
2. Tap on your named card from the list shown.
3. Pull up the App options and enable 'Notify When Left Behind' and tap 'Done'.
4. You will receive a notification on your Apple device when you leave your card behind and it's no longer in range.

Notify When Your Card Has Been Found In Lost Mode

1. Open the Find My app on your Apple device and select the 'Item' tab.
2. Tap on your named card from the list shown.
3. Pull up the App options and tap on 'Enable' under 'Lost Mode'.
4. Information about Lost Mode will be displayed, tap on 'Continue'.
5. Enter a contact phone number or email address and tap 'Next'.
6. You can now enter a message that will be shared with the person who finds your card.
7. Tap 'Activate' to enable Lost Mode and Notify When Found.

Note: When 'Lost and Find' is enabled, your card is locked and cannot be paired to a new Apple device.

Remove the card from Find My app

1. Open the Find My app on your Apple device and select the 'Items' tab.
 2. Tap on your named card from the list shown.
 3. Pull up the App options and tap on 'Remove Item'.
 4. A 'Remove Item?' check screen will appear, and then tap on 'Remove'.
 5. Your card will be disconnected from your Apple ID with an audible beep sound and a flash of blue light.
- ⊗ (You can operate as the following figures which is for reference only.)



How to Perform a Factory Reset

If you would like to unpair your card from your Find My account so that it can be paired to a different Find My account, follow the steps below.

1. Remove the card from Find My app as instructed on previous page.
2. On your card, press the Power button 5 times in quick succession and hold the button on the 5th pressing.
3. The card will sound an audible beep with a flash of blue light and perform the factory reset.

How to Find the Serial Number

To find your device's serial number, follow the steps below.

1. On the device:
 - 1) The series number is printed on the backside of the card.
2. Or Via the Find My App:
 - 1) Open the Find My app, tap the 'Items' tab, and tap you named card from the list shown.
 - 2) Scroll to the bottom of the Item Detail Card. The serial number is displayed below *Manufacturer*.

TROUBLESHOOTING

Battery Status

Check the battery status of the card within the Find My app

1. Open the Find My app on your Apple device and select the 'Items' tab.
2. Tap on your named card from the list shown.
3. Underneath the name you have given to your card, a battery icon will display the current battery status.
4. When your named card is in low battery, it will send notification to your Apple device.

The Find My App Cannot See the Card to Connect

- The card may be powered off. Press the Power button to power it on.
- The Find My app need to be updated. Please update to the latest version.
- The card may be out of range. Keep the card with you when you are trying to connect it to your Apple device and ID.
- The card may be in a low power status. charge it immediately.

Play a Sound Does not Work Within the Find My App

The card is out of Bluetooth range, which is 40 metres/131.2 feet. Move closer to the card using Directions within the Find My app, and then tap Play Sound again.

DECLARATION

The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac, or the Find Items app on Apple Watch.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.