



# ACTIVE

## TRUE WIRELESS SPORT EARPHONES



28 HOURS TOTAL  
PLAYTIME



SPORT  
FIT



POCKET-SIZED  
CASE



IPX5 WATERPROOF  
EARPHONES

# SAFETY PRECAUTIONS

When using your earphones, basic safety precautions should always be followed, including:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR EARPHONES.
2. Never expose your earphones to high temperatures, extreme cold, or high humidity. Do not submerge in water.
3. To avoid the risk of electric shock, never attempt to open or repair your earphones without the assistance of certified professionals.
4. Your earphones are not to be used by children or the infirm without suitable adult supervision.
5. Always press all buttons carefully. Do not manhandle your earphones.
6. Do not use your earphones at temperatures under 32°F (0°C) or over 104°F (40°C).
7. Do not drop your earphones, throw them, or subject them to strong impacts or physical trauma.
8. Contact the manufacturer for support if you detect any abnormalities when using your earphones. In addition, do not continue to use your earphones if you detect any smoke or fire.
9. Unplug your earphones when not in use for extended periods of time.
10. When plugged in, do not place your earphones on flammable materials such as rugs, carpets, or bedding.
11. Please recycle or dispose of your earphones properly according to your municipality's laws and rules. Contact local recycling facilities and/or the manufacturer for further information.
12. Clean your earphones and charging case using a soft cloth or paper towel. Do not use harsh chemicals when cleaning your earphones, and never submerge your earphones in water.



## CAUTION

### BATTERY WARNING:

- The device is equipped with an integrated lithium ion battery. The battery cannot be replaced. Do not attempt to remove the battery from the device.
- Do not dispose of in fire or expose to excessive heat.
- Do not crush, puncture, incinerate, or short circuit external contacts.
- Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.

# INTRODUCTION

Thank you for purchasing the Reebok Active True Wireless Sport Earphones, item RBK1000. Pump up your sports routine with high quality sound. To get the most out of your device, please read this user's manual thoroughly before use.

## PACKAGE CONTENTS

- True Wireless Sport Earphones with Charging Case
- USB-C Charging Cable
- User's Manual with Warranty Information

## FEATURES


- 28 Hour Total Playtime
- Seven Hours Playtime per Charge\*
- Three Extra Charges in Case
- Sport Fit
- Touch Controls

\*Applicable at 50% of maximum volume. Results will lower with increased volume.

## SPECIFICATIONS

- Bluetooth Range: Up to 33 Feet (10 Meters)
- Charging Input: DC5V


# A CLOSER LOOK




# CHARGING

## Charging The Case


Insert one end of the included USB-C charging cable into the charging port on your case.



Insert the other end of the USB cable into a suitable USB charging adapter.



When charging, an indicator light on the case will flash.



## Charging The Earphones

Place the earphones in the charging case. Make sure the charging points make contact between the case and earphones. If there are any stickers on the earphones' charging contacts, remove them.


While charging, the Indicator lights will flash. The lights will stop flashing when the earphones are charged.

Charging can take approximately 2-3 hours.

# POWERING ON/OFF


When first using your earphones, remove any stickers on the charging contacts. Then, place the earphones into the case. To turn the earphones ON, remove them from the case. To turn the earphones OFF, set them back into the case.

**Note:** It is recommended that the earphones be fully charged before use.




# BLUETOOTH PAIRING

When you remove your earphones from the case, they will power ON and go into pairing mode. Both earphones will automatically sync together when removed from the case.



- Pairing (FLASHING RED AND BLUE)
- Connected (ONE OFF, THE OTHER ONE FLASH RED AND BLUE)


The indicator lights on the earphones will flashing red and blue while in pairing mode.



Go to the Bluetooth settings menu on your phone. Make sure Bluetooth is ON. Connect to the device listed as "RBK1000 Sport TWS".

After connecting the earphones, their indicator lights will turn OFF.

# USING YOUR EARPHONES



## LEFT EARPHONE

Pause/Play: Press

Decrease Volume: Press three times

Previous Selection: Press twice

Answer Call: Press

Decline Call: Press and hold

Hang Up Call: Press

Voice Assistant: Press and hold until there is a single audible beep

## RIGHT EARPHONE

Pause/Play: Press

Increase Volume: Press three times


Next Selection: Press twice

Answer Call: Press

Decline Call: Press and hold

Hang Up Call: Press

Voice Assistant: Press and hold until there is a single audible beep



Warning

To prevent possible hearing damage, do not listen at high volume levels for long periods. For your own safety, please be aware of your surroundings when using these earphones.



# RESET

If the earphones have any technical problems without visible physical damage, please first attempt a soft reset. A soft reset does not remove previous pairing information.

## Soft Reset

Place the earphones into the case. Let the earphones sit for approximately five seconds before taking out.

If a soft reset does not work, attempt a hard reset. A hard reset will remove all pairing information.

## Hard Reset

Remove the earphones from the case. Make sure the earphones are not connected to any device through Bluetooth. Press either earphone's touch sensor five times to reset.

# MAINTENANCE AND CARE

-Use a soft cloth or paper towel to clean your earphones and charging case. Never use any harsh chemicals or detergents for cleaning. Make sure your earphones are dry before charging.

-When your earphones are unused, they should be stored in a cool, dry place.

-Never tug or yank on a cable connected to your earphones or charging case. Connect and disconnect cables as carefully as possible.

-Never expose your earphones to high temperatures or extreme cold.

# FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID:2AOKX-TD509B

## Warning

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

# CSI ONE YEAR WARRANTY

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

## **What Is Not Covered By Warranty**

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

## **To Obtain Warranty Service and Troubleshooting Information:**

Call 1-800-592-9541 for 24/7 support.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address of the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepared.

# Reebok



2024 CSI  
Edison NJ 08817

© Reebok International Limited, All rights reserved. Reebok® and ® are registered trademarks of Reebok International Limited.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sakar International, is under license. Other trademarks and trade names are those of their respective owners.