


Usage


6. Camera privacy protection

Use the camera cover for privacy protection when the product is not in use. Remove the cover and store it on the magnet on the rotating stand when using the product.

①.Remove the camera cover.




②.Attach the cover to the magnet on the rotating stand.



7. Adjust camera vertical angle of view


There are **5 gears** for vertical angle of view adjustment. Move the elevation lever up and down and watch the view via the app until you find the appropriate position.




Cleaning and Maintenance

1. Clean the case

- ①.Wipe off the dust on the product surface with clean, soft cloth.
- ②.All components except for the bowl are not water-proof, and so please do not rinse or wet the product.
- ③.Please do not press the mechanical transmission parts forcefully on the holder lid.
- ④. Align the treat-tossing outlet on the lid with the product on the product body and close the lid.



2. Clean the treat bowl



- ①.Discard any leftover treats and crumbs from the bowl after removing it from the product.
- ②.You could wash the bowl either with a dish-washer or by hands.
- ③.When washing the bowl by hand, use mild detergent and rinse it with clean water.
- ④. Wipe or dry the bowl after cleaning. Ensure that the bowl is completely dry before reinstalling it.

Troubleshooting

? The video stalls or delays

- ✓ Check the strength of WiFi signal in accordance with the instructions in the "Indicators" chapter of this manual.
- ✓ Check if the router is placed too far from the product or if there is any wall in between. Place the product within 20 ft from the router and remove any barrier in between.
- ✓ Check the network situation. It can slow WiFi connection when multiple products use the same network.

? The product fails to connect to the app or the WiFi network

- ✓ Check the strength of WiFi signal in accordance with the instructions in the "Indicators" chapter of this manual.
- ✓ Check if the router is placed too far from the product or if there is any wall in between. Place the product within 20 ft from the router and remove any barrier in between.
- ✓ Check if the product has been connected to another user's app. If so, please contact the user and ask him/her to unbind the product.

? The app shows that the product is offline

- ✓ Check if all router networks function normally. After router connection is fixed, wait for the product to reconnect automatically.
- ✓ Check if the product power supply has been cut off. If so, repower the product and try again.

? The product has not connected to power supply after it connects to the adapter

- ✓ Please use the original adapter and cable provided in the box.
- ✓ Make sure that the cable has been properly inserted into the power port. You will hear a click when the rotating stand cable is fully inserted into the interface on the main body of the product.
- ✓ If using a power strip, check if the power strip is connected to power, or try another power strip.

Further Queries

You could find the answers to your questions by going to "My Center – Help and Feedback" in the app, or contact customer support team.

Contact Us

Phone



Email



Guarantee Terms and Conditions

LIMITED 12-MONTH WARRANTY

Your xxxxxxxx product will be covered for parts and labor for 12 months from the date of purchase, subject to the terms of the warranty. This warranty does not cover damage resulting from accident, misuse or abuse, lack of reasonable care, the affixing of any attachment not provided with the product or loss of parts or subjecting the product to any but the specified voltage or batteries. NO RESPONSIBILITY IS ASSUMED FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES.

To read the warranty, please visit <https://www.xxxxxxx.net>. To obtain warranty service, simply contact xxxxxxxx Customer Support for assistance.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement, This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.
- Operations in the 5.15-5.35GHz band are restricted to indoors usage only

Product Specifications

Product Name	Pet Game Console		
Model	P301201		
Input	5V/2A		
Dimensions	7" x 5.4" x 6.6"		
Weight	1.8 lbs		
Capacity	10 oz		
Material	Case	Bowl	Treat-tossing lever
	ABS	PP	PC+ABS
USB Cable Length	5 ft		
Operating Ambient Temperature	32 °F to 113 °F		