

APPLICANT: MOTOROLA, INC.

FCC ID: IHDT56FQ1

INSTRUCTION MANUAL

A preliminary draft copy of the Users Manual follows:




MOTOMANUAL


motorola **Q**[™]
CDMA



HELLOMOTO

Introducing your new Motorola Q CDMA wireless phone! You can **check and write e-mail**, use the **QWERTY Keyboard** for texting capabilities, and use it with **Bluetooth Enabled** headsets. Here's a quick anatomy lesson.





If you need help while using your phone press **Start** > **Help and QuickStart** (Ⓢ) to open the in-device help. Also see Additional Information on page 77.

Motorola, Inc.
Consumer Advocacy Office
1307 East Algonquin Road
Schaumburg, IL 60196
www.hellomoto.com

Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality. All features, functionality, and other product specifications, as well as the information contained in this user's guide are based upon the latest available information and are believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. The Bluetooth

trademarks are owned by their proprietor and used by Motorola, Inc. under license. Microsoft, Windows, ActiveSync, Windows Media, Outlook, Pocket Outlook, Excel, and Word and MSN are registered trademarks of Microsoft Corporation; and Windows XP, Windows Mobile and Microsoft.net are trademarks of Microsoft Corporation. All other product or service names are the property of their respective owners.

© Motorola, Inc., 2006.

Caution: Changes or modifications made in the radio phone, not expressly approved by Motorola, will void the user's authority to operate the equipment.

Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or

reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Manual Number: 6809500A11-O

contents

start menu	7	infrared port	15	iTAP® mode	46
use and care	8	memory card	15	numeric mode	47
essentials	9	lock & unlock phone ..	16	symbol mode	47
about this guide	9	lock & unlock keypad ..	17	volume	47
battery	10	main attractions	18	handsfree speaker ...	48
turn it on & off	13	synchronize	18	voice commands	48
make a call	13	e-mail & messages ...	21	flight mode	50
answer a call	13	take & send a photo ..	31	media player	50
open a program	13	record & play video clip	33	audio enhancement ..	51
your phone number ..	14	download and copy		web browser	51
change between		media files	36	file manager	52
uppercase, lowercase, and		Bluetooth® wireless ..	37	task manager	52
caps lock	14	basics	40	customize	54
entering text and		display	40	profiles	54
numbers	14	thumb wheel	42	time & date	55
undo/back key	15	menus	43	home screen	55
thumb wheel	15	text entry	45	backlight	57

brightness	57	phone information	74	index 110
answer options	57	fun & games	75	
calls	59	additional information .	77	
turn off a call alert	59	service & repair	78	
recent calls	59	SAR Data	79	
redial	60	Microsoft License	81	
view missed call	60	Safety Information	91	
caller ID	61	Warranty	97	
emergency calls	61	Hearing Aid		
international calls	62	Compatibility	103	
speed dial	62	WHO Information	105	
voicemail	62	Product Registration . .	105	
other features	64	Export Law		
advanced calling	64	Assurances	106	
contacts	65	Wireless: The New		
personalizing	68	Recyclable	106	
call times & costs	70	Smart Practices While		
handsfree	71	Driving	108	
network connections . .	72			
calendar	72			
security	74			

start menu

From the home screen, press the **Start Left Soft Key**.

main menu

-  Internet Explorer
-  Wireless Sync
-  Windows Media
-  Calendar
-  Active Sync
-  Call History
-  Bluetooth
-  Contacts
-  File Manager

-  **Messaging**
 - Text Messages
 - Outlook E-mail
 - MMS
-  **Settings**
 - Call Options
 - Sounds
 - Profiles
 - Home Screen
 - Clock & Alarm
 - Connections
 - Security
 - Remove Programs
 - Power Management
 - Accessibility
 - Regional Settings
 - Owner Information
 - About
 - Error Reporting
 - Phone Settings
 - TTY Settings
 - Unread Message Alert
 - Text Input Settings

-  **Games**
-  **Pocket MSN**
-  **Pictures & Videos**
-  **Voice Recognition**
-  **Help and QuickStart**
-  **Media Center**
-  **Speed Dial**
-  **Tasks**
-  **Voice Notes**
-  **Accessories**
-  **System Tools**

This is the standard menu layout. **Your phone's menu may be a little different.**

* If desired menu item does not appear on your screen, use the navigation key, thumb wheel, or press the **More Left Soft Key**.

use and care

To care for your Motorola phone, please keep it away from:



liquids of any kind

Don't expose your phone to water, rain, extreme humidity, sweat, or other moisture.



dust and dirt

Don't expose your phone to dust, dirt, sand, food, or other inappropriate materials.



extreme heat or cold

Avoid temperatures below -10°C/14°F or above 45°C/113°F.



cleaning solutions

To clean your phone, use only a dry soft cloth. Don't use alcohol or other cleaning solutions.



microwaves

Don't try to dry your phone in a microwave oven.



the ground


Don't drop your phone.

essentials

CAUTION: Before using the phone for the first time, read the *Important Safety and Legal Information* included in the gray-edged pages at the back of this guide.

about this guide

This guide shows how to locate a menu feature. Press the **Left** and **Right Soft Keys** to select screen menus and options. Use the **Navigation** key (⬅️⬆️➡️) to scroll and highlight menu features. Press the **Center Select** key (⬆️⬤⬆️) to select items.



Find it: Press **Start** > **Call History** > **[Incoming Call]**

This example shows that, from the main or Home Screen of the phone, you press the **Left Soft Key** to open the **Start** menu and then use the thumb wheel to scroll to  **Call History** then highlight and select an incoming (↻) call.

symbols



This means a feature is network/subscription dependent and may not be available in all areas. Contact your service provider for more information.



This means a feature requires an optional accessory.

need more help?

If you need help while using your phone, press **Start > Help and QuickStart** (?).

For more support, see Additional Information on page 77.

battery

battery tips

Battery life depends on the network, signal strength, temperature, features, and accessories you use.

- Always use Motorola Original batteries and chargers. The warranty does not cover damage caused by non-Motorola batteries and/or chargers.
- New batteries or batteries stored for a long time may take more time to charge.
- When charging your battery, keep it near room temperature.



- When storing your battery, keep it uncharged in a cool, dark, dry place, such as a refrigerator.
- Never expose batteries to temperatures below -10°C (14°F) or above 45°C (113°F). Always take your phone with you when you leave your vehicle.
- It is normal for batteries to gradually wear down and require longer charging times. If you notice a change in your battery life, it is probably time to purchase a new battery.



Contact your local recycling center for proper battery disposal.


Warning: Never dispose of batteries in a fire because they may explode.

Before using your phone, read the battery safety information in the "Safety and General


Information" section included in the gray-edged pages at the back of this guide.


battery installation

1.




2.





battery charging

New batteries are not fully charged. You can charge your battery by connecting the power supply to your phone's mini-USB port and plug into a wall outlet. Your phone displays a full battery icon or **Charge Complete** when finished.




Tip: Relax, you can't overcharge your battery. It will perform best after you fully charge and discharge it a few times.

Note: If your battery has been completely drained, it cannot be charged via the USB cable plugged into the computer (this connection will only maintain current battery

life). Use a wall charger or car charger to recharge the battery. Some computer USB ports provide a higher current than others, and will provide more rapid charging.

turn it on & off

To turn on your phone, press and hold the **Power/End** key (⏻) until the display turns on.



To turn off your phone, press and hold the **Power/End** key (⏻) for 3 seconds.

make a call

From the Home Screen, enter a phone number and press the **Call /Answer** key (☎) to

make a call. To learn how to use voice dialing, see page 67.

answer a call

When your phone rings and/or vibrates, press the **Call/Answer** key (☎) or the **Accept Left Soft Key** to answer. To “hang up,” press the **Power/End** key (⏻).

open a program


On the Home Screen and press **Start** to access the list of programs. Use the thumb wheel or navigation key (⬅️) to scroll to a program. Then press the center select key (⬇️) or thumb wheel to open the program.

your phone number

To view your phone number, press **Start** > **Settings** > **Phone Settings** > **My Telephone Number** to see your number.

change between uppercase, lowercase, and caps lock

Your phone has a QWERTY Keypad, much like your computer keyboard. You can use it to type e-mail and text messages, as well as enter contact information. Here are some basics: Press the **Caps** key (↵) to change




between uppercase, lowercase, and caps lock within a text input mode. For more details regarding text input modes see page 45.

entering text and numbers


You enter text and numbers using the phone keypad.

When you select a field that requires text or numbers, the phone automatically selects the appropriate input mode. However, if you need to switch between modes, press the **ALT** key (⌘). See the indicator at the top of the Home Screen to identify the current text mode setting. For details about the different text modes, see page 45.



undo/back key

To return to the previous screen or menu, press the **Undo/Back** key (see graphic) or use the **Back** key (←) on the keypad.



thumb wheel

To display a list of options on the Home Screen, use the thumb wheel to scroll through the menu.



infrared port

Use the infrared port to sync and exchange files with a PC or other infrared capable device.



Tip: Want to use Bluetooth or USB Cable to transfer data? For Bluetooth transfer information see page 37. For data transfer using USB cable and ActiveSync, see page 18.

memory card


You can use a removable memory card with your phone to store and retrieve multimedia objects (such as photos and sounds).



Caution: Do not remove your memory card while your phone is using or writing files on it.

To insert a memory card:

- 1 Open memory slot cover. Place fingernail on bottom ridge of infrared port and lift rubber cover from the memory slot.
- 2 Insert memory card, with the contacts facing down, into the exposed memory slot.
- 3 Place memory card cover back in place and push to close.



Caution: Don't bend or scratch your memory card. Keep it away from static electricity, water, and dirt.

Note: Move media files (pictures, videos, music) to a memory card as often as possible to save storage space on your phone.

lock & unlock phone

You can manually lock your phone to keep others from using it.

- 1 Press and hold the home key (▲). The Quick List displays.
- 2 Highlight and select **Device Lock**.
- 3 In **Lock phone after**, select the amount of time for the phone to be inactive before automatically locking.
- 4 Enter and confirm your password.
- 5 Press **Done**.

To unlock the phone, press **Unlock**. When the unlock screen displays, enter your password and press **Unlock**.

Note: To quickly lock the phone, press and hold the home key (⬆). When the Quick List displays, select **Device lock**.

Note: You can make emergency calls on a locked phone (see page 61). A locked phone still rings or vibrates for incoming calls or messages, **but you DO NOT need to unlock it to answer** a call.

security auto phone lock

To enable an automatic phone lock, where your phone automatically locks after a specified time, use auto phone lock.

Find it: On the Home Screen, press **Start > Settings > Security > Enable Phone Lock**

lock & unlock keypad

Press and hold the home key (⬆). When the Quick List displays, highlight and select **Key Lock**. Once the keypad is locked, the **Left Soft Key** label changes to **Unlock**.

Tip: To quickly lock the keypad press the home key (⬆) and then the space bar.

To unlock the phone, press **Unlock**. When the unlock screen displays, press the  key.

main attractions

You can do much more with your phone than make and receive calls!

synchronize

You can synchronize the information on your phone in two ways, over the air (OTA) or using a cable and your computer.

sync over the air

To sync your phone over the air (OTA) you must sync it directly with your company's Microsoft Information Server or Microsoft Exchange Server 2003. For more information about this set-up see Additional Information on page 77 and the Motorola Q Support

website at:

<http://www.motorola.com/support/Q>.

Note: You can also contact your system administrator to set up this synchronization.

sync with a computer

Note: For information about connections (Bluetooth®, VPN, and web browser) see page 72.

You can use Microsoft® ActiveSync® version 4.1 or above to synchronize information between your phone and desktop computer. ActiveSync compares your phone's contact information, calendar appointments, e-mail messages, and media files to those on your

computer and then updates to the most recent information.

installing and setting up ActiveSync

To synchronize information on your phone with a PC, you must install Microsoft ActiveSync software on your computer.

Caution: Verify the minimum requirements for your computer and the operating system on the CD-ROM sleeve or Microsoft Mobile Phone website (<http://www.microsoft.com/windowsmobile>) before installing the software.

Note: If you do not have a CD-ROM, you can download the latest ActiveSync software from the Microsoft Windows Mobile website (<http://www.microsoft.com/windowsmobile>).

1 Install ActiveSync on your PC.

- 2** After setup completes, connect your phone to the PC. The phone drivers install on your computer and then the Sync Setup Wizard automatically starts.
- 3** Follow the instructions on the screen to complete the wizard.


Note: You can configure an Exchange Server connection to synchronize directly with Exchange Server and Outlook e-mail clients. The Sync Setup Wizard will prompt you for the name of the Exchange Server, your user name, password, and domain name. If you don't have this information available, you can contact your company's system administrator to setup your phone or see Additional Information on page 77 and the Motorola Q Support website at: <http://www.motorola.com/support/Q>.

When you finish the wizard, ActiveSync starts to synchronize automatically with your phone.

Once synchronization completes, you can disconnect your phone from your PC.

synchronizing via a cable connection

Once ActiveSync is installed on your PC, you can connect it to your phone and sync.



- 1 Turn on the phone.
- 2 Connect your phone to your PC using a USB cable.



Note: For more detailed information, see “Connecting a mobile device to a PC” in ActiveSync Help on your PC or the Microsoft Web Site for ActiveSync.

synchronizing via Bluetooth

Once ActiveSync is installed on your PC, you can connect it to your phone and sync via Bluetooth.

Note: In order to use this feature, your PC must be equipped with Bluetooth or a Bluetooth PC adaptor accessory.

- 1 Follow the instructions in ActiveSync Help for configuring Bluetooth on your PC to support ActiveSync.
- 2 Turn on the phone.
- 3 On your phone, verify that Bluetooth is turned on (Press **Start** > **Bluetooth** > **Bluetooth Manager** > **Settings**. Toggle **Status** to **Bluetooth On**).
- 4 Press **Start** > **ActiveSync**.
- 5 Select **Menu** > **Connect via Bluetooth**. Ensure that the phone and PC are within close range.

- 6 If this is the first time you have connected to this PC via Bluetooth, you must complete the Bluetooth wizard on the phone and set up a Bluetooth partnership with the PC before synchronizing.
- 7 Select **Sync**.
- 8 When finished, select **Menu > Disconnect Bluetooth**.
- 9 To preserve battery power on your phone, turn off Bluetooth (see page 37).

synchronizing via infrared

Once ActiveSync is installed on your PC, you can connect it to your phone and sync via infrared.

Note: To use this feature, your PC must be equipped with infrared capability.



- 1 Follow the instructions in ActiveSync Help on the PC for setting up your PC to receive infrared signals.
- 2 Turn on the phone.
- 3 On your phone, verify that IR is turned on (Press **Start > Settings > Connections > Beam** and select **Receive incoming beams**).
- 4 Line up the infrared (IR) port on your phone and PC so that they are unobstructed and within close range.
- 5 Press **Start > ActiveSync**.
- 6 Select **Menu > Connect via IR**.
- 7 Select **Sync**.

e-mail & messages

Note: You can set up e-mail with your company's Microsoft Exchange Server 2003.

Contact your system administrator for the required e-mail set-up information or see Additional Information on page 77 and the Motorola Q Support website at: <http://www.motorola.com/support/Q> .

setting up e-mail

You can set up an e-mail on your phone to check and send messages. There are two ways to set up e-mail: automatically or manually. If you have a Hotmail or Pocket MSN account, see Hotmail E-mail Setup on page 23.

automatic e-mail set up

Some e-mail providers allow for automatic e-mail set up. Have your e-mail address, username, and password ready and:

- 1 Press **Start** > **Messaging** > **Outlook E-mail**.
- 2 Select **Menu** > **Options** > **New Account**.

22 main attractions

- 3 In **Your name**, enter your display name for e-mail messages.
- 4 In **E-mail address**, enter the e-mail address for this account.
- 5 Select **Attempt to obtain e-mail settings from the Internet** and select **Next**.

Note: If the account sets up successfully, you will be prompted to send and receive e-mail. If not, you must click **Next** and see the next section.

manual e-mail accounts settings

If you tried to automatically set up your account and were prompted for detailed e-mail settings, call your e-mail (internet) service provider for additional information.

Note: You will need the following information from your e-mail provider: Domain, Server type (POP3 or IMAP4), Account name, Incoming mail server (POP3 or IMAP4),

Secure Sockets Layer (SSL) connection requirements, and Outgoing mail server (SMTP) to complete the set up.

- 1 Press **Start** > **Messaging** > **Outlook E-mail**. 
- 2 Select **Menu** > **Options** > **New Account**.
- 3 In **Your name**, enter your display name for e-mail messages.
- 4 In **E-mail address**, enter the e-mail address for this account.
- 5 Select **Next**.
- 6 Enter the information from the e-mail (Internet) service provider as appropriate until setup is complete, and click **Finish**.

Caution: If you save your password and then lose your phone, someone finding your phone may gain access to your e-mail.

Hotmail e-mail setup



If you use the Hotmail or MSN email services, have your e-mail address, and password ready and:

- 1 Press **Start** > **Pocket MSN**.
- 2 Select **MSN Hotmail**.
- 3 In **E-mail address**, enter the e-mail address for your account.
- 4 In **Password**, enter the password for the account.
- 5 Select **Next**.
- 6 Press **Menu** > **Send and Receive**.

If the Hotmail account completes set up correctly, your e-mail files and account folders will be synchronized with your phone.

Tip: Once you set up your Hotmail e-mail account, you won't need to do it again.

operator hosted e-mail

If you have Operator Hosted Email, please contact your operator, or access their web site in order to get information about their hosted email solution, and its compatibility with Windows Mobile® 5.0 enabled devices.

receive & read messages

When you receive a message your phone plays an alert and displays  **New Message** with a message indicator such as ✉.

Find it: On the Home Screen, press **Start** > **Messaging** > *E-mail account*

Tip: If you do not see a list of messages, press **Menu** > **Folders** > **Inbox**. To return to the Folder list, press the **Back** key (←).

To read a message:

To open the next message in the list from within an open message, press the navigation key  to the right; to open the previous message in the list, press the navigation key  to the left.

message options

To delete, save, reply, or forward the messages, use these quick steps from the Inbox with a message selected or when viewing a message:

- To delete, press **Menu** > **Delete**.
- To reply, press **Menu** > **Reply** or **Reply All**. Enter the message and press **Send**.
- To forward, press **Menu** > **Forward**. Enter the message and press **Send**.
- To create a contact card for the sender, press **Menu** > **Save to Contacts**.

Tip: Need to check your e-mail right now? Press **Start** > **Messaging**. Select the account to send and receive messages and press **Menu** > **Send/Receive**. The phone connects to your Internet e-mail server and sends and receives your messages. To stop this process, press **Menu** > **Stop Send/Receive**.

send a message

You can send SMS text messages, MMS multimedia messages to other capable mobile phones. MMS messages and e-mail messages can contain pictures, animations, sounds, videos, PDFs, compressed files, word processing and spreadsheet files.



Find it: Press **Start** > **Messaging** > **Text Messages** or *E-mail Account*

To send a text message:

- 1 Press **New**.
- 2 For e-mail, in **To**, **Cc**, and/or **Bcc**, enter e-mail addresses. Insert a semicolon (;) between multiple numbers or addresses.

For text messages, enter contact telephone number.

Tip: You can quickly enter phone numbers or e-mail addresses from your contact cards. In **To**, press **Enter** (↵) and select a recipient from the list. Then select the recipient's phone number or e-mail address.

- 3 Use the keypad to compose a message.
- 4 Press **Send**.

Tip: In an e-mail you can insert a **picture**, **voice note** or **file** in the message, on the

message area press **Menu > Insert > Picture** or **Voice Note** or **File**.

Note: If you select to insert a voice note into the message, you will also need to record it. Press **Record** and start speaking into the phone's microphone. When finished speaking, press **Stop** and then **Done**.

To set the priority for an e-mail message, press **Menu > Message Options**.

To cancel a message, press **Menu > Cancel Message**.

messaging quick reference

Note: Make sure you have an e-mail provider and the following account information: ISP settings, protocols, user id, password, and sending and receiving host information. Otherwise, you might not get these features to work.



features

send text message

Press **Start > Messaging > Text Messages > New**



create and send e-mail

Press **Start > Messaging > Outlook E-mail > E-mail Account > New**



Tip: Remember you must have your e-mail set up to send an e-mail (see page 21).

To add a picture, voice note, or file in an e-mail message, in the message area press **Menu > Insert > Picture** or **Voice Note** or **File**

Tip: You can save a draft of a message that you are composing to finish and send later. Press **Menu > Save to Drafts**. A draft of the message is stored in the Drafts folder of the account you are in.

features

create and add e-mail signature

Press **Start** > **Messaging** > **Outlook E-mail** > *E-mail Account*

Press **Menu** > **Options** > **Signatures**

Scroll to the account for which you are creating the signature. Select **Use signature with this account**.

Select the Signature box, enter your signature, and press **Done**.

Tip: To insert a signature in every message you send, select **Include when replying and forwarding**. Otherwise, a signature is inserted only in new messages.

read new messages



To quickly view new messages, click the message notification area on the Home Screen.

features

view attachment



While viewing the message, use the center select key (•) to select the attachment.

Note: You can view attachments only for file types that are supported by the phone.

read old messages



Press **Start** > **Messaging** > **Outlook E-mail** > *E-mail Account*

Icons next to each message show if it is **unread** , **read** , **urgent** , **locked** , or has an **attachment** .

features

reply, reply all or forward messages

From your Inbox or an open message, press **Menu > Reply or Reply All or Forward** 

Tip: If you are replying to an e-mail in the Outlook E-mail account, you will send less data if you do not edit the original message. This may reduce data transfer costs based on your rate plan.

features

download message objects

If an e-mail message includes an attachment, when you open the message, the name of the attachment will appear highlighted. To download the attachment, click the highlighted attachment name. The attachment is downloaded the next time you synchronize or connect to your e-mail server. 

Note: If there are multiple attachments in the message, all attachments are downloaded.

insert a media object in an e-mail

To add a picture, voice note, or file in an e-mail message, in the composing message area press **Menu > Insert > Picture or Voice Note or File**.

features

download complete e-mail messages

Press **Start** > **Messaging** > **Outlook E-mail** > *E-mail Account* > *Message*



Press **Menu** > **Download Message**.

The complete message is retrieved the next time you synchronize or connect to your e-mail server and send and receive e-mail.

features

mark a folder for synchronization



When you synchronize your Outlook E-mail account with your PC, the same Inbox folders that are in Outlook on your PC are created on your phone.

Press **Start** > **Messaging** > **Outlook E-mail**

Press **Menu** > **Folders** > **Menu** > **Show all Folders**

Press **Menu** > **Manage Folders** > *Folder* > **Sync**

Note: Make sure to mark your e-mail sent folder for synchronization, or you won't be able to view sent message status.

features

view status of sent e-mail

Press **Start** > **Messaging** > **Outlook E-mail** > *E-mail Account*

Messages are sorted from newest to oldest. If you see a , your message was successfully sent. If a **✕** is displayed, your message could not be sent. Try again, the e-mail provider network could be busy.

receive e-mail



If your phone is set up to automatically check for new messages, your phone will display the message waiting () indicator when a new message arrives.

Press the **Read** key to open the message.

features

delete e-mail

From the Inbox or an open e-mail message:

Press **Menu** > **Delete**

manually send and receive e-mail



Press **Start** > **Messaging** > **Outlook E-mail** > *E-mail Account*

Press **Menu** > **Send/Receive**.

call a phone number in e-mail



Highlight a phone number in a message and press .

create personal folders

Press **Start** > **Messaging** > **Outlook E-mail** > *E-mail Account* > *Message*



Press **Menu** > **Manage Folders**

features

move e-mail to personal folder

After you're done reading the e-mail:

Press **Menu** > **Move** > *Folder*

delete a mail account

Press **Start** > **Messaging** > *E-mail Account*

Press **Menu** > **Options** > **Account Options** > *E-mail Account*

Press **Menu** > **Delete**

Note: You cannot delete your Text Messages or Outlook E-mail accounts.

empty deleted items folder

Press **Start** > **Messaging** > *E-mail Account*

Press **Menu** > **Folders** > **Deleted items**

Press **Menu** > **Empty Folder**

take & send a photo

Press and hold the **Camera** (📷) key for 2 seconds to see the camera viewfinder:



Tip: To adjust picture settings (**mode**, **brightness**, **resolution**, **zoom**, **white balance**, and **flash**) in the camera viewfinder press **Menu**.

- 1 Point the camera lens at the photo subject.

2 Press the **Camera** (📷) key again or the center select key (⬤) to take a photo. The picture is automatically saved and displays in the view finder.

3 Press **Menu** to see the camera options.

- To delete the photo and return to the active viewfinder, select **Delete**.

- To send the photo, select **Send**.

Your send options are **Text Messages**, **Outlook E-mail**, or **MMS** (Multimedia Message).

- To sent the picture via Bluetooth, select **Bluetooth**.
- To beam the picture via the Infrared port, select **Beam**.
- To use the picture as the Home Screen, select **Use as Home Screen**.
- To edit the picture, select **Edit**.

- To view image properties, like the filename, select **Properties**.
- To view picture option, select **Options**.

Note: Pictures are automatically stored in your phone. To view them: Press **Start > Pictures & Videos**. Select the picture to view and press **View**.

Tip: To view pictures located in a folder other than the default pictures folder, including a storage card, press **Start > Pictures & Videos > Menu > Folder**, and select the folder that contains stored pictures.

self portrait

1 Press the **Camera** (📷) key to activate the camera.

2 Press **Menu > Mode > Timer**.

- 3 Press the **Camera** (📷) key to start the 5 second delay.
- 4 Aim the camera lens at yourself.
- 5 When you hear the camera shutter sound, the photo is taken, and your photo displays.

picture options

In the picture viewfinder press **Menu > Options** to open the **Picture Options Menu**. This menu can include the following options:

option	
General	Determine default picture sizes for e-mail and rotating picture settings.
Slide Show	Select default slide show settings.

option	
Camera	Select default locations to store pictures, filename prefixes, and image compression.
Video	Determine audio settings and time limits for video files.

record & play video clip

record a video clip

Find it: Press the **Camera** (📷) > **Menu > Video**



Tip: To adjust video settings (**still**, **brightness**, **quality**, and **white balance**) in the video viewfinder, press **Menu**.

- 1 Point the camera lens at the photo subject.
- 2 Press the **Camera** (📷) key or the center select key (⬤) to begin recording a video. The video displays in the viewfinder.
- 3 Press **Stop** to end recording the video altogether, or press **Pause** to pause recording and **Resume** to continue recording.

Note: Videos are automatically stored in your phone. To view them: Press **Start** > **Pictures & Videos**. Select the video to view and press **Play** or the center select key (⬤).

Tip: To view videos located in a folder other than the default video folder, including a

storage card, press **Start** > **Pictures & Videos** > **Menu** > **Folder**, and then select the folder that contains the stored videos.

video options

In the video viewfinder press **Menu** > **Options** to open the Options Menu. This menu can include the following options:

option	
Camera	Select default save locations, video filename prefixes, and image compression.
Video	Determine audio and time limit settings for video files.

Note: **General** and **Slideshow** options are also available in this menu, however these settings are specific to picture files only.

play a video clip

For more video playback and Windows Media features, see page 50.

Find it: Press **Start > Pictures & Videos > video clip > Play**

The video clip displays in the Windows Media screen.



Tip: To play video in full screen, press **Menu > Full Screen**. Not all videos play in full screen mode. Only those videos that were captured in the correct resolution.

If a call comes in while watching a video, the video pauses and a call alert appears. You can choose to answer the call or ignore it. To continue watching the movie, select the **Play** button.

video playback options

In the video playback window press **Menu > Options** to open the **Video Playback Menu**. This menu can include the following options:

option	
Playback	Determines how the time counter is displayed, whether to pause playback while using another program, and whether to resume playback after a phone call.

option	
Video	Options for displaying in full screen and when to scale to fit window.
Network	Selects default network settings for streaming media.
Library	Determines if the player starts on the Library screen.
Skins	Determine Windows Media Player skin theme.
Buttons	Set playback button mapping.

download and copy media files

You can copy or download media files from your computer or the Internet onto your phone.

copy files from your computer

To copy files from your computer to your phone:

Note: You must have ActiveSync on your PC installed as described on page 18.

- 1 Connect the phone to your PC.
- 2 In ActiveSync on your PC, click **Explore** and double-click **My Windows Mobile** device.
- 3 On your computer, find the files you would like to copy to your device and paste the files into the **My Windows Mobile** folder.
- 4 Resync your phone and computer and then view the picture or video on your phone from **Start > Pictures & Videos**.

Bluetooth® wireless

Your phone supports Bluetooth wireless *pairing* (also called *linking* or *bonding*). You can pair your phone with a Bluetooth headset or car kit, or pair your phone with a computer to exchange and synchronize files.

Note: The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

turn Bluetooth power on or off

If Bluetooth **Power** is **On**, your phone can automatically pair with the handsfree device you have used before. Just turn on the device or move it near the phone.

To turn Bluetooth on: Press **Start > Bluetooth > Bluetooth Manager > Settings** then toggle **Status** to **Bluetooth On**.

The Bluetooth indicator  displays in the Home Screen.

Note: To extend battery life, use the previous procedure to set Bluetooth **Power** to **Off** when not in use. Your phone will not pair with devices until you set Bluetooth **Power** back to **On** and pair your phone with the devices again.

pair with a headset or handsfree device

Before you try to pair your phone with a device, make sure your phone's Bluetooth power is **on** and the device is **on** and **ready** in *pairing* or *bonding* mode (see the device user's guide). You can pair your phone with multiple devices, but only use it with one headset device at a time.

Your phone lists the devices it finds within range.

- 1 Press **Start** > **Bluetooth Manager** > **Hands-free**.
- 2 Put the device (handsfree headset, stereo headset, keyboard, etc.) in pairing mode.
- 3 Press **Add**. The phone prompts you to verify your device is ready. Press **Search**.
- 4 Select the device from the list.
- 5 When prompted press **Yes** to pair with the device.
- 6 If necessary, enter the device passkey (such as 0000) and press the **Accept** key.

When the devices are paired, an icon appears on the Home Screen in the Bluetooth Task Tray.

Tip: For specific information about the Bluetooth device you are using with your phone, refer to the instructions that came with it.

send objects to another device

You can use Bluetooth pairing to send text messages, contacts, tasks, calendar items, audio, ring tones, pictures, video, and voice notes from your phone to a computer or other device.



- 1 Press **Start** > **Bluetooth** > **BT Send Object**.
- 2 Select the object type and object you want to send.
Tip: To select an item, press the center select key (•••).
- 3 Press **Send**.
- 4 Select the name of the device to send the file.
- 5 To cancel sending an item, press **Menu** > **Cancel**.

advanced Bluetooth features

features	
make phone visible to other device	
Allow a Bluetooth device to discover your phone:	
Press Start > Bluetooth > Bluetooth Manager > Settings > Allow other Bluetooth devices to see this phone	
connect to recognized device	
Connect to a recognized handsfree device:	
Press Start > Bluetooth > Bluetooth Manager > Hands-free > <i>device name</i>	
drop pairing with device	
Press Start > Bluetooth > Bluetooth Manager > Hands-free > <i>device name</i> > Menu > Delete	

features	
send object to device	
Send an object to another device:	
Press Start > Bluetooth > BT Send Object	
edit device properties / change device name	
Edit the properties of a recognized device:	
Press Start > Bluetooth > Bluetooth Manager > Hands-free > <i>device name</i> > Menu > Properties > Nickname	
Tip: To change the Bluetooth name of your phone, press Start > Bluetooth > Bluetooth Manager > Settings and enter the name in My Bluetooth name .	


basics

See page 1 for a basic phone diagram.

display


The *Home Screen* displays when you turn on the phone. To dial a number from the Home Screen, press number keys and .

Note: Your Home Screen may look different, than this one, depending on your service provider.




Soft Key Labels show the current soft key functions. For soft key locations, see page 1.

Press the navigation key  up, down, left, or right or use the thumb wheel to navigate basic menu items or text in the Home Screen. Press the home key () to return to the Home Screen.



Status indicators can display at the top of the Home Screen:



1 Roam Indicator – The roam indicator  shows when your phone is seeking or using a network outside your home network. Other indicators can include:

 = 2G home

 = roaming unavailable

2 Bluetooth Indicator – Shows connection status. Indicators can include:

 = Bluetooth [®] wireless connection

3 Message Indicators – Shows when you receive new messages. Indicators can include:

 = new e-mail or text message

 = voicemail message

4 Signal Strength Indicator – Vertical bars show the strength of the network connection. You can't make or receive calls when no vertical bars are displayed.

5 Battery Level Indicator – Vertical bars show the battery charge level. Recharge the battery when your phone shows one or two bars. Arrow indicators above the battery indicator, signifies data transfer to the phone.

- 6 Profile Indicator** – Shows the profile (ring style) setting. When the profile is normal, outdoor, or automatic no indicator is displayed.

📞 = meeting	(no icon) = headset
(no icon) = car	(no icon) = normal
🔇 = silent	(no icon) = outdoor
📞 = speakerphone	(no icon) = automatic

Note: You cannot change to speakerphone mode from the Profiles menu.

- 7 Location Indicator** – Shows when your phone can send location information 📍 or not 🚫.



thumb wheel


You can use the thumb wheel to scroll through menu items and lists. Press the thumb wheel to select the highlighted item in a list or menu.



Tip: Use the **Back** button (the button below the thumb wheel) to undo the current action or return to the previous screen.

menus

From the Home Screen, press **Start** to open the main menu.



Use the navigation key  up, down, left, or right or thumb wheel to see more menu items.




The following menu icons may be available in the main menu.

menu features	
 Internet Explorer	 Wireless Sync
 Windows Media	 Calendar
 ActiveSync	 Call History

menu features

 Bluetooth	 Contacts
 File Manager	 Messaging
 Settings	 Games
 Pocket MSN	 Pictures & Videos
 Voice Recognition	 Help and QuickStart
 Media Center	 Speed Dial
 Tasks	 Voice Notes
 Accessories	 System Tools

Some features require you to select an option from a list:




- Scroll up or down to highlight the option you want.
- In a numbered list, press a number key to highlight an option.
- In an alphabetized list, use the keyboard and press the first letter of the desired item and the phone will highlight the closest matching list option.

- When an option has a list of possible settings, noted by an arrow displayed next to the option, scroll left or right to select the setting.
- When an option has a list of possible numeric values, press a number key to set the value.
- Press **Menu** for additional items for option.

text entry

You can enter text and numbers using the keypad. When you select a field that requires text or numbers, the phone automatically selects the appropriate entry mode. The status indicator at the top right of the display

screen shows the entry mode you are currently using.



Press the **ALT** key (⌘) in a text entry screen to select an entry mode:



input modes	
<u>abc</u>	primary key entry

input modes	
Alt	Secondary key entry. In this mode the next key pressed will be the secondary character. After next key is pressed, the device will return to primary key entry mode.
ALT	Secondary key lock. In this mode all subsequent keypresses will be secondary keys until the ALT key (⌘) is pressed again. 

- To backspace and delete a single character in any input mode, press the **Back** key (←).

To backspace and delete an entire text or numeric field in any input mode, press and hold the **Back** key (←).

- To enter a symbol, press the **ALT** key (⌘) and then the **Caps** key (⇧). The Symbol page displays. Press the center select key (⬮) or thumb wheel to select the symbol you want.
- To enter numbers quickly, press **Alt** key (⌘), to switch to **ALT** mode.

Tip: If a field permits a numeric entry only, like a phone number, the input mode automatically defaults to secondary key entry mode.

- To start a new line, press **Enter** (↵).

iTAP® mode

iTAP mode lets you enter words using one keypress per letter. The iTAP software combines your keypresses into common words, and predicts each word as you enter it.

If you want a different word (such as **Progress**), continue pressing keypad keys to enter the remaining characters.

numeric mode

Press **Alt** key to activate the secondary key mode (top keypad symbols) and enter the numbers you want.

symbol mode

Press the **Alt** key and then the **Caps** key (↵). The Symbol page displays. Select the symbol you want and click **Done**.

volume

Press and hold the thumb wheel to adjust earphone, speaker, or headset volume.



- Need to change profiles on the fly? On the Home Screen, scroll to and select **Profile**. Choose from **Normal**, **Silent**, **Meeting** and others.
- Want to turn off a sound? Press **Start** > **Settings** > **Sounds**. Highlight the desired item and select the sound you want to associate with that item.


Tip: You can eliminate the ringer volume instantly when an incoming call comes in—just use the thumb wheel to turn the ringer off.

handsfree speaker

Note: The use of wireless phones while driving may cause distraction. Discontinue a call if you can't concentrate on driving. Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

You can use your phone's handsfree speaker on calls without holding the phone to your ear.

During a call, press the **Voice** key (see graphic) or press **Menu > Speakerphone On**.



Your phone displays **Spkrphone On** until you turn it off or end the call.

Note: The handsfree speaker won't work when your phone is connected to a car kit or headset.

voice commands

You can use voice commands to make calls, and to open and use some phone applications.

Note: Not all phone languages support voice recognition and voice commands.

open applications

To open a call a contact, send a text message, look up contact information or open a program:

- 1 Press and hold the voice key for 2 seconds.

Your phone prompts you to say a command.

- 2 Say one of the following commands:

"Call <contact name or phone number>,"
"Send text <contact name>," "Look up
<contact name>," or "Open <program
name>."

Your phone will respond to the request by making a call, opening a text message screen, open the contact information for requested contact, or open the program.

Tip: Speak numbers at a normal speed and volume, pronouncing each digit distinctly. Avoid pausing between digits.

Notes:

- Your phone may prompt you to repeat a name or number. If the name/number isn't valid, the phone doesn't make the call.
- If the phone does not recognize the name or number, the display shows a list of names/numbers, asks, "Did you say ...," and highlights the first item in the list. Say "Yes" to call the highlighted number, or "No" to go to the next list item.

To select the name or number manually, scroll to the name/number on the list and press the **Select** key.

flight mode

You can put your phone in flight mode to safely access your address book, games, camera, and music in areas where cellular network access is prohibited (i.e. during airline flights and in hospitals).

To turn flight mode on or off: Press and hold the home key (⬆). The Quick List displays. Highlight and select **Flight Mode**.

Tip: To turn off flight mode, press and hold the home key (⬆), when the Quick List displays, highlight and select **Flight Mode Off**.

media player

You can use Windows Media Player 10.1 Mobile for Smartphone to play digital audio and video files that are stored on your phone or on the Web.

By default, Windows Media Player Mobile can play the following types of files: Windows Media Audio (WMA), Windows Media Video (WMV), and Motion Picture Experts Group-2 Audio Layer-3 (MP3).

Find it: Press **Start** > **Windows Media**



- To play or pause a music or video file, press **Enter** (↵).

- To skip to the previous or next file, press the navigation key (◂◃) left or right.
- To increase or decrease the volume, press the navigation key (◂◃) up or down.

Tip: If you need to turn the sound off, press **#**.

- To switch to full screen video playback, press **0**.
- To fast forward or rewind, press and hold the navigation key (◂◃) left or right.

Tip: Do you want to play a song or video on the Internet or network? Use the Open URL command. From the Library screen press **Menu > Open URL** (if you need to get to the Library screen, in Windows Media, press **Menu > Library**).

For more information about downloading or copying video files see page 36.

audio enhancement

Your phone allows you to adjust surround sound, bass, and clarity levels for the phone speakers as well as your headset.

Find it: From the Home Screen, press **Start > Accessories > Audio Enhancement**

Note: If you are adjusting headset audio, make sure you wear your headset when adjusting audio levels. You can also set the speaker size for your particular headset.

web browser

You can use Internet Explorer Mobile to search and view the web.

Find it: Press **Start** > **Internet Explorer**



- To go to a web page, press **Menu** > **Address Bar**. Enter the address and press **Go**.
- To go to a link in a web page, use the navigation key to highlight the link and then press the center select key (•◄•).
- Change connection options, press **Menu** > **Tools** > **Options** > **Connections**.

- To show/hide pictures, press **Menu** > **View** > **Show Pictures**.
- To add web address to your Favorites, open the web page and press **Menu** > **Add to Favorites**.

file manager

You can use File Manager to sort, view, copy, and move files on your phone. Files you might want to use in file manager include text, pictures, music, and video files.

Find it: On the Home Screen, press **Start** > **File Manager**

task manager

Want to see what programs are running (active) on your phone? Use the Task Manager

to see the programs, or stop a specific program from running.

Find it: On the Home Screen, press **Start > System Tools > Task Manager**

Tip: Need to stop running program? In **Task Manager**, select the program and press **Menu > Kill**.

Note: If you want to completely remove a program from your phone, from the Home Screen, press **Start > Settings > Remove Programs**.

customize

profiles

Each profile uses a different set of sounds, ring styles, earpiece volume settings, or vibrations for incoming calls and other events. For example, the Outdoor profile volume is much louder than the Normal profile.

Here are the profiles you can choose:

Normal	Silent
Meeting	Outdoor
Automatic	Headset
Car	Speakerphone

The ring style profile's indicator displays at the top of your Home Screen.

Note: The ring style profile indicators do not display in all Home Screen settings and will not display if the Home Screen is set to Windows simple or Large Font.

To choose your profile:

Find it: On the Home Screen, scroll and select **Profile:** > *profile style name*

change sounds in profile

You can change the alerts for incoming calls and other events. Your changes are saved in the current ring style profile.

Find it: Press **Start** > **Settings** > **Sounds**

Note: Changes made to the alert settings will have no effect when using the **Silent** profile.

- 1 Scroll and highlight the sound you want to change, then press the navigation key (•◊•) right or left to change it.
- 2 Press the **Done** key to save the sound setting.

time & date

Your service provider usually sets the time and date on your phone. But, if you decide to change it manually:

Find it: Press **Start** > **Settings** > **Clock & Alarm** > **Date and Time**

- 1 In **Time Zone**, use the navigation key (•◊•) to select your time zone.
- 2 In **Date**, edit the month, day, or year.


Tip: To change the month, day, and year, press the **Alt** key (see graphic) repeatedly.

- 3 In **Time**, edit the hour, minute, and second.

Tip: To change the hour, minute, and second press the **Alt** key repeatedly.

- 4 Press **Done** to save the clock and date settings.

You can specify the date and time style by changing the regional settings. Press **Start** > **Settings** > **Regional Settings**



home screen

Set a photo, picture, or animation as a wallpaper (background) image or change your

layout and color scheme on your Home Screen.

Find it: Press **Start > Settings > Home Screen**

options	
Home Screen Layout	Select a layout for the Home Screen.
Color Scheme	Select a color scheme for the display.
Background Image	Select a picture for your wallpaper image, or None for no wallpaper.
Time out	Select the time interval before the display will go inactive or Never .

copy image to background

Want to copy an image from your PC to your phone to use as a background image?

Note: You must have ActiveSync on your PC installed as described on page 18.

- 1 Connect the phone to your PC.
- 2 On your PC, copy the image file you want. The file format must be .gif, .jpg, or .bmp.
- 3 In ActiveSync on your PC, click Explore and double-click My Windows Mobile device.
- 4 Double-click Application Data, double-click Home, and paste the image into that folder.

Note: For best results, use images with the same screen resolution as your phone's screen resolution, either 240 x 320 pixels, or 176 x 200 pixels, depending on the phone.

- 5 Resync your phone and computer and then set the background to the image you copied to the phone.

backlight

To save battery life, your **backlight** turns off when you're not using your phone. The backlight turns back on when you press a key. To set how long your phone waits before the backlight turns off:


Press **Start** > **Settings** > **Power Management** > **Backlight time out on battery** and **Backlight time out on AC**

To save battery life, the **display** can turn off when you're not using your phone. The display turns back on when press a key. To set how long your phone waits before the display turns off:

Press **Start** > **Settings** > **Power Management** > **Display Time out**

brightness

Use a long press on the the messaging / brightness key (see graphic) to increase the backlight brightness to medium. To increase the backlight brightness to high, press the messaging/brightness key again.



answer options

You can use additional, alternative methods to answer an incoming call. To activate or deactivate an answer option:

Find it: Press **Start** > **Settings** > **Call Options** > **Any key answer**

When selected, you can put the first call on hold and answer the second call by pressing **Answer**. To switch between calls, press **Swap**.

To postpone answering the call, press **Ignore**. The call is placed in voicemail.

DRAFT

calls

To make and answer calls, see page 13.

turn off a call alert

You can use the thumb wheel to turn off the ringer before answering the call.

recent calls

Your phone keeps a list of incoming and outgoing calls, even for calls that didn't connect. The most recent calls are listed first. The oldest calls are deleted as new calls are added.

Find it: Press **Start** > **Call History**

1 Highlight a call.

- To call the number, press .
- To see call details (like time and date), press the center select key .
- To see **Menu Options**, press **Menu** from the Call History screen. This menu includes:

options	
Find Contact	Find this phone number in your Contacts.
Send Text Message	Send a text message to this phone number.
E-mail	Send an e-mail message to this Contact.
View Timers	View the call times for this call and all calls.

options	
Delete/ Delete List	Delete this call from the Call History.
Save to Contacts	Save this number to a Contact.
Filter	Filter all calls in the Call History list. Filtering calls allows you to group calls in a specific matter. For example, if you filter the list for all Missed Calls, all the incoming phone calls that you did not answer will be listed first.

redial

- 1 Press  from the Home Screen to see the dialed calls list.

- 2 Highlight the entry you want to call, then press .

If you hear a **busy signal** and you see **Call Failed, Number Busy**, press  or the **RETRY** key to redial the number. When the call goes through, your phone rings or vibrates one time, displays **Redial Successful**, and connects the call.



view missed call

Your phone keeps a record of your unanswered calls.

- 1 Press **Start > Call History**.
- 2 Press **Menu > Filter > Missed Calls**.

caller ID

Calling line identification (caller ID) shows the phone number for an incoming call on your Home Screen.



Your phone shows the caller's name and picture when they're stored in your phonebook, or **Incoming Call** when caller ID information isn't available.

You can set your phone to play a distinctive ringer ID for specific entries stored in your phonebook (see page 66).

To show or hide **your phone number** for the next outgoing call:

Find it: Press **Start > Settings > Phone > Caller ID > Callers**

emergency calls

Your service provider programs one or more emergency phone numbers, such as 911 or 112, that you can call under any circumstances, even when your phone and keypad are locked.

Note: Emergency numbers vary by country. Your phone's preprogrammed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

- 1 Press the keypad keys to dial the emergency number.
- 2 Press  to call the emergency number.

international calls

If your phone service includes international dialing, press and hold  to insert your local international access code (indicated by +). Then, press the keypad keys to dial the country code and phone number.



speed dial

To call speed dial entries, press and hold the single-digit speed dial number for one second. If the speed dial is two digits, press the first digit, and press and hold the second digit. The phone dials the phone number, opens a new e-mail message, or goes to the Web page.

You can set the speed dial to call the entries in your phone's contact list:

- 1 Press **Start** > **Contacts**.

- 2 Scroll to the desired contact and press **Select** key.
- 3 Select the phone number, e-mail address, or web address for which to create the speed dial.
- 4 Press **Menu** > **Add to Speed Dial**.
- 5 In the **Keypad Assignment**, select the speed dial number to use.
- 6 Press **Done**.

Note: Speed dial 1 is reserved for calling your voicemail.

voicemail

Your network stores the voicemail messages you receive. To listen to your messages, call your voicemail number.



Note: Your service provider may include additional information about using this feature.

When you **receive** a voicemail message, your phone displays the voicemail message indicator  and **New Voicemail**.

To **check** voicemail messages:

Press and hold the  key.

Note: You can't store a **p** (pause), **w** (wait), or **n** (number) character in your voicemail number. If you want to store a voicemail number with these characters, create a contact and when entering the voicemail number press **Menu** to insert these special characters. Then, you can use the entry to call your voicemail.

other features

advanced calling

features	
speed dial	
Speed dial a contact, e-mail address or web address:	
Press and hold the speed dial number.	
If the speed dial is two digits, press the first digit, and press and hold the second digit.	
To store phone book entries on your phone, see page 62.	
Tip: If you forget Aunt Mildred's speed dial number, press Start > Contacts , and find her entry.	

features	
TTY calls	
Set up your phone for use with an optional TTY device:	
Press Start > Settings > TTY Settings	
make call from hyperlink phone number	
You can quickly dial a phone number from an e-mail or text message that contains a hyperlink phone number. A hyperlink phone number is underlined in the same manner as a Web site address.	
From a message containing a hyperlink phone number, select the phone number and press  .	

features

make call from the contact list



You can quickly dial a phone number from the contact list.

Press **Start** > **Contacts**. Select the contact and press

Tip: If you have a long list of contacts, you can use a shortcut to find the contact you want. Enter the first few letters of the contact's name. The phone searches through the contact list and displays the name.

contacts

features

add new entry

Press **Start** > **Contacts** > **New**

Enter information for the new contact.

Tip: If someone who isn't in your list of contacts calls you or sends you a message, you can create a contact from Call History, or from the message by clicking **Menu** > **Save to Contacts**

edit contact

Press **Start** > **Contacts** > *Contact Name*

Press **Menu** > **Edit**

features

dial number

Call a number stored in the phonebook:

Press **Start** > **Contacts** > *Contact Name* > 

The contact's default number is dialed.

Tip: To call a phone number other than the default, click the contact, scroll to the number you want to dial, and press .

search for contact

Enter the first few letters of the contact's name. The phone searches through the contact list and displays the name.

features

set ringer ID for a contact

To easily identify who is calling you by the ring tone, you can assign a custom ring tone to each contact.

Press **Start** > **Contacts** > *Contact Name*

Press **Menu** > **Edit** > **Custom Ring Tone**

features

set picture ID for contact

Assign a photo or picture to display when you receive a call from an entry:

Press **Start** > **Contacts** > *Contact Name*

Press **Menu** > **Edit** > **Picture**

Tip: If you want to instantly take a picture with the camera for this contact, press the **Camera** (📷) key and take a picture.

Tip: Want to remove a picture ID? Press **Start** > **Contacts** > *Contact Name* > **Menu** > **Edit** > **Remove Picture**

voice dial

To user voice dialing:

Press **Start** > **Voice Recognition**

features

set category for contact

Press **Start** > **Contacts** > *Contact Name*

Press **Menu** > **Edit** > **Categories**

Tip: Categories are shared between your appointments, contacts, and tasks. A category will remain in the list of shared categories as long as it is assigned to at least one appointment, contact, or task.

set category view

Press **Start** > **Contacts**

Press **Menu** > **Filter**

features

send contact to another device

Use a Bluetooth® connection or Infrared connection to send a contact to another phone, computer, or device:

Press **Start** > **Contacts** > *Contact Name*

Press **Menu** > **Beam Contact**

Status information displays, indicating the name of the device to which the phone is beaming, and whether the beaming process is pending, finished, or was unsuccessful.

For more about Bluetooth connections, see page 37.

Tip: Remember you can only do this if you have an active Bluetooth connection.

personalizing

features

language

Set menu language:

Press **Start** > **Settings** > **Regional Settings**

Note: You must turn your phone off and on again for the changes to take effect.

Tip: If you want to specify a language for reading e-mail, while reading a message press **Menu** > **Languages**.

ring volume

Use the thumb wheel to adjust ring volume from the Home Screen.

Tip: You can eliminate the ringer volume instantly when an incoming call comes in—just use the thumb wheel to turn the ringer off.

features
accessibility You can set system font size, multipress timeout, confirmation timeout, and in-call alerts: Press Start > Settings > Accessibility
calendar events The default reminder time for tasks and calendar items is 15 minutes. To change this default: Press Start > Calendar > <i>event</i> > Reminder

features
sounds To change the default sounds for ring tone, reminders, new messages, alarm clock, or keypad controls: Press Start > Settings > Sounds Note: Changes made to the alert settings will have no effect when using the Silent profile.
alarm Press Start > Settings > Clock & Alarm Tip: Need to change or set the alarm alert style? Press Start > Settings > Sounds > Alarm Clock

features

owner information

Entering and displaying owner information are best practices; they allow someone to return the phone to you in case it is lost:

Press **Start** > **Settings** > **Owner Information**

master reset

Reset all options except **unlock** code, security code, and lifetime timer:

Press **Start** > **System Tools** > **Master Reset**

The amount of network connection time you track on your resettable timer may not equal the amount of time for which you are billed by your service provider. For billing information, contact your service provider.

features

call times



The default reminder time for tasks and calendar items is 15 minutes. To change this default:

Press **Start** > **Call History**

Press **Menu** > **View Timers**

call times & costs

Network connection time is the elapsed time from the moment you connect to your service provider's network to the moment you end the call by pressing . This time includes busy signals and ringing.

features

reset call timers

To reset all call timers to zero (0), except for the Lifetime calls timer:

Press **Start** > **Call History**

Press **Menu** > **View Timers**

Press **Menu** > **Reset Timers**

handsfree

Note: The use of wireless phones while driving may cause distraction. Discontinue a call if you can't concentrate on driving. Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

features

speakerphone



Activate a connected external speakerphone during a call:

Press the **Voice** key or press **Menu** > **Speakerphone On**.

Note: With a Bluetooth headset press **Menu** > **Handsfree Off** and then press **Menu** > **Speakerphone On**.

auto answer (car kit or headset)



Change to the headset profile to automatically answer calls when connected to a car kit or headset:

Press **Start** > **Settings** > **Profiles** > **Headset**

network connections

features
create proxy, Virtual Private Network (VPN), or dial-up network
Every network connection is different. You should gather all of the relevant information or network settings you need before starting this process: Press Start > Settings > Connections Note: For additional documentation and information about this feature, see page 77.
beam To allow your phone to receive data beamed from other devices (via Bluetooth® or Infrared): Press Start > Settings > Connections > Beam

calendar

features
add new calendar event
Press Start > Calendar Press Menu > New Appointment Note: To schedule an all-day event, under End time, select All day event. All-day events do not occupy blocks of time in Calendar; instead, they appear in banners at the top of the calendar.
view calendar event
To quickly view today's agenda, on the Home Screen, scroll and press the center select key (•◉•) on an upcoming appointment (if one is present). To view previous or approaching dates, scroll left or right, or click Menu > Go to Date.

features

calendar event reminder

The default reminder time for tasks and calendar items is 15 minutes. To change this default:

Press **Start > Calendar**

Press **Menu > Options > Set Reminders**

features

send calendar event to another device

Use a Bluetooth® connection to send a calendar event to another phone, computer, or device:

From the calendar item, press **Menu > Beam**.

If using Bluetooth, select the device to which you want to send the item.

If using infrared, align the infrared (IR) ports at close range until the target device name appears, and then select the device to which you want to send the item.

For more about Bluetooth connections, see page 37.

calculator

Press **Start > Accessories > Calculator**

features

respond to a meeting request

You can receive and respond to Outlook meeting requests on your phone in a similar manner as you do in Outlook on your PC.

Press **Start** > **Messaging** > **Outlook E-mail** > *E-mail Account* > *Meeting Request*

Press **Menu** > **Accept, Decline, or Tentative**

security

features

manage certificates



Enable or disable Internet access certificates stored on your phone:

Press **Start** > **Settings** > **Security** > **Certificate**

Certificates are used to verify the identity and security of Web sites when you download files or share information.

phone information

features

software version

To view your phone software version:

Press **Start** > **Settings** > **About**

features

memory & storage

To view your available and total memory capabilities of your phone and memory card use Memory Manager.

Press **Start** > **System Tools** > **Memory Manager**

fun & games

features

manage pictures

Manage pictures:

Press **Start** > **Pictures & Videos**

features

manage sounds

Manage ring tones and music that you have downloaded or composed:

Press **Start** > **Windows Media**

For more information about Windows Media, see page 50.

manage video clips

Manage video clips:

Press **Start** > **Pictures & Videos**

For more information about Windows Media, see page 50.

start web-browser

Press **Start** > **Internet Explorer**

For more information about Internet Explorer Mobile, see page 51.



features

download objects from web page



Download a picture, sound, or phone theme from a Web page:

Highlight the file, press the **Select** key, press the **Store** key.

Note: Normal airtime and/or carrier usage charges apply.

disconnect web sessions



Press the **End Session** key.

additional information

Need additional assistance or more documentation? See the following websites:

Motorola Q Support Website:

www.motorola.com/support/Q

Microsoft Windows Mobile Websites:

Windows Smartphone Support

<http://www.microsoft.com/windowsmobile/smartphone/default.aspx>

Virtual Private Network and ActiveSync

<http://download.microsoft.com/download/ad/1/c/5/1c541c3d-c8c7-4899-81fd-1b8e9bac09ed/readme.doc>

service & repair

If you have questions or need assistance, we're here to help.

Go to www.motorola.com/support/Q, where you can select from a number of customer care options. You can also contact the Motorola Customer Support Center at 1-800-657-7576 (United States), 1-888-390-6456 (TTY/TDD United States for hearing impaired), or 1-800-461-4575 (Canada).

Specific Absorption Rate Data

This model meets international guidelines for exposure to radio waves.

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The ICNIRP SAR limit for mobiles devices used by the general public is 2 W/kg and the highest SAR value for this device when tested at the ear was ____ W/kg.¹ As

mobile devices offer a range of functions, they can be used in other positions, such as on the body as described in this user guide.² In this case, the highest tested SAR value is ____ W/kg.¹

As SAR is measured utilizing the device's highest transmitting power, the actual SAR of this device while operating is typically below that indicated above. This is due to automatic changes to the power level of the device to ensure it only uses the minimum level required to reach the network.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.

Specific Absorption Rate Data

THIS MODEL MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government and by the Canadian regulatory authorities. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age or health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC and by the Canadian regulatory authorities is 1.6 W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC and by Industry Canada with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station, the lower the power output.

Before a phone model is available for sale to the public in the U.S. and Canada, it must be tested and certified to the FCC and Industry Canada that it does not exceed the limit established by each government for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) reported to the FCC and available for review by Industry Canada. The highest SAR value for this model phone when tested for use at the ear is 1.11 W/kg, and when worn on the body, as described in this user guide, is 1.47 W/kg. (Body-worn measurements differ among phone models, depending upon available accessories and regulatory requirements).²

While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.

The World Health Organisation has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. They note that if you want to reduce your exposure then you can do so by limiting the length of calls or using a 'hands-free' device to keep the mobile phone away from the head and body.

Additional Information can be found on the websites of the World Health Organisation (<http://www.who.int/emf>) or Motorola, Inc. (<http://www.motorola.com/rfhealth>).

- * The tests are carried out in accordance with international guidelines for testing. The limit incorporates a substantial margin for safety to give additional protection for the public and to account for any variations in measurements. Additional related information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.
- ** Please see the Safety and General Information section about body worn operation.

Information from the World Health Organization

Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If you are concerned, you may want to limit your own or your children's RF exposure by limiting the length of calls or by using handsfree devices to keep mobile phones away from your head and body.

Source: WHO Fact Sheet 193

Further information: <http://www.who.int./peh-emf>

The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. They note that if you want to reduce your exposure then you can do so by limiting the length of calls or using a “hands-free” device to keep the mobile phone away from the head and body.

Additional Information can be found on the websites of the World Health Organization (<http://www.who.int/emf>) or Motorola, Inc. (<http://www.motorola.com/rfhealth>).

1. The tests are carried out in accordance with international guidelines for testing. The limit incorporates a substantial margin for safety to give additional protection for the public and to account for any variations in measurements. Additional related information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.
2. Please see the *Safety and General Information* section about body worn operation.

Microsoft End User License Agreement

You have acquired a device ("DEVICE") that includes software licensed by Motorola, Inc. ("Motorola") from one or more third-party licensors ("Licensor"), for use in connection with wireless network services provided under separate agreement between you and a wireless telecommunications provider ("Mobile Operator"). Those installed software products provided by Licensor, as well as associated media, printed materials, and "online" or electronic documentation ("SOFTWARE") are protected by international intellectual property laws and treaties. SOFTWARE includes software already installed on the DEVICE ("DEVICE Software") and Licensor software contained on any CD-ROM disk accompanying the DEVICE ("Desktop Software").

The SOFTWARE is licensed, not sold. All rights reserved.

IF YOU DO NOT AGREE TO THIS END USER LICENSE AGREEMENT ("EULA"), DO NOT USE THE DEVICE OR COPY THE SOFTWARE. INSTEAD, PROMPTLY CONTACT MOTOROLA FOR INSTRUCTIONS ON RETURN OF THE UNUSED DEVICE(S) FOR A REFUND. ANY USE OF THE SOFTWARE, INCLUDING BUT NOT LIMITED TO USE ON THE DEVICE, WILL CONSTITUTE YOUR AGREEMENT TO THIS EULA (OR RATIFICATION OF ANY PREVIOUS CONSENT).

1. GRANT OF SOFTWARE LICENSE. This EULA grants you the following license:

1.1. DEVICE Software. You may use the DEVICE Software as installed on the DEVICE (including as installed on removable media installed in the DEVICE). All or certain portions of the DEVICE Software may be inoperable if a proper account is not established or maintained with an appropriate Mobile Operator, or if the Mobile Operator's network

facilities are not operating or configured to operate with the DEVICE software.

1.2. Desktop Software. If Desktop Software is included with your DEVICE, you may install and use the Desktop Software on one (1) or more computers to exchange information with one (1) or more computing devices that contain a compatible version of the DEVICE Software. For other software component(s) contained in the Desktop Software, you may install and use such components only in accordance with the terms of the printed or online end user license agreement(s) provided with such component(s). In the absence of an end user license agreement for particular component(s) of the Desktop Software, you may install and use only one (1) copy of such component(s) on the DEVICE or a single computer with which you use the DEVICE.

1.3. Back-up Copy. If Motorola has not included a back-up copy of the DEVICE Software with the DEVICE, you may make a single back-up copy of the

DEVICE Software. You may use the back-up copy solely for archival purposes.

1.4. Microsoft Windows® 2003. If Microsoft Outlook® 2002 is included with your Device, the following terms apply to your use of Microsoft Outlook® 2002: (i) regardless of the information contained in "Software Installation and Use" section of the online EULA you may install one (1) copy of Microsoft Outlook® 2002 on one (1) computer to use, exchange data, share data, access and interact with the DEVICE, and (ii) the EULA for Microsoft Outlook® 2002 is between Motorola and the end user - not between the PC manufacturer and end user.

2. Speech/Handwriting Recognition. If the Software includes speech and or handwriting recognition component(s), you should understand that speech and handwriting recognition are inherently statistical processes; that recognition errors are inherent in the processes; that it is your responsibility to provide for handling such errors and to monitor the recognition processes and correct any errors. Motorola, its

affiliates, subsidiaries, or suppliers shall not be liable for any damages arising out of errors in the speech and handwriting recognition processes.

3. Limitations on Reverse Engineering, Decompilation and Disassembly. You may not reverse engineer, decompile, or disassemble the SOFTWARE, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation.

4. Single DEVICE. The Device Software is licensed with the DEVICE as a single integrated product. The DEVICE Software may only be used as part of the DEVICE, notwithstanding any installation of the DEVICE Software on removable media.

5. Single EULA. The package for the DEVICE may contain multiple versions of this EULA, such as multiple translations and/or multiple media versions (e.g., in the user documentation and in the software). Even if you receive multiple versions of the EULA, you are licensed to use only one (1) copy of the DEVICE Software.

6. Rental. You may not rent or lease the SOFTWARE.

7. Software Transfer. You may not permanently transfer any of your rights under this EULA with regard to the DEVICE Software or Desktop Software, except as permitted by the applicable Mobile Operator. In the event that the Mobile Operator permits such transfer, you may permanently transfer all of your rights under this EULA only as part of a sale or transfer of the DEVICE, provided you retain no copies, you transfer all of the SOFTWARE (including all component parts, the media and printed materials, any upgrades or backup copies, this EULA and, if applicable, the Certificate(s) of Authenticity), and the recipient agrees to the terms of this EULA. If the Software is an upgrade, any transfer must include all prior versions of the SOFTWARE.

8. Termination. Without prejudice to any other rights, Motorola, Licensor and their affiliates and subsidiaries may terminate this EULA if you fail to comply with the terms and conditions of this EULA. In

such event, you must destroy all copies of the SOFTWARE and all of its component parts.

9. Security Updates. The SOFTWARE may include digital rights management technology. If SOFTWARE does contain digital rights management technology, content providers are using the digital rights management technology ("Licensor DRM") contained in the SOFTWARE to protect the integrity of their content ("Secure Content") so that their intellectual property, including copyright, in such content is not misappropriated. Owners of such Secure Content ("Secure Content Owners") may, from time to time, request Licensor, or its subsidiaries or affiliates to provide security related updates to the Licensor DRM components of the SOFTWARE ("Security Updates") that may affect your ability to copy, display and/or play Secure Content through Licensor software or third party applications that utilize Licensor DRM. You therefore agree that, if you elect to download a license from the Internet which enables your use of Secure Content, Licensor, its subsidiaries or affiliates may, in conjunction with such license, also download

onto your DEVICE such Security Updates that a Secure Content Owner has requested that Licensor, its subsidiaries or affiliates, to distribute. Licensor, its subsidiaries or affiliates will not retrieve any personally identifiable information, or any other information, from your DEVICE by downloading such Security Updates.

10. Consent to Use of Data. You agree that Licensor, its subsidiaries and affiliates may collect and use technical information gathered in any manner as part of product support services related to the SOFTWARE.. Licensor, its subsidiaries and affiliates may use this information solely to improve their products or to provide customized services or technologies to you. Licensor, its affiliates and subsidiaries may disclose this information to others, but not in a form that personally identifies you.

11. Internet Gaming/Update Features. If the SOFTWARE provides, and you choose to utilize, the Internet gaming or update features within the SOFTWARE, it is necessary to use certain computer

system, hardware, and software information to implement the features. By using these features, you explicitly authorize Licensor, its subsidiaries and affiliates, and/or their designated agent to use this information solely to improve their products or to provide customized services or technologies to you. Licensor, its subsidiaries and affiliates may disclose this information to others, but not in a form that personally identifies you.

12. Internet-Based Services Components. The SOFTWARE may contain components that enable and facilitate the use of certain Internet-based services. You acknowledge and agree that Licensor, its affiliates and subsidiaries may automatically check the version of the SOFTWARE and/or its components that you are utilizing and may provide upgrades or supplements to the SOFTWARE that may be automatically downloaded to your Device.

13. Links to Third Party Sites. The SOFTWARE may provide you with the ability to link to third party sites through the use of the SOFTWARE. The third party

sites are NOT under the control of Motorola, Licensor, or their affiliates or subsidiaries. Neither Motorola, Licensor, nor their affiliates or subsidiaries are responsible for (i) the contents of any third party sites, any links contained in third sites, or any changes or updates to third party sites, or (ii) webcasting or any other form of transmission received from any third party sites. If the SOFTWARE provides links to third party sites, those links are provided to you only as a convenience, and the inclusion of any link does not imply an endorsement of the third party site by Motorola, Licensor, or their affiliates or subsidiaries.

14. Additional Software/Services. The SOFTWARE may permit Motorola, Licensor, their affiliates or subsidiaries to provide or make available to you SOFTWARE updates, supplements, add-on components, or Internet-based services components of the SOFTWARE after the date you obtain your initial copy of the SOFTWARE ("Supplemental Components").

14.1. If Motorola, or its subsidiaries or affiliates, provides or makes available to you Supplemental Components and no other EULA terms are provided along with the Supplemental Components, then the terms of this EULA shall apply.

14.2. If Licensor, or its affiliates or subsidiaries, make available Supplemental Components, and no other EULA terms are provided, then the terms of this EULA shall apply, except that the Licensor, or its affiliates or subsidiaries providing the Supplemental Component(s) shall be the licensor of the Supplemental Component(s).

14.3. Motorola, Licensor, and their affiliates and subsidiaries reserve the right to discontinue any Internet-based services provided to you or made available to you through the use of the SOFTWARE.

15. UPGRADES AND RECOVERY MEDIA.

15.1. DEVICE Software. If the DEVICE Software is provided by Motorola, its subsidiaries or affiliates, separate from the DEVICE on media such as a ROM chip, CD ROM disk(s) or via web download or other

means, and is labeled "For Upgrade Purposes Only" or "For Recovery Purposes Only", you may install one copy of such DEVICE Software on the DEVICE as a replacement copy for the existing DEVICE Software and use it in accordance with the Grant of Software License section of this EULA.

15.2. Desktop Software. If any Desktop Software component(s) is provided by Motorola, its subsidiaries or affiliates, separate from the DEVICE on CD ROM disk(s) or via web download or other means, and labeled "For Upgrade Purposes Only" or "For Recovery Purposes Only", you may (i) install and use one copy of such component(s) on the computer(s) you use to exchange data with the DEVICE as a replacement copy for the existing Desktop Software component(s).

16. COPYRIGHT. All title and intellectual property rights in and to the SOFTWARE (including but not limited to any images, photographs, animations, video, audio, music, text and "applets", incorporated into the SOFTWARE), the accompanying printed

materials, and any copies of the SOFTWARE, are owned by Motorola, Licensor, and/or their affiliates, subsidiaries, or suppliers. You may not copy the printed materials accompanying the SOFTWARE. All title and intellectual property rights in and to the content which may be accessed through use of the SOFTWARE is the property of the respective content owner and may be protected by applicable copyright or other intellectual property laws and treaties. This EULA grants you no rights to use such content. All rights not specifically granted under this EULA are reserved by Motorola, Licensor, their affiliates, subsidiaries, and suppliers.

17. EXPORT RESTRICTIONS. You acknowledge that SOFTWARE is subject to U.S. export jurisdiction. You agree to comply with all applicable international and national laws that apply to the SOFTWARE, including the U.S. Export Administration Regulations, as well as end-user, end-use and destination restrictions issued by U.S. and other governments.

18. PRODUCT SUPPORT. Product support for the SOFTWARE is NOT provided by Licensor, its parent corporation, or their affiliates or subsidiaries.

19. NO LIABILITY FOR CERTAIN DAMAGES. EXCEPT AS PROHIBITED BY LAW, MOTOROLA, LICENSOR, AND THEIR AFFILIATES AND SUBSIDIARIES, SHALL HAVE NO LIABILITY FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES ARISING FROM OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE SOFTWARE. THIS LIMITATION SHALL APPLY EVEN IF ANY REMEDY FAILS OF ITS ESSENTIAL PURPOSE.

20. FOR APPLICABLE LIMITED WARRANTIES AND SPECIAL PROVISIONS PERTAINING TO YOUR PARTICULAR JURISDICTION, PLEASE REFER TO YOUR WARRANTY BOOKLET INCLUDED WITH THIS PACKAGE OR PROVIDED WITH THE SOFTWARE PRINTED MATERIALS.

DRAFT



MOTOROLA

Important Safety and Legal Information

Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Manual Number: 6809497A59-0

Safety and General Information

This section contains important information on the safe and efficient operation of your mobile device. Read this information before using your mobile device.*

Exposure To Radio Frequency (RF) Energy

Your mobile device contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate with your mobile device, the system handling your call controls the power level at which your mobile device transmits.

* The information provided in this document supersedes the general safety information in user's guides published prior to September 1, 2005.

Your Motorola mobile device is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

Operational Precautions

For optimal mobile device performance and to be sure that human exposure to RF energy does not exceed the guidelines set forth in the relevant standards, always follow these instructions and precautions.

External Antenna Care

If your mobile device has an external antenna, use only a Motorola-supplied or approved replacement antenna. Use of unauthorized antennas, modifications, or attachments could damage the mobile device and/or may result in your device not

complying with local regulatory requirements in your country.

DO NOT hold the external antenna when the mobile device is IN USE. Holding the external antenna affects call quality and may cause the mobile device to operate at a higher power level than needed.

Product Operation

When placing or receiving a phone call, hold your mobile device just like you would a landline phone.

If you wear the mobile device on your body, always place the mobile device in a Motorola-supplied or approved clip, holder, holster, case, or body harness. If you do not use a body-worn accessory supplied or approved by Motorola, keep the mobile device and its antenna at least 2.5 centimeters (1 inch) from your body when transmitting.

When using any data feature of the mobile device, with or without an accessory cable, position the mobile device and its antenna at least 2.5 centimeters (1 inch) from your body.

Using accessories not supplied or approved by Motorola may cause your mobile device to exceed RF energy exposure guidelines. For a list of Motorola-supplied or approved accessories, visit our website at www.motorola.com.

RF Energy Interference/Compatibility

Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances your mobile device may cause interference with other devices.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Follow Instructions to Avoid Interference Problems

Turn off your mobile device in any location where posted notices instruct you to do so. These locations include hospitals or health care facilities that may be using equipment that is sensitive to external RF energy.

In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an airplane mode or similar feature, consult airline staff about using it in flight.

Pacemakers

If you have a pacemaker, consult your physician before using this device.

Persons with pacemakers should observe the following precautions:

- ALWAYS keep the mobile device more than 20 centimeters (8 inches) from your

pacemaker when the mobile device is turned ON.

- DO NOT carry the mobile device in the breast pocket.
- Use the ear opposite the pacemaker to minimize the potential for interference.
- Turn OFF the mobile device immediately if you have any reason to suspect that interference is taking place.

Hearing Aids

Some digital mobile devices may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer or physician to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult your physician or the manufacturer of your device to determine if it is adequately shielded from RF energy.

Driving Precautions

Check the laws and regulations on the use of mobile devices in the area where you drive. Always obey them.

When using your mobile device while driving, please:

- Give full attention to driving and to the road. Using a mobile device may be distracting. Discontinue a call if you can't concentrate on driving.
- Use handsfree operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.

Responsible driving practices can be found in the "Smart Practices While Driving" section at the end of this guide and/or at the Motorola website:

www.motorola.com/callsmart.

Operational Warnings

Obey all posted signs when using mobile devices in public areas, such as health care facilities or blasting areas.

Automobile Air Bags

Do not place a mobile device in the air bag deployment area.

Potentially Explosive Atmospheres

Areas with potentially explosive atmospheres are often but not always posted, and can include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain, dust, or metal powders.

When you are in such an area, turn off your mobile device, and do not remove, install, or charge batteries. In such areas, sparks can occur and cause an explosion or fire.

Damaged Products

If your mobile device or battery has been submerged in water, punctured, or subjected to a severe fall, do not use it until you take it to a Motorola Authorized Service Center. Do not attempt to dry it with an external heat source, such as a microwave oven.

Batteries and Chargers

If jewelry, keys, beaded chains, or other conductive materials touch exposed battery terminals, this could complete an electrical circuit (short circuit), become very hot, and could cause damage or injury. Be careful when handling a charged battery, particularly when placing it inside a pocket, purse, or other container with metal objects. **Use only Motorola Original™ batteries and chargers.**

Caution: To avoid risk of personal injury, do not dispose of your battery in a fire.

Your battery, charger, or mobile device may contain symbols, defined as follows:

Symbol	Definition
	Important safety information follows.
	Do not dispose of your battery or mobile device in a fire.
	Your battery or mobile device may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
	Do not throw your battery or mobile device in the trash.
	Your mobile device contains an internal lithium ion battery.

Choking Hazards

Your mobile device or its accessories may include detachable parts, which may present a choking

hazard to small children. Keep your mobile device and its accessories away from small children.

Glass Parts

Some parts of your mobile device may be made of glass. This glass could break if the product is dropped on a hard surface or receives a substantial impact. If glass breaks, do not touch or attempt to remove. Stop using your mobile device until the glass is replaced by a qualified service center.

Seizures/Blackouts

Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when playing video games. These may occur even if a person has never had a previous seizure or blackout.

If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult with your physician before playing video

games or enabling a flashing-lights feature (if available) on your mobile device.

Discontinue use and consult a physician if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. It is always a good idea to hold the screen away from your eyes, leave the lights on in the room, take a 15-minute break every hour, and stop use if you are very tired.

Repetitive Motion

When you repetitively perform actions such as pressing keys or entering finger-written characters, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. If you continue to have discomfort during or after such use, stop use and see a physician.

Motorola Limited Warranty for the United States and Canada

What Does this Warranty Cover?

Subject to the exclusions contained below, Motorola, Inc. warrants its telephones, pagers, messaging devices, and consumer and professional two-way radios (excluding commercial, government or industrial radios) that operate via Family Radio Service or General Mobile Radio Service, Motorola-branded or certified accessories sold for use with these Products ("Accessories") and Motorola software contained on CD-ROMs or other tangible media and sold for use with these Products ("Software") to be free from defects in materials and

workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola Products, Accessories and Software purchased by consumers in the United States or Canada, which are accompanied by this written warranty:

Products and Accessories

Products Covered	Length of Coverage
Products and Accessories as defined above, unless otherwise provided for below.	One (1) year from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.
Decorative Accessories and Cases. Decorative covers, bezels, PhoneWrap™ covers and cases.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.

Products Covered	Length of Coverage
Monaural Headsets. Ear buds and boom headsets that transmit mono sound through a wired connection.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.
Consumer and Professional Two-Way Radio Accessories.	Ninety (90) days from the date of purchase by the first consumer purchaser of the product.
Products and Accessories that are Repaired or Replaced.	The balance of the original warranty or for ninety (90) days from the date returned to the consumer, whichever is longer.

Exclusions

Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola, are excluded from coverage.

Use of Non-Motorola Products and Accessories. Defects or damage that result from

the use of Non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage.

Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products Accessories or Software is excluded from coverage.

Software

Products Covered	Length of Coverage
Software. Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk).	Ninety (90) days from the date of purchase.

Exclusions

Software Embodied in Physical Media. No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

Software NOT Embodied in Physical Media.

Software that is not embodied in physical media (e.g. software that is downloaded from the internet), is provided "as is" and without warranty.

Who Is Covered?

This warranty extends only to the first consumer purchaser, and is not transferable.

What Will Motorola Do?

Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

How to Obtain Warranty Service or Other Information

USA	Phones 1-800-331-6456 Pagers 1-800-548-9954 Two-Way Radios and Messaging Devices 1-800-353-2729
Canada	All Products 1-800-461-4575
TTY	1-888-390-6456
For Accessories and Software , please call the telephone number designated above for the product with which they are used.	

You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS

LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights,

and you may also have other rights that vary from state to state or from one jurisdiction to another.

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce and distribute copies of the Motorola software. Motorola software may only be copied into, used in, and redistributed with, the Products associated with such Motorola software. No other use, including without limitation disassembly of such Motorola software or exercise of the exclusive rights reserved for Motorola, is permitted.

Hearing Aid Compatibility with Mobile Phones

Some Motorola phones are measured for compatibility with hearing aids. If the box for your particular model has “Rated for Hearing Aids” printed on it, the following explanation applies.

When some mobile phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed ratings for some of their mobile phones, to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label on the box.

The ratings are not guarantees. Results will vary depending on the user’s hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device’s telecoil (“T Switch” or “Telephone Switch”) than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find results for your hearing device. The more immune your hearing aid is, the less likely you are to experience interference noise from mobile phones.

Information from the World Health Organization

Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If you are concerned, you may want to limit your own or your children's RF exposure by limiting the length of calls or by using handsfree

devices to keep mobile phones away from your head and body.

Source: WHO Fact Sheet 193

Further information:

<http://www.who.int./peh-emf>

Product Registration

Online Product Registration:

<http://www.motorola.com/warranty>

Product registration is an important step toward enjoying your new Motorola product. Registering helps us facilitate warranty service, and permits us to contact you should your product require an update or

other service. Registration is for U.S. residents only and is not required for warranty coverage.

Please retain your original dated sales receipt for your records. For warranty service of your Motorola Personal Communications Product you will need to provide a copy of your dated sales receipt to confirm warranty status.

Thank you for choosing a Motorola product.

Export Law Assurances

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation or

re-exportation of this product to certain destinations. For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

Wireless: The New Recyclable

Your wireless phone can be recycled. Recycling your wireless phone reduces the amount of waste disposed in landfills and allows recycled materials to be incorporated into new products.

The Cellular Telecommunications Industry Association (CTIA) and its members encourage

consumers to recycle their phones and have taken steps to promote the collection and environmentally sound recycling of end-of-life wireless devices.

As a wireless phone user, you have an important role in ensuring that this phone is recycled properly. When it comes time to give this phone up or trade it

in for a new one, please remember that the phone, the charger, and many of its accessories can be recycled. It's easy. To learn more about CTIA's Recycling Program for Used Wireless Devices, please visit us at <http://promo.motorola.com/recycle/phones/whyrecycle.html>

Smart Practices While Driving

Drive Safe, Call Smart SM

Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas. Contact www.motorola.com/callsmart for more information.

Your mobile device lets you communicate by voice and data—almost anywhere, anytime, wherever wireless service is available and safe conditions allow. When driving a car, driving is your first responsibility. If you choose to use your mobile device while driving, remember the following tips:

- **Get to know your Motorola mobile device and its features such as speed dial and redial.** If available, these features

help you to place your call without taking your attention off the road.

- **When available, use a handsfree device.** If possible, add an additional layer of convenience to your mobile device with one of the many Motorola Original™ handsfree accessories available today.
- **Position your mobile device within easy reach.** Be able to access your mobile device without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voicemail answer it for you.
- **Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.** Rain,

sleet, snow, ice, and even heavy traffic can be hazardous.

- **Do not take notes or look up phone numbers while driving.** Jotting down a “to do” list or going through your address book takes attention away from your primary responsibility—driving safely.
- **Dial sensibly and assess the traffic; if possible, place calls when your car is not moving or before pulling into traffic.** If you must make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
- **Do not engage in stressful or emotional conversations that may be distracting.** Make people you are talking with aware you are driving and suspend conversations that can divert your attention away from the road.
- **Use your mobile device to call for help.** Dial 911 or other local emergency number in

the case of fire, traffic accident, or medical emergencies.*

- **Use your mobile device to help others in emergencies.** If you see an auto accident, crime in progress, or other serious emergency where lives are in danger, call 911 or other local emergency number, as you would want others to do for you.*
- **Call roadside assistance or a special non-emergency wireless assistance number when necessary.** If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.*

* Wherever wireless phone service is available.

index

A

- accessibility 69
- accessories 10, 71
- accessory connector port 1, 2
- ActiveSync 19
- alarm 69
- alert
 - set 54
 - turn off 47, 50, 52, 59
- animation 75
- answer a call 13, 57
- attachments 27
- audio enhancement 51
- auto-lock
 - phone 17

- automatic email setup 22

B

- background 55
- backlight 57
- battery 11, 12
- battery indicator 41
- battery life, extending 10, 37, 57
- Bluetooth connection 68, 73
- Bluetooth wireless 37
- bonding. See Bluetooth wireless
- brightness 57
- browser 76
 - disconnect 76

C

- calculator 73
- calendar 72
- call
 - answer 13, 57
 - end 13
 - make 13, 66
- call timers 70, 71
- caller ID 61, 67
- camera 31, 33
- camera key 1, 2
- cancel message 26
- car kit 71
- center key 1, 2
- certificate management 74, 75

codes 16
contacts 62, 65
copy files 36, 38

D

data indicator 41
date, 55
datebook 72, 73
delete program 53
dial a phone number 13, 66
dialed calls 59
digit dial (voice) 48
display 40, 57
download email messages
29
download files 36
download message objects
28

E

email 21, 26, 27
 attachment 27
 signature 27
email address 65
emergency number 61
end a call 13
end key 1, 2, 13
enter
 numbers 14
 text 14
export regulations 106

F

file manager 52
filter 60
flight mode 50
forward 28

H

handsfree 71
handsfree speaker 48
headset 71
headset jack 1, 2
hearing aid compatibility 103
home screen 40, 55
hyperlink
 phone number 64

I

Incoming Call message 61
international access code 62
ISP 26
iTAP text entry mode 46

L

language 68
linking. See Bluetooth wire-
less

location indicator 42
lock
 phone 16
Low Battery message 41
lowercase 14

M

make a call 13, 66
make call 64
manual email setup 22
master reset 70
media player 69, 75
memory 16
memory card 16
menu 43
menu icons 40, 43
menu indicator 40
menu key 1, 2
message 26, 27, 28
message indicator 41

message reminders 69
messages 21, 26
 email 21
 text 21
missed call 60
Missed Calls message 60
MMS 16
MMS, defined 22, 25
mode
 flight 50
multimedia message 21, 27,
28
music 75

N

name dial 48
navigation key 1, 2, 9
network settings 72
number. See phone number
numbers 14

numeric entry mode 47

O

object exchange 38
open
 program 13
open program 13
operator hosted e-mail 22
optional accessory 10
optional feature 10
over the air (OTA) 18
owner information 70

P

pairing. See Bluetooth wire-
less
personalize 68
phone 17
phone number 14, 65
phonebook 64

photo 31, 75
picture 75
picture ID 61, 67
power key 1, 2, 13
priority 26
product registration 105
profile 54
program
 open 13

R

received calls 59
recent calls 59
recycling 106
redial 60
reminders 69
remove program 53
reply 28
return a call 60
ring style indicator 42

ring style, setting 54
ring tone 75
ringer ID 61, 66
ringer volume 68
roam indicator 41

S

safety information 91
safety tips 108
SD 16
security
 lock 17
send and receive messages
 24
send key 1, 2, 13
signal strength indicator 41
signature 27
smart key 1, 2, 15
soft keys 1, 2, 40
sounds 69, 75

speakerphone 71
speed dial 62, 64, 65
Start menu 9
store your number 14
symbol entry mode 47
sync (cable) 20
sync (infrared) 21
synch (Bluetooth) 20
synchronize 18
synchronizing with computer
 18

T

task manager 52
telephone number. See
phone number
text 14
text entry 45
text message 26, 27, 28
thumb wheel 42

time, setting 55
timers 59, 70, 71
TTY calls 64
turn on/off 13

U

unlock
 phone 16, 17
unlock code 16
uppercase 14

V

video 75
video clip 33
voice commands 48
voice key 1, 2
voice recognition 48
voicemail 62
voicemail message indicator
41, 63

volume 47, 68
volume keys 1, 2

W

wallpaper 55
warranty 97
web 76
 phone number 64
web browser 75, 76
 disconnect 76
web page 75
WHO information 105

Y

your phone number 14

U.S. patent Re. 34,976

