



ACTIVE NOISE CANCELLING TWS Earbuds



Introduction

Thank you for purchasing the Muze Active Noise Cancelling TWS Earbuds, item MUZ3O1O. You can pair your phone and other Bluetooth devices to stream music wirelessly. Please read this manual first before using the earbuds.

Important Safety Precautions

When using your Active Noise Cancelling TWS Earbuds, basic safety precautions should always be followed including:

1. Do not allow children to play with the earbuds and charging case without adult supervision.
2. Do not use or put the earbuds and charging case near water, in wet conditions, or on wet surfaces.
3. Do not expose the earbuds or charging case to excessive heat, fire, or direct sunlight. Do not expose the earbuds or charging case to temperatures above 100° F.
4. The earbuds and charging case should not be handled roughly.
5. Do not use in extremely dry environments. This can lead to static discharge during usage.
6. Do not tamper with the electrical housing of the charging case.
7. Do not attempt to repair this product yourself. Contact a qualified service center if your earbuds and charging case are in need of service.
8. Do not drop, throw, or expose your earbuds and charging case to extreme physical force.
9. The earbuds and charging case is not intended for commercial use.
10. Do not place these products near objects that generate a strong magnetic field.
12. Never use any harsh chemicals or detergents to clean the exterior of the earbuds and charging case.
13. Please recycle or dispose of the earbuds and charging case properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your earbuds and charging case for further information.

Package Contents

- Active Noise Cancelling TWS Earbuds
- USB-C Charging Cable
- User's Manual with Warranty Information

Specifications

Bluetooth Specification: V5.0

Bluetooth Range: Up to 30 feet

Power Supply: DC 5V/400mA

Charging Time: 2 Hours

Play Time: 5 Hours*


*Applicable at 50% of maximum volume. Results will be lower when volume is higher.



BATTERY WARNING:

- The device is equipped with an integrated lithium battery. The battery cannot be replaced. Do not attempt to remove the battery from the device.
- Do not dispose of in fire or expose to excessive heat.
- Do not crush, puncture, incinerate, or short circuit external contacts.
- Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.

Charging the Earbuds




Using the included charging cable, connect the standard USB end into a wall adapter (not included) or into a computer. Insert the cable's USB-C end into the charging port on the side of the charging case.

The earbud's LED Indicator will illuminate red when charging and turn off when charging is complete.

The charging case's LED Indicator will flash blue when charging, and all four lights will illuminate solid blue when charging is complete.

● (red) = Charging
○ (off) = Charging complete



Bluetooth Pairing

Take the earbuds out of the charging case to turn the On. On your phone, go into the Bluetooth page in the Settings app. Make sure Bluetooth is turned on before connecting to the available device 'MUZ3O1O'.



Earbud Controls

Multi-function Button



- ▶|| Press either earbud's multi-function button to pause and play music.
- ▶▶ 🔊+ Press the left earbud's multi-function button twice to go to the next track. Press the button three times to increase the volume.
- ◀◀ 🔊- Press the right earbud's multi-function button twice to go to back to the previous track. Press the button three times to decrease the volume.
- 🔇 Press and hold either earbud's multi-function button for two seconds to turn Active Noise Cancelling On and Off and turn on transparency.
- 📞 Press either earbud's multi-function button to answer an incoming call. Press the button again to end the call.
- 🚫 Press and hold either earbud's multi-function button for two seconds to decline an incoming call.

Manual Reset

1. Turn bluetooth Off on your phone to disconnect the earbuds.
2. Take one earbud from charging case. After the LED Indicator alternately flashes red and blue, quickly press the button five times to turn the earbud Off.
3. Repeat this process for the second earbud.
4. When both earbuds have been reset, place them back into the charging case. When you take them back out they will be ready to use.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Vivitar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call 1-800-592-9541 or visit our website at www.vivitar.com.

To receive warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaid.

Vivitar One Year Warranty (continued)

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR INT. BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

