



Wireless Activity Wristband



Product Manual
Version 1.0

TABLE OF CONTENTS

Getting Started	1
Welcome	1
What's included	1
How to put on your Charge	1
Setting up Fitbit Charge Using a Computer	3
Mac & PC requirements	3
Installing Fitbit Connect on a computer	3
Mac installation	3
PC installation	3
Pairing to a computer	4
Wireless sync to a computer	4
Setting up Fitbit Charge Using a Mobile Device.....	6
Mobile device requirements.....	6
Installing the Fitbit app	6
iOS pairing	6
iOS syncing	7
Manual sync	7
Real-time dashboard.....	7
All-day sync	8
Android pairing	8
Android syncing	9
Tap to open app using Near-Field Communication (NFC)	10
Manual sync	10

Background sync	10
Tracking with Fitbit Charge	11
Tracking sleep with Charge	11
Tracking sleep on your mobile device.....	12
Tracking goals with Charge	12
Tracking activities with Charge	13
Wearing your Fitbit Charge.....	14
Wearing on your dominant vs. non-dominant wrist	14
Using your Charge in wet conditions	14
Silent Alarms.....	15
Setting silent alarms from a computer	15
Setting silent alarms from an iOS device	15
Setting silent alarms from an Android device.....	16
Dismissing silent alarms.....	16
Caller ID.....	17
Battery Life and Power.....	18
Battery life.....	18
Charging your Charge	18
Memory.....	19
Your Fitbit.com Dashboard.....	20
Browser requirements	20
Using your dashboard	20
Logging food, activities, and sleep	20
Device info.....	21
Managing your Charge from Fitbit.com	21

Updating Fitbit Charge	22
Updating Charge on a computer	22
Updating Charge on an iOS device	22
Updating Charge on an Android device	23
Fitbit Charge General Info & Specifications	24
Sensors and motors	24
Size	24
Environmental conditions	24
Help	25
Return policy and warranty	25
Regulatory & Safety Notices	26
USA and Canada	26
European Union	27
Australia and New Zealand	27
Singapore	27
Israel	Error! Bookmark not defined.
Korea	Error! Bookmark not defined.
Mexico	Error! Bookmark not defined.
Russia	28
South Africa	Error! Bookmark not defined.
Taiwan	Error! Bookmark not defined.
United Arab Emirates	Error! Bookmark not defined.
China	Error! Bookmark not defined.
Disposal and Recycling Information	29
Important Safety Instructions	30

Cautions 30

Care and Wearing Tips 30

Built-In Battery Precautions 31

GETTING STARTED

WELCOME

Welcome to Fitbit Charge, the high-performance wristband tracker that helps you meet your fitness goals.

WHAT'S INCLUDED

Your Fitbit Charge Wireless Activity + Sleep Wristband box includes:



Charge wristband



Charging cable




Wireless sync
dongle

HOW TO PUT ON YOUR CHARGE

1. Put on the wristband so the screen is closest to the outside of your wrist and facing you.
2. Align both ends of the wristband so they are directly overlapping each other with the clasp over the two holes that best fit your wrist.

FPO (adding illustration)

3. Squeeze both the clasp and the wristband between your thumb and forefinger until you hear a soft click.



You'll know your Charge wristband is securely fastened if both pegs on the clasp are fully inserted.



NOTE: If you're having trouble, try securing the wristband off your wrist to get a feel for how it securely clasps and then try again on your wrist.

SETTING UP FITBIT CHARGE USING A COMPUTER

MAC & PC REQUIREMENTS



Software
Mac OS 10.5 or later
Internet Connection

Hardware
USB port



Software
Windows XP, Vista, 7, 8
Internet Connection

Hardware
USB port

INSTALLING FITBIT CONNECT ON A COMPUTER

Fitbit Connect is the software application that connects your Charge wristband to your Fitbit.com dashboard and services. It's free to download at Fitbit.com.

MAC INSTALLATION

1. Go to <http://www.fitbit.com/setup>.
2. Verify that Mac is highlighted and click the **Download Here** button below Charge.
3. Double-click the .dmg file in your Downloads folder.

NOTE: If the file does not appear on your desktop, search for "Fitbit Connect" using the Spotlight search feature.

4. Run the Fitbit Connect installation package by double-clicking **Install Fitbit Connect.pkg**.
5. Follow the onscreen instructions to complete setup.

PC INSTALLATION

1. Go to <http://www.fitbit.com/setup>.
2. Verify that PC is highlighted and click the **Download Here** button below Charge.
3. Go to your Downloads folder and double-click the **FitbitConnect_Win.exe** file.
4. Choose your language and follow the onscreen instructions.

PAIRING TO A COMPUTER

Once Fitbit Connect is installed on your computer, you can pair your Charge to your account. This will allow you to sync your data and manage device settings.

Onscreen setup instructions guide you through the pairing process. Use the following steps if the setup guide doesn't appear.

1. Mac users: On the Menu Bar of your Mac, click the Fitbit Connect icon and choose **Open Main Menu**.
PC users: In the Windows System Tray, right-click the Fitbit Connect icon and choose **Open Main Menu**.
2. From the main menu, select **Set Up a New Fitbit Device**.
3. Account Setup:
 - a. Select **New to Fitbit** to set up your device if you don't already have a Fitbit.com account.
 - b. Select **Existing User** to log into your existing Fitbit.com account and replace an existing device with your Charge.

NOTE: Only one Fitbit tracker can be paired to an account.

4. Enter or confirm your personal information and click **Next**. This information personalizes your Fitbit experience and improves the accuracy of your calorie burn and distance data. By default this personal information is visible only to your friends, but you can adjust your privacy settings from your Fitbit.com account to control what information is shared with others.
5. Choose **Charge** and follow the onscreen instructions to power on your Charge.
6. Insert the wireless sync dongle into your computer and click **Next**.
7. Fitbit Connect will search for your Charge. Once found, a four-digit number will appear on your Charge display. Enter this number where prompted and click **Next**.
8. You're all set. Follow the onscreen instructions to put on the wristband and view an introduction.

WIRELESS SYNC TO A COMPUTER

Wireless syncing to Fitbit.com is automatic, as long as:

- Your computer is powered on, awake, and connected to the internet
- The wireless sync dongle is plugged in
- Fitbit Connect is installed and running

When your Charge is within 15–20 feet of your computer, it will sync every 15 minutes.

You can manually sync your Charge by clicking on the Fitbit Connect icon that is located near the time and date on your computer. Select **Sync Now** to start the manual sync.

SETTING UP FITBIT CHARGE USING A MOBILE DEVICE

MOBILE DEVICE REQUIREMENTS

You can set up and sync your Charge using select mobile devices that support Bluetooth 4.0 technology. To see if your mobile device is compatible with your Charge, visit <http://www.fitbit.com/devices>.

NOTE: If your mobile device is not compatible to sync via Bluetooth 4.0, you can still use the Fitbit app to view your data and track your progress, you'll just need to set up and sync using a Mac or PC.

INSTALLING THE FITBIT APP

You can find the Fitbit app on the iOS App store or Google Play store by searching for "Fitbit." If you already have the Fitbit app installed, check for available updates to make sure you have the latest version.

IOS PAIRING

Unlike most Bluetooth accessories, like headsets, your Charge must be paired directly through the Fitbit app, not through the Settings app on your iOS device.

1. Open the Fitbit app.
2. Create an account:
 - a. Select **Join Fitbit** if you don't already have a Fitbit.com account.

NOTE: Click **Log In** if you're an existing Fitbit app user. Only one Fitbit tracker can be paired to an account.

If you're replacing an existing tracker, at the top of your dashboard tap **Charge** and then **Set Up a New Fitbit Device**.

(TBD – may be possible to pair two trackers at once)

- b. Tap Charge and then **Set up your Charge**.
 - c. On the next few screens enter your personal information. This personalizes your Fitbit experience and improves the accuracy of your

calorie burn and distance data. By default this personal information is visible only to your friends, but you can adjust your privacy settings on the Fitbit website to control what information is shared with others.

- d. Enter your name and the email address and password that you want to use for your Fitbit account.
3. Follow the onscreen prompts to power on your Charge. The app will begin searching for it.
4. Once the Charge is found, enter the four digits that appear on its display and click **Next**.
5. Once the Fitbit app shows the message “Your Charge is linked to Fitbit” you can tap **Next** to see an introduction to Charge.

NOTE: If you experience trouble pairing your Charge, you can get support at <http://help.fitbit.com>.

IOS SYNCING

Your Charge can sync directly to supported iOS devices via Bluetooth. To see if your iOS device is compatible with your Charge, go to <http://www.fitbit.com/devices>.

As long as Bluetooth is enabled in the iOS settings, syncing occurs automatically every time you open the app and when the app is running in the background on your device.

MANUAL SYNC

To initiate a manual sync while the app is already open, tap **Charge** at the top of your dashboard and tap the **Sync Now** icon.

REAL-TIME DASHBOARD

You can use the Fitbit app to see your stats update in real time. Open the Fitbit app. Once your Charge syncs, a message stating that the Charge is connected will appear at the top of the screen. Take a few steps to see your stats update instantly.

ALL-DAY SYNC

The Fitbit app also supports all-day sync. This setting allows your Charge to sync with your iOS device while the Fitbit app is running in the background. All-day sync is on by default.

To turn this setting on or off, tap Charge on your dashboard and adjust the All-Day Sync toggle as needed.

ANDROID PAIRING

Unlike most Bluetooth accessories, your Charge must be paired directly through the Fitbit app, and not through your Android device's Bluetooth preferences.

1. Open the Fitbit app.
2. Create an account:
 - a. Select **Set up** if you don't already have a Fitbit.com account.

NOTE: Are you an existing Fitbit app user? Only one Fitbit tracker can be paired to an account.

If you're replacing an existing tracker, log into your account and tap the **Menu button** > **Devices** > **Set up new device**.

(TBD – may be possible to pair two trackers at once)

- b. Tap Charge and then enter the email address and password for your Fitbit account.
 - c. Enter your personal details, then tap **Save**. This information personalizes your Fitbit experience and improves the accuracy of your calorie burn and distance data. By default this personal information is only visible to your friends, but you can adjust your privacy settings on the Fitbit website to control what information is shared with others.
3. Follow the onscreen prompts to power on your Charge. The app will begin searching for it.
4. Once the Charge is found, enter the four digits that appear on its screen and click **Next**.
5. Once the Fitbit app shows the message "Your Charge is linked to Fitbit" you can tap **Next** to see an introduction.

ANDROID SYNCING

Your Charge can sync directly to supported Android devices via Bluetooth. To check if your Android device is compatible with your Charge, see <http://www.fitbit.com/devices>.

Syncing will occur automatically when you open the Fitbit app if Bluetooth is enabled in both the Android device settings and the Fitbit app. To turn on Bluetooth in the Fitbit app, tap the **Menu** button > **Devices** > check **Use Bluetooth**.

TAP TO OPEN APP USING NEAR-FIELD COMMUNICATION (NFC)

Your Charge is equipped with Near-Field Communication (NFC) technology, allowing it to interact with Android devices that support this feature.

With the screen on and unlocked, hold your Android device to your Charge's display. You may need to adjust the location based on where your Android device's NFC chip is located.

After a moment, the Fitbit app will automatically open. If you haven't opened the Fitbit app recently, launching will automatically sync via Bluetooth.

MANUAL SYNC

To initiate a manual sync with your Charge and Fitbit.com:

1. Open the Fitbit app.
2. Tap the **Menu** button.
3. Tap **Devices**.

NOTE: Make sure Use Bluetooth is checked.

4. Tap **Charge**.
5. Tap the **Sync Now** icon.

BACKGROUND SYNC

The Fitbit app also supports background sync. This setting allows your Charge to sync with your Android device while the Fitbit app is in the background or minimized.

To turn on background sync, tap the **menu** button > **Devices** > **Charge** > **Background Sync**.

TRACKING WITH FITBIT CHARGE

Your Charge tracks:

- Steps taken
- Distance traveled
- Floors climbed
- Calories burned
- Hours slept
- Quality of sleep


To scroll through your stats simply press the button on the side of your Charge. You'll see the time followed by an icon and stat in turn. If you have an alarm set, your display will also show the next alarm time.



Time



Steps Taken



Distance Traveled



Floors Climbed



Calories Burned

TRACKING SLEEP WITH CHARGE

TBD – this section will change if autosleep is available at launch. To be determined in July.

Your Charge can track the hours you sleep and your movement during sleep to help you understand your sleep quality.

To enter sleep mode, press and hold the button on the side of your Charge. You'll feel a vibration and a stopwatch icon will appear, indicating that sleep mode has begun.

When you wake up, exit sleep mode by pressing and holding the button until it vibrates. Log into Fitbit.com and go to **Log > Sleep** or the sleep dashboard tile to view last night's sleep summary. You can also view the information on your mobile device.

If you forget to put your Charge into sleep mode, you can always enter your sleep time at <http://www.fitbit.com/sleep>.

TRACKING SLEEP ON YOUR MOBILE DEVICE

You can track your sleep using the Fitbit app on your mobile device.

To track sleep on your iOS device:

1. Open the Fitbit app.
2. Scroll down your dashboard and tap the sleep tile.
3. Tap the **+ button** in the top-right corner.
4. Tap **Begin Sleep Now**.

To track sleep on your Android device:

1. Open the Fitbit app.
2. Tap the **menu** in the top-left corner of the app.
3. Tap **Sleep**.
4. Tap the **+ button** in the top-right corner.
5. Tap **Begin Sleep Now**.

If you forget to track your sleep you can manually log it the next morning by following the steps above for tracking sleep on an iOS or Android device but choosing **Add Sleep Log** instead of **Begin Sleep Now**.

If you close the Fitbit app by pressing the home button, your sleep will continue to be tracked. When you awaken, just open the Fitbit app again and tap **I'm Awake**, then tap **View Summary** to see a summary of your sleep.

TRACKING GOALS WITH CHARGE

Your Charge is designed to track your progress towards a main goal that you define on your Fitbit.com dashboard. The goal can be set for steps taken, distance traveled, calories burned, or floors climbed. A progress bar below your goal keeps you motivated throughout the day. When you reach your goal your Charge will vibrate and flash to celebrate.

To choose the specific goal you want to track:

1. Log in to your Fitbit.com dashboard.
2. Click the **gear** icon in the top-right corner of the page.
3. Click **Settings**.
4. Click **Devices**.
5. Under Main Goal, choose the goal you would like to track on your Charge.
6. Sync your Charge to send the new goal to your tracker.

Once you've chosen which goal you want to track, you can set a specific value for that goal on the Fitbit.com dashboard page or using the Fitbit app for mobile. For example, instead of the default 10,000 steps per day, you may want your goal to be 15,000 per day. To change your goal value using your dashboard:

1. Log into your Fitbit.com dashboard.
2. Find the tile that corresponds to your goal.
3. Click the gear icon in the lower left corner of the tile.
4. Change your Daily Goal value.

TRACKING ACTIVITIES WITH CHARGE

Your Charge automatically tracks your steps taken, distance traveled, floors climbed, and calories burned throughout the day. Using the activity mode feature you can choose to track a specific activity in greater detail. Activity mode works similar to the trip mode on a car's odometer. For example, if you put your tracker in activity mode and go for a run, once you stop activity mode at the end of the run and sync your data, you'll see an entry on your activity log. The entry provides a summary of the activity's stats as well as a minute-by-minute graph.

To put your Charge in activity mode, press and hold the button until a stopwatch icon appears. When you finish the activity, press and hold the button again to turn off activity mode.

WEARING YOUR FITBIT CHARGE

Your Charge is designed to be most accurate when worn on your wrist.

WEARING ON YOUR DOMINANT VS. NON-DOMINANT WRIST

To get the most accurate reading from your Charge, you can configure whether you are wearing the wristband on your dominant or non-dominant wrist.

NOTE: Your dominant wrist is that which you use for most day-to-day activities, e.g., writing, washing dishes, or throwing a ball.

To configure this setting:

1. Log in to Fitbit.com.
2. Click the gear icon in the top-right corner of the dashboard.
3. Click **Settings**.
4. Click **Devices** on the left sidebar.
5. Under Dominant Hand choose the correct setting.

NOTE: Changes to this setting will not appear until you sync your Charge.

USING YOUR CHARGE IN WET CONDITIONS

Your Charge is water resistant. It should not be used while swimming but is splash, rain, and sweat-proof.

SILENT ALARMS

Your Charge gently vibrates to wake or alert you with its silent alarm feature. You can set alarms using your computer or a compatible mobile device.

Silent alarms can be configured to recur every day or on particular days of the week.

You can set up to eight alarms on your Charge.

NOTE: Setting multiple alarms may diminish the battery life of your Charge.

SETTING SILENT ALARMS FROM A COMPUTER

You can set silent alarms from your computer by using the Fitbit.com dashboard.

1. Log in to your Fitbit.com dashboard.
2. Click the **gear** icon in the top-right corner of the page.
3. Click **Settings**.
4. Click **Silent Alarms**.
5. Click the **Add Alarm** button.
6. Enter the time you want the alarm to alert you.
7. Choose how often you want the alarm to occur:
 - a. Once – Your alarm will alert you at the specified time and not repeat.
 - b. Repeats – Choose which days you want this alarm to repeat every week.
8. Click **Save**.

Your new alarm will be saved to your Charge the next time you sync your tracker. If you want to sync the alarm immediately, open Fitbit Connect and select **Sync Now**.

SETTING SILENT ALARMS FROM AN IOS DEVICE

To set silent alarms using the Fitbit app for iOS, Bluetooth must be enabled in your iOS Settings app.

Your iOS device also must support wireless sync. To see if your device is supported, go to <http://www.fitbit.com/devices>.

1. Open the Fitbit app.
2. Tap **Account**.
3. Tap **Silent Alarms**.
4. Tap **Add a new alarm**.

5. Set the time by adjusting the click-wheel.
6. If you prefer, tap the days of the week you want this alarm to repeat.
7. Tap **Save**.

Your iOS device will now sync the alarm to your Charge.

Make sure your Charge is nearby in order to sync your alarm. To manually sync the alarm, tap **Charge** at the top of your dashboard and then tap the **Sync Now** icon.

SETTING SILENT ALARMS FROM AN ANDROID DEVICE

To set silent alarms using the Fitbit app for Android, Bluetooth must be enabled in your Android device settings, as well as the Fitbit app Devices screen.

Your mobile device also must support Wireless Sync. To check if your device is supported, see <http://www.fitbit.com/devices>.

1. Open the Fitbit app.
2. Tap the **menu** button.
3. Tap **Devices**.
4. Choose **Charge**.
5. Tap **Silent Alarm**.
6. Tap **Add a new alarm**.
7. Tap **Next**.
8. Tap **Add a new alarm**.
9. Tap the **time** to enter a time.
10. If you prefer, tap the **Repeats** checkbox and tap the days of the week you want this alarm to repeat.
11. Tap **Done**.
12. Tap the **Sync tracker to save alarms** button.

NOTE: Make sure your Charge is nearby in order to sync your alarm. To manually sync the alarm, tap the **Menu button** > **Device Settings** > choose **Charge** > tap the **Sync Now** icon.

DISMISSING SILENT ALARMS

Your Charge will vibrate when your silent alarm goes off and the screen will flash. This notification will repeat several times until dismissed. You can dismiss the alarm by pressing the button on the side of the Charge. If you do not dismiss the alarm, it will repeat after nine minutes.

CALLER ID

With iPhone 4S and higher iOS devices using iOS 7, you can choose to receive incoming smart call notifications right on your Charge when your phone is within about 15 to 30 feet (5 to 10 meters).

When you receive a phone call, your Charge vibrates once and the incoming number or name (if the contact is in your address book) scrolls across the display. The notification scrolls for 10 seconds or until the call is answered. You can dismiss the notification at any time by pressing the button on your Charge.

To turn Caller ID on or off:

1. Open the Fitbit app on your iOS device.
2. Click **Charge** at the top of your dashboard.
3. Toggle **Caller ID** on or off.
4. The first time you turn on Caller ID, you'll receive a Bluetooth pairing request. Tap **Pair**.

BATTERY LIFE AND POWER

BATTERY LIFE


Your Charge contains a rechargeable lithium-polymer battery.

With normal use, your fully charged Charge should last about 7 to 10 days before needing a charge. You can check the level of your battery by logging into Fitbit.com and clicking the gear icon on the top-right corner of the page.

When you press the button on your Charge to cycle through your stats, the first screen will show a battery if there is approximately one day or less of battery life remaining.

CHARGING YOUR CHARGE

To charge your Charge, plug the charging cable into the USB port on your computer and plug the other end into the port on the back of the Charge.



Charging completely takes an average of one and a half to two hours.

MEMORY

When you sync your Charge, your activity data is uploaded to your Fitbit.com dashboard. Your Charge holds detailed minute-by-minute information for the most recent 7 days, and up to 30 days of daily activity summaries.

Your recorded data consists of steps taken, distance traveled, calories burned, floors climbed, and sleep tracked.

Sync your Charge regularly to have the most detailed data available to view on your Fitbit.com dashboard.

NOTE: Your Charge starts tracking your goal for the next day at 12:00AM for the time zone selected in your personal settings on your Fitbit.com account. You can adjust your time zone at <http://www.fitbit.com/user/profile/edit>.

Though your stats reset to zero at midnight this does not delete the previous day's data; that data will be uploaded to your Fitbit.com dashboard the next time you sync your Charge.

YOUR FITBIT.COM DASHBOARD

BROWSER REQUIREMENTS

BROWSER	MAC VERSION	WINDOWS VERSION
 Apple Safari	5.0.5 and higher	Not supported
 Google Chrome	12 and higher	12 and higher
 Microsoft Internet Explorer	Not supported	8 and higher
 Mozilla Firefox	3.6.18 and higher	3.6.18 and higher

USING YOUR DASHBOARD

Fitbit provides you with a free online tool to help track, manage, and evaluate your fitness progress.

When you log into Fitbit.com, you will automatically be taken to your dashboard. Your dashboard shows an overview of your progress towards your goals, as well as graphs with historical data.

LOGGING FOOD, ACTIVITIES, AND SLEEP

From your dashboard, you can launch individual log pages to keep track of your food, activities, sleep, and other custom trackers. Custom trackers are available to log anything we have not already provided a tracker for; for example, you may want to track how many sit-ups you do per day or how many caffeinated beverages you consume.

DEVICE INFO

You can see a quick preview of your tracker's last sync, battery level, and upcoming alarms if you click on the gear icon in the top-right corner of the page.

MANAGING YOUR CHARGE FROM FITBIT.COM

Manage your tracker from Fitbit.com by clicking the gear icon in the top-right corner of the page, clicking **Settings**, and choosing **Devices** from the left sidebar.

The Devices screen allows you to change:

- **Display Settings**: Hide and show items to customize what you see on your Charge's OLED display. You can also drag items up and down to change the order in which they appear.
- **Main Goal**: Choose which goal you want your Charge to track for you throughout the day. You can edit the value of this goal from the Fitbit.com dashboard or your mobile device using the Fitbit app.
- **Tap Gesture**: If you want your Charge to respond to taps, choose whether you want the clock or your main goal displayed when you double tap your Charge.
- **Clock Display**: Choose from four different clock styles.
- **Dominant Hand**: Choose which wrist you wear your Charge on to get the most accurate data readings. More information on this topic is located [here](#).
- **Sleep Tracking**: Set the sensitivity of your sleep tracking by changing this setting. The Normal setting is sufficient for most people. If you are a sound sleeper, you can choose Sensitive to capture the smallest movements of your body.

You can manage silent alarms by clicking **Silent Alarms** from the left sidebar.

NOTE: You must sync your Charge in order to apply any changed settings to your tracker.

UPDATING FITBIT CHARGE

Fitbit may release free updates for your Charge. You can update your Charge using Fitbit Connect on your computer or the Fitbit app on your mobile device.

We recommend that you keep your Charge up to date. The latest feature enhancements and product improvements are made through updates.

NOTE: Updating your Charge takes about 5 to 7 minutes and is demanding on the battery. We recommend that you charge your Charge prior to updating or while the update is in progress.

UPDATING CHARGE ON A COMPUTER

To update your Charge on a Mac or PC:

1. Click the **Fitbit Connect icon** near the time and date.
2. From the **Main Menu**, choose **Check for device update**.
3. **Log in** to your account using your Fitbit.com credentials. Fitbit Connect will now look for your Charge.

NOTE: Make sure your wireless sync dongle is plugged in.

4. If an update has been found for your Charge, Fitbit Connect will display a progress bar indicating that the update is in progress. Keep your Charge close to your computer while you perform the update.

You'll see a notification when the update completes.

If you have trouble updating your Charge on a computer, see <http://help.fitbit.com>.

UPDATING CHARGE ON AN IOS DEVICE

Your Charge can be updated using the Fitbit app for iOS if your iOS device is compatible with the wireless sync feature. To see if it is compatible, go to <http://www.fitbit.com/devices>.

1. Open the Fitbit app.
2. Tap your tracker name at the top of the app dashboard. If an update is available, the option Update Available will appear in pink toward the top of this screen.

3. Make sure your tracker remains near your iOS device while it updates. You can make your tracker easier to find by pressing its button to wake it up.

You'll see a notification when the update completes.

If you have trouble updating your Charge with the Fitbit app for iOS, see <http://help.fitbit.com> for more information.

UPDATING CHARGE ON AN ANDROID DEVICE

Your Charge can be updated using the Fitbit app for Android if your Android device is compatible with the wireless sync feature. To see if it is compatible, go to <http://www.fitbit.com/devices>.

- 1 Open the Fitbit App.
- 2 Tap the **Menu** button.
- 3 Tap **Devices**.

NOTE: Make sure Use Bluetooth is checked.

- 4 Tap **Charge**.
- 5 If there is an update available, tap the **Update Available** button at the top of this screen.

NOTE: Make sure your Charge remains near your Android device while finding and updating it.

- 6 When the update completes, the Fitbit app will say "You're all set!"

If you have trouble updating your Charge with the Fitbit app for Android, see <http://help.fitbit.com> for more information.

FITBIT CHARGE GENERAL INFO & SPECIFICATIONS

SENSORS AND MOTORS

Your Charge uses a MEMS 3-axis accelerometer that measures your motion patterns to determine your steps taken, distance traveled, calories burned, and sleep quality. Its altimeter also measures floors climbed. Charge also contains a vibration motor, which allows it to vibrate when alarms go off.

SIZE

	Length	Width
Small wristband	5.5 – 6.9 in 140 – 176 mm	20.9 mm
Large wristband	6.3 – 8.2 in 161 – 209 mm	20.9 mm

ENVIRONMENTAL CONDITIONS

Operating Temperature	–4° to 113° F (–20° to 45° C)
Non-operating Temperature	–22° to 140° F (–30° to 60° C)
Water Resistant	Device is splash proof
Maximum Operating Altitude	30,000 feet (9,144 m)

HELP

Troubleshooting and assistance for your Charge can be found at <http://help.fitbit.com>.

RETURN POLICY AND WARRANTY

Warranty information and the Fitbit.com Store Return Policy can be found online at <http://www.fitbit.com/returns>.

REGULATORY & SAFETY NOTICES

Model Name:

USA AND CANADA

This device complies with FCC Part 15 and Industry Canada license exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme à FCC Partie 15 d'Industrie Canada RSS standard exempts de licence (s). Son utilisation est soumise à Les deux conditions suivantes: (1) cet appareil ne peut pas provoquer d'interférences et (2) cet appareil doit accepter Toute interférence, y compris les interférences qui peuvent causer un mauvais fonctionnement du dispositif.

FCC Warning

Changes or modifications not expressly approved by Fitbit, Inc. could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device meets the FCC and IC requirements for RF exposure in public or uncontrolled environments.

Les changements ou modifications non expressément approuvés par la partie responsable de la conformité pourraient annuler l'autorité de l'utilisateur à utiliser cet équipement.

This device complies with Health Canada's Safety Code. The installer of this device should ensure that RF radiation is not emitted in excess of the Health Canada's requirement. Information can be obtained at http://www.hc-sc.gc.ca/ewh-sem/pubs/radiation/radio_guide-lignes_direct-eng.php

Cet appareil est conforme avec Santé Canada Code de sécurité 6. Le programme d'installation de cet appareil doit s'assurer que les rayonnements RF n'est pas émis au-delà de l'exigence de Santé Canada. Les informations peuvent être obtenues: http://www.hc-sc.gc.ca/ewhsemt/pubs/radiation/radio_guide-lignes_direct-eng.php

This Class B digital apparatus complies with CAN ICES-3 (B)/NMB-3(B).

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

EUROPEAN UNION

Declaration of Conformity with Regard to the EU Directive 1999/5/EC. Fitbit Inc. is authorized to apply the CE Mark on its product, thereby declaring conformity to the essential requirements and other relevant provisions of Directive 1999/5/EC and other applicable Directives.

Compliant with the standard R&TTE 99/CE/05

Conforme à la norme R&TTE 99/CE/05

The complete Declaration of Conformity can be found in the specific product section at help.fitbit.com/safety.

AUSTRALIA AND NEW ZEALAND



R-NZ

SINGAPORE

Complies with
IDA Standards
DA00006A

RUSSIA

EAC

DISPOSAL AND RECYCLING INFORMATION



The symbol on the product or its packaging signifies that this product must be disposed of separately from ordinary household wastes at its end of life. Please kindly be aware that it is your responsibility to dispose of electronic equipment at recycling centers to help conserve natural resources.

Each country in the European Union should have its collection centers for electrical and electronic equipment recycling. For information about your recycling drop off point, please contact your local related electrical and electronic equipment waste management authority or the retailer where you bought the product.

Le symbole sur le produit ou son emballage signifie que ce produit doit être traité séparément des déchets ménagers ordinaires à la fin de sa vie. S'il vous plaît être conscient qu'il est de votre responsabilité de vous débarrasser de l'équipement électronique dans les centres de recyclage pour aider à préserver les ressources naturelles.

Chaque pays de l'Union européenne devrait avoir ses centres de collecte pour le recyclage des équipements électriques et électroniques. Pour plus d'informations au sujet de votre point de recyclage point de départ, s'il vous plaît contactez votre autorité de gestion locale des déchets connexes équipements électriques et électroniques ou le détaillant où vous avez acheté le produit.

- Do not dispose of your Fitbit product with household waste
- Disposal of the packaging and your Fitbit product should be done in accordance with local regulations.
- Batteries are not to be disposed of in the municipal waste stream and require separate collection.



IMPORTANT SAFETY INSTRUCTIONS

CAUTIONS

- Prolonged contact may contribute to skin irritation or allergies in some users. If you notice any signs of skin redness, swelling, itchiness, or other skin irritation, please discontinue use or wear the product clipped over a piece of clothing. Continued use, even after symptoms subside, may result in renewed or increased irritation. If symptoms persist, consult your doctor.
- The device contains electrical equipment that could cause injury if not handled properly.
- This product is not a medical device, and is not intended to diagnose, treat, cure, or prevent any disease.
- Maps, directions, and other GPS or navigation data, including data relating to your current location, may be unavailable, inaccurate, or incomplete.
- Consult your doctor before beginning or modifying any exercise program.
- Consult your doctor before use if you have any preexisting conditions that might be affected by your use of this Fitbit product.
- Do not check call notifications or other data on the product's display while driving or in other situations where distractions could be hazardous.
- This product is not a toy. Do not allow children or pets to play with your Fitbit product. The product contains small components that can be a choking hazard.
- Your Fitbit product is water resistant to 10m and is splash and rain proof. It can be worn in the shower but should not be worn while swimming or bathing and should not be submerged under water.
- PurePulse products have a heart rate tracking feature that may pose risks to users with certain health conditions. Consult your doctor prior to use if you:
 - Have a medical or heart condition.
 - Are taking any photosensitive medicine.
 - Have epilepsy or are sensitive to flashing lights.
 - Have reduced circulation or bruise easily.

CARE AND WEARING TIPS

- Clean and dry your Fitbit product regularly, particularly in areas in contact with the skin. Use a clean, damp cloth. Do not wash the product under a faucet.
- Wear your Fitbit product loosely enough to allow air circulation. Review the sizing guide at www.fitbit.com/_____ for more information.
- Use skin care products sparingly on the areas of the skin covered by your Fitbit product.
- Take the product off from time to time to clean it and allow for your skin to be uncovered

- Do not open the enclosure or disassemble your Fitbit product.
- Do not use your Fitbit product if the display is cracked.
- Substances in this product and its battery may harm the environment or cause injury if handled and disposed of improperly.
- Do not place your Fitbit product in a dishwasher, washing machine, or dryer.
- Do not expose your Fitbit product to extremely high or low temperatures.
- Do not use your Fitbit product in a sauna or steam room.
- Do not leave your Fitbit product in direct sunlight for an extended period of time.
- Do not dispose of your Fitbit product in a fire. The battery could explode.
- Do not use abrasive cleaners to clean your Fitbit product.
- Do not wear your Fitbit product while charging it.
- Do not charge your Fitbit product while it is wet.
- Remove your Fitbit product if it feels warm or hot.

BUILT-IN BATTERY PRECAUTIONS

- Your Fitbit product features a built-in battery, which is not user replaceable. Tampering with your product, or attempting to open it, will void the warranty and can result in a safety hazard.
- Use only the charger cable that shipped with your product to charge the battery.
- Charge the battery using a computer, powered hub, or power supply that is certified by a recognized testing laboratory.
- Charge the battery in accordance with the instructions supplied with this guide.





Wireless Activity Wristband