
# INSTRUCTION FOR REMOTE CONTROLLER MODE:NN13T4 SERIES



#### 1 DISPLAY:

(a)If the display is OFF, press the button would wake up the display, And the display show the status of fan, light or timing by flickering.(b)If the display is ON, the display would be bright for 10s and show the status of fan, light or timing after you press the button.

(2)F/R: Press and hold the button for 2s to change the direction of fan. And the display would show the direction of fan.



## ③NATURAL WIND ON/OFF:

(a)The natural wind mode: the fan run from speed level 1 increase to level 3 slowly in 10s, and then from speed level 3 decrease to level 1 slowly in 10s, and so on.

(b)If the fan is OFF, this button is useless. The display will show the fan speed when you press this button.

(c)If the fan is ON, but is not in the natural wind mode, the fan will be enter the natural wind mode when you press this button. And the display will show

(d)If the fan is ON and is in the natural wind mode, the fan will exit the natural wind mode and run in the last speed when you press this button. And the display will show the fan speed.

### (4) TIMING:

(a)If the fan is OFF, this button is useless, The display will show "0" when you press this button.

(b)If the fan is ON or is in the natural wind mode, it will set the timing increase 1 hour when you press this button. And the display will show the timing.(The timing of display cycles from 0 to 9.)


(c)If the fan is ON or is in the natural wind mode, it will cancel the timing when you press and hold on this button for 2s. And the display will show "0".

(d)If the fan turns off during timing, the timing will be canceled. (e)The timing of display is not cleared to "0" after the timing is over.

### (5) Temperature Control & CODE :

(a)Press and hold on this button less then 1s, the function is open or close the temperature control. And the display will show the status of temperature control.

(open temperature control: close temperature control: )



(b)When you would like to operate ceiling fan by remote controller, you need to press and hold on this button more then 1s to code within the receiver powered in 10s. You would hear a sound "beep" if the controller codes with receiver successfully.

(c) If you press and hold on this button more then 1s, the display will



# (6) SPEE D UP:

(a) If the fan is ON and is in natural wind mode, the fan will exit the natural wind and increase one speed level based on the speed level before entering natural wind mode when you press this button. The display will show the fan speed level. (The maximum speed level is 6.)

(b) If the fan is ON and is not in natural wind mode, the fan will increase one speed level when you press this button. The display will show the fan speed level. (The maximum speed level is 6.) (7) SPEED DOWN:

(a) If the fan is ON and is in natural wind mode, the fan will exit the natural wind and decrease one speed level based on the speed level before entering natural wind mode when you press this button. The display will show the fan speed level. (The minimum speed level is 1.)

(b) If the fan is ON and is not in natural wind mode, the fan will decrease one speed level when you press this button. The display will show the fan speed level. (The minimum speed level is 1.)

### (8) FAN ON/OFF:

(a) If the fan is OFF, the fan will run in the last speed when you press this button. And the display will show the fan speed level. (b)If the fan is ON, the fan will stop when you press this button. And the display will show "0".

(9)LIGHT ON/OFF:

(a) If the light is OFF, the light will be turned on with the last luminance level when you press this button. And the display will show the luminance level.

(b) If the light is ON, the light will be turned off when you press this button. And the display will show "0".

(10) B RIGH TNESS UP:

(a) If the light is OFF, this button is useless. And the display will show "0" when you press this button.

(b) If the light is ON, The luminance will increase one level when you press this button. And the display will show the luminance level. (The maximum luminance level of display is 9.)

#### (11) B RIGH TNE SS DOWN:

(a) If the light is OFF, this button is useless. And the display will show "0" when you press this button.

(b) If the light is ON, The luminance will decrease one level when you press this button. And the display will show the luminance level. (The minimum luminance level of display is 1.)

#### (12) YE LLOW BUTON:

(a) If the light is OFF, this button is useless. And the display will don't show anything when you press this button.

(b) If the light is ON, change the color temperature to warm when you press this button. But the display will don't show anything.

#### (13) WHITE BUTTON:

(a) If the light is OFF, this button is useless. And the display will don't show anything when you press this button.

(b) If the light is ON, change the color temperature to neutral when you press this button. But the display will don't show anything.

#### (14) BLUE BUTTON:

(a) If the light is OFF, this button is useless. And the display will don't show anything when you press this button.

(b) If the light is ON, change the color temperature to white when you press this button. But the display will don't show anything.

#### FCC ID: OGT-2022-NN

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

□ Reorient or relocate the receiving antenna.

- □ Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### Model: NN13T4A / NN13T4B / NN13T4C / NN13T4D IC: 23598-2022NN

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science

and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following

two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired

operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR

d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio

exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1) L'appareil ne doit pas produire de brouillage;

2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible

d'en compromettre le fonctionnement.