


A view of your PowerView® Gen 3 Gateway or Gateway Pro



This equipment should be installed and operated with minimum distance 20cm separation from the user.

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme aux RSS sans licence d'Industrie Canada. Son fonctionnement est soumis aux deux conditions suivantes:

- (1) Cet appareil ne doit pas provoquer d'interférences; et
- (2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles d'entraîner un fonctionnement indésirable de l'appareil.

ICES-003

This Class B digital apparatus complies with Canadian ICES-003.

- Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

NMB-003

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

- L'utilisation de ce dispositif est autorisée seulement aux conditions suivantes : (1) il ne doit pas produire de brouillage et (2) l'utilisateur du dispositif doit être prêt à accepter tout brouillage radioélectrique reçu, même si ce brouillage est susceptible de compromettre le fonctionnement du dispositif.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/tv technician for help.

Note: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

CE Statement

Hunter Douglas Window Fashions, One Duetta Way, Broomfield, CO 80020, USA

Hunter Douglas hereby declares that the PowerView® Remote Control is in compliance with the essential requirements and other relevant provisions of Electromagnetic Compatibility (EMC) Directive 2014/30/EU and Radio Equipment Directive (RED) 2014/53/EU. A copy of the Doc can be obtained online: www.hunterdouglas.com/RFcertifications.



Rev A

©2022 Hunter Douglas. All rights reserved. All trademarks used herein are the property of Hunter Douglas or their respective owners. 7/22

HunterDouglas 



PowerView® Gen 3 Gateway
QUICK START GUIDE

POWERVIEW® GEN 3 GATEWAY





Step 1:

Plug in your PowerView® Gen 3 Gateway or Gateway Pro using the provided USB power cable and power adapter.

(Optional) Gateway Pro Only: Apply power by using Power over Ethernet (PoE).


Step 2:

Download the PowerView® App from the Google Play or the App Store.

To download, go to www.hdpvapp.com or scan this QR code:



PowerView



Step 3:

Open the PowerView® App and follow the on-screen instructions to finish the setup process.

To add a gateway to an existing project, navigate to **More>Accessories>Gateways** in the PowerView App and follow the on-screen instructions.

