


PRODUCT INTRODUCTION



THREE WAYS TO TURN ON Z CAM S1x Pro

AC/DC power adapter

- Connect the appropriate AC power cable (26, 27 or 28) to AC/DC power adapter (25).
- Connect the AC power cable to the power outlet.
- Connect the DC power plug (24) of the power adapter to the DC power adapter socket (13) of Z CAM S1x Pro.
- Note that Z CAM S1x Pro will be turned on whenever the DC power adapter socket (13) is connected to power source.

Battery Unit

- Insert four 18650 standard lithium ion rechargeable battery cells (not included) to the Battery cell holder (18). Pay attention to the polar direction and make sure that the battery cells are fully charged.
- Insert Battery cell holder (18) into Battery unit (15). Pay attention to the right direction. Then slide the Battery cell holder lock (17) to lock position.
- Attach Battery unit (15) to the Main camera unit (07). Pay attention to the right direction and make sure that USB Type-C power plug (14) is properly plugged into the USB Type-C power socket (12). Then pull up the Safety latch (16) , mount it onto the Main camera unit (07) and lock it properly.
- Press and hold Power button (02) to turn on Z CAM S1x Pro.

External power source

- Connect other DC power source (12V  $\equiv$  3A) to the DC power adapter socket (13) of Z CAM S1x Pro.
  - Note that Z CAM S1x Pro will be turned on whenever the DC power adapter socket (13) is connected to power source.
- Or
- Connect other DC power source (7.4V  $\equiv$  3A) to the USB Type-C power socket (12). Press and hold Power button (02) to turn on Z CAM S1x Pro.

BEFORE RECORDING

- Make sure that all four SD cards are properly inserted into the SD card slots A, B, C & D (03).
- It is recommended to use SANDISK EXTREME PRO® SDXC™ UHS-I MEMORY CARDS or compatibles. Note that Z CAM S1x Pro supports SDXC™ memory cards up to 128GB capacity.

RECORDING

- Press and hold Record button (05) to start recording.
- To stop recording, press and hold Record button (05).
- Recorded video image files are stored in the corresponding SD cards.

TURN OFF Z CAM S1x Pro

- While Z CAM S1x Pro is turned on, press and hold Power button (02) to turn off.

LED INDICATOR STATUS

- |                      |  |
|----------------------|--|
| All green            | : When Z CAM S1x Pro is turned on with all SD cards properly inserted.         |
| All red              | : When Z CAM S1x Pro is turned on but without SD cards.                        |
| Flashing green       | : When Z CAM S1x Pro is recording, LED indicator will flash once every second. |
| Flashing red         | : When SD card memory is full, LED indicator will flash every 500ms.           |
| Flashing red (rapid) | : When Z CAM S1x Pro is overheated, LED indicator will flash every 200ms.      |

**FCC caution**

Federal Communication Commission (FCC) Radiation Exposure Statement

When using the product, maintain a distance of 20cm from the body to ensure compliance with RF exposure requirements.

FCC statements:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.