


尺寸: 52*96mm



Product Specification:

Button count: 4 buttons OPERATING FREQUENCY: 2.4 GH RESOLUTION:800/1200/1600 DPI RECEIVER INTERFACE: USB VERSION 2. INPUT: DC1.5V 9mA

Directions for Use: 1. Connecting the Receiver

automatically.

- Take out USB Nano receiver and plug it into an available USB port in your computer. The Plug & Play function works
 - 2. The RF 2.4GHZ optical mouse uses one AA battery (battery is not included). Open the battery cover. Insert the batteries into the compartment, ensuring they correspond with the polarity marking.
- 3. Replace the battery cover.
- 4. TeckNet Mouse will pair automatically, the LED indicator will flash for 5-10 seconds, when the LED indicator stops flashing, the mouse is ready for use.

- Pairing process will stop if inserting the battery first and then plugging the Nano receiver beyond 5-10 seconds.
- . Make sure that the polarity of the batteries is correct. The positive (+) and negative (-) ends of each battery must match the positive (+) and negative (-) markings in the battery housing.

USB Nano Receiver:

The receiver can be removed and stored next to the battery compartment while not

DPI Switch:

he mouse supports 800 -1200- 1600 DPI. To switch to either setting, press the DPI button. (Default is 1200DPI)

Reconnection:

here is a wireless signal connection code for this mouse. High temperatures, electro-magnetic fields or vibration may influence the code signal and occasionally the mouse may need to be reconnected. Both the mouse and Nano Receiver have a

built-in code and one mouse can be connected to one receiver, or several mice t one Nano Receiver.

- . Unplug the Nano receiver from USB port, and plug it back in and remove the AA battery from the mouse, and then re-insert.
 - 2. Move the mouse to within 50cm of the Nano receiver or re-insert the battery or press any key to reconnect; the above process must be completed in 15 second
 - 3. Mouse will ready for use after reconnectio

- 1. To maximize battery life, it is recommended you use the mouse on a white or light colour surface.
- 2. If not used, the mouse will drop into auto-sleeping mode within 3 seconds. Pres any key or scroll wheel to activate the
- 3. Do not use the mouse on a glass or mirrored surface, as these surfaces will cause the mouse to fail temporarily.
- 4. The mouse might not work smoothly on some special surfaces, such as smooth, dar or black, reflecting and 3D mouse pads surfaces.



Avoid using the mouse on a metal surface. Metals, such as iron, aluminium or copper, shield the radio frequency transmission and

- may slow down the mouse presenter's response time or cause the mouse to fail temporarily.
 - 6. If your PC has a metal case that contains aluminium or magnesium, use the mouse to the side. The display panel may interfere with the radio frequency signal if you use the mouse directly in front of the PC.
 - Please remove the batteries if you are not going to use it for a prolonged period of time (several weeks or months).

Note on handling batteries:

- 1. Keep batteries out of the reach of children. Replace old or weak batteries promptly.
- 3. Remove the batteries if the mouse is not going to be used.

Safety Measures:

- Keep the mouse away from young children.
- 2. Any attempt to disassemble, adjust or repair the mouse may result in exposure and other safety hazards.



Troubleshooting:

- 1. What do I do if the mouse does not
- Make sure that the polarity of the batteri is correct. The positive (+) and negative (ends of each battery must match the positive (+) and negative (-) markings in the battery housing.
- Make sure the batteries are not discharged.
- Try to remove the batteries, and reinstall 2402MHz - 2480MHz, such as a 2.4G the batteries again. telephone, 2.4G baby monitors, 2.4G
- · Verify that your computer's power interference, move the mouse's receiver
- Check that the Nano receiver's USB far away from each other as possible; connector is firmly attached to the USB alternatively try to change the 2.4G port of your computer. frequency of the affected devices
- Windows (XP, Vista, Win 7, 2000, 2003, 2007, Win8, Win10) but the cursor does
 - the USB Nano receiver and restart your PC Increase the distance between the Nano receiver and the base units of other cordless devices.



- the Receiver, please try "Reconnection". . When I use the mouse, other 2.4G
 - Cordless devices work more slowly or fail temporarily – what should I do? The mouse has 34 channels to prevent

If replacing the batteries does not help, it is

likely that the mouse is not connected to

interference. However, the mouse may

and the base unit of the affected device as

. What do I do if the response time of the

mouse is slow or the mouse intermit-

operational working distance (1.5m) from

Ensure that the mouse is within the

tently stops working?

- cause interference with any cordless. radio-based device that operates at
- cordless routers and toys. To reduce
- management features are turned of
- Still not working? Please try "Reconnec-
- 2. The USB Nano receiver is recognised by
- Check whether the low power indicato the top of the mouse lights up. If the sensor lights up, it is likely that the batteries are discharged. Please replace




Turn off any cordless device and their base units that are near the mouse Nano

- If you are using the mouse on a metal surface, move the mouse and the receiver to a non-metallic surface. Metals, such as iron, aluminium or copper, shield the radio frequency transmission and may slow down the mouse presenter's response time or cause the mouse to fail temporarily.
- 5. I cannot use the mouse while another cordless mouse is in use – what should I
- Please try "Reconnecting"

IMPORTANT SAFETY INSTRUC-TIONS-CAREFULLY FOLLOW THESE INSTRUCTIONS.

1. SAVE THESE INSTRUCTIONS - This sheet contains important safety


sheet contains important safety



Before using the product, read al instructions and caution marking on the product, accessories and device using our product.



lack of experience and knowledge, unless they have bee given supervision or instruction



- 4. Children should be supervised to ensure that they do not play with the appliance.
 - 5. Keep the product away from fire or explosion may occur.



- 3. This appliance is not intended for no quarantee that interference will not occur in a particular installation. If this equipment use by persons (including children) with reduced physical, turning the equipment off and on, the user is encouraged to try to correct the interference by
- sensory or mental capabilities, or - Reorient or relocate the receiving anten
 - Connect the equipment into an outlet on a circuit different from that to which the

FCC Warning Statement

could void the user's authority to operate the equipment.

- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible forcompliance

This equipment has been tested and found to comply with the limits for a Class B digital

device, pursuant to Part 15 of the FCC Rules. These limits are designed to providereasonab

uses and can radiate radio frequency energy and, if not installedand used in accordance wit

材质: 80g书纸 单色印刷 双面印刷 骑马钉

