


USER GUIDE

SMART PLUG SP1




Contents

Introduction	01
Technical Specifications	02
APP Installation	03
Indicator Status & Operations	04
Quick Start on Mobile Phone	06
Sensor Connection	08
Warranty Information	09

Introduction

Package List: Smart Plug SP1 (×1)
User Guide (×1)



Note: The sensor interface is a 3.5 mm audio jack.

Technical Specifications

Input Voltage: 110-240 V ac, 50/60 Hz

Output Voltage: 110-240 V ac, 50/60 Hz

Maximum Load: 16 A, 3000 W

Operating Temperature: -10 °C to 60 °C

Operating Humidity: ≤80% RH

System Requirements: Android/iOS

Network: WiFi 2.4GHz

Wireless Protocol: IEEE 802.11b/g/n

Bluetooth: BT4.2, Classic BT&BLE supported

 Text marked with asterisk means the feature depends on the specific model purchased.

APP Installation

Option 1: Download the App from
www.ubibot.com/setup

Option 2: Search for "UbiBot" on the
App Store or Google Play.



Indicator Status & Operations

- When the indicator flashes alternately yellow and blue, it means the device is in the setup mode.
- When the indicator is constantly blue, the device is powered on and the network is connected.
- When the indicator is constantly yellow, the device is powered on but the network is disconnected.
- When the indicator is off, the device is powered off.

- When the indicator flashes blue, the device is resetting to default settings.
 - When the indicator flashes yellow, it means there are hardware errors.
-

- ⏻ Press the power button once to turn on/off the device.
- ⏻ Press and hold the button for 5 seconds to enter the setup mode.
- ⏻ Under “setup mode” , press the button three times in quick succession to reset the device.

Quick Start on Mobile Phone

STEP 1.

Turn on your phone's Bluetooth first. Launch the App, register if needed, and log in. Tap "+" to add a device. Scan the QR code on the device or manually enter the serial number.

STEP 2.

Plug the socket into the power supply and then press and hold the power button for 5 seconds to enter the setup mode.

STEP 3.


Follow the on-screen instructions to enter correct WiFi password. Then tap "Next Step" to complete the setup.



⚠ If the setup fails, please check if the indicator flashes alternately yellow and blue. Please make sure that WiFi is 2.4 GHz and the password is entered correctly.

Sensor Connection

Plug the external sensor into Smart Plug.
(sensors need to be purchased separately)



Warranty Information

This device is warranted to be free of defects in materials and workmanship for a period of up to one year from the original purchase date.

The following situations are not covered by the warranty:

- ① Issues arising after the warranty period has ended.
- ② Malfunction or damage caused by improper handling or not operating the device according to the instructions.
- ③ Accidental or man-made product damage.
- ④ Natural wear and aging of materials.
- ⑤ Failure or damage caused by unauthorized removal of the product.
- ⑥ Failure or damage caused by *force majeure*.
- ⑦ Other faults or damage not caused by product design, technology, manufacturing, quality, etc.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

ISED Statement

- English: This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device. The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

- French: Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. L'appareil numérique est conforme à CAN ICES-3 (B) / NMB-3 (B).

Radiation Exposure Statement

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Déclaration d'exposition aux radiations

Cet équipement est conforme Canada limites d'exposition aux radiations dans un environnement non contrôlé. Cet équipement doit être installé et utilisé à distance minimum de 20cm entre le radiateur et votre corps.



www.ubibot.com