Wireless Quick Charging
Vehicle Holder

Instruction Manual

Parameter Description

Product Name: wireless fast charging vehicle holder (intelligent induction type)

Power:15W/10W/7.5W


Effective transmission distance:0-5mm

Boundary dimension: 102mm * 71mm * 46mm

Host size: 98mm * 60MM * 7mm

Charging interface: TYPE-C USB

Functional components





Spectifications

- 1. Weight: 117g
- 2. Material: ABS / PC + magnesium aluminum alloy
- 3. Input voltage / current: 5V / 2a, 9V / 1.67a
- 4. Output power: 15W/10W/7.5W automatic identification
- 5. Rated frequency: 110k-205khz
- 6. Charging distance: 0 5mm
- 7. Equipment supporting QC wireless fast charging, such as: HUAWEI P40Pro/Mate 30/Mate20/MateRS/Iphone13/ 13 Pro/13 Pro Max/iphone12/12 Pro/iphone 12 Pro Max/ 11/11 Pro/11Pro Max/X/iphone XS Max/XR/iphone8/ 8 Plus/Samsung Galaxy Note20/Note10+/Note10+5G/ Note9 / note8 / S20 / S10 + / S10 / S9 + / S9 / S8 + and other supportWireless charger

Instructions For Use

- 1. Connect the product to the appropriate data cable during use
- Connect the USB end of the data cable to the vehicle interface(e.g. cigarette lighter converter and USB charging interface)
- 3. The base clamp clamps the air outlet of the air conditioner, and can also be placed in other places that can be clamped
- 4. After the equipment is connected with 5 ~ 9V DC power supply, it will automatically check the tension and closing once, The indicator light is on. When the object is 5cm-20cm close to the equipment, it will automaticallySense and open your arms, put in the mobile phone, and the device automatically clamps the mobile phone, At this time, the wireless fast charging will automatically charge the mobile phone (the mobile phone has wirelessA charging function). When taking out the mobile phone, you need to touch the upper right corner of the back, fingersIcon sensing area, when the finger touches this position, the device will open automaticallyTake out your mobile phone with both arms
- 5. The equipment has built-in overvoltage protection, over temperature protection, magnetic field protection and short circuitProtection. In case of abnormality, it will automatically stop working

Precautions

- 1. Do not over squeeze or collide with the equipment
- Do not use it under severe high temperature,
 humidity or corrosive environmentThis product can
 avoid damaging the circuit of the equipment

Thank you for using this product!

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.