

Double Sided



Energizer
SMART WIFI
INDOOR FIXED CAMERA

QUICK START GUIDE
EIX1-1004 v1.2

GETTING STARTED

Thank you for choosing the **Energizer** Smart Camera. This quick start guide will help you with setup and installation.

Package Includes:

- Smart Camera
- Mounting Kit
- 6ft USB Type-C Power Cable
- Quick Start Guide
- USB Power Adapter

What You Need:

- Energizer App
- 2.4GHz WIFI
- Screwdriver and Drill (Optional)

Before setup, make sure your phone is connected to the 2.4GHz WIFI network that your device will be placed on. You may also need to turn on location and Bluetooth to find nearby networks.

CONNECT THE DEVICE

STEP 1

Download the free **Energizer Connect** app from the App Store (for iPhones) or Google Play Store (for Android phones).

STEP 2

Make sure your mobile device is connected to your **2.4GHz WIFI** network.

Open the app and **click** "Create Account" by following the on-screen instructions.

After your initial sign in, your app will remember your password and log you in automatically. You can also choose to manually log out under Settings in the Main menu.

Click "Create Account"

You may need to check your Spam folder for the verification code.

STEP 3

Plug the camera into a wall outlet using the provided 6 foot cable and USB power adapter.

The indicator light on the camera should start blinking **RED** for pairing mode. The camera will also make a chime sound, letting you know it has started up.

LED Behavior	Device Status
Red Blinking	Pairing Mode
Red Solid	Starting Up
Blue Blinking	Attempting to Pair
Blue Solid	Connected

If the LED is not blinking, then you are not in pairing mode. Reset the camera by using your finger to **hold down** this button for 5 seconds until you hear the camera make a chime sound.

Reset button

Hold down

Tip: If you would like to install a micro SD card, insert it as shown with the gold pins facing the lens. (micro SD card not included)

STEP 4

After logging in, **click** "+" on the top right of the screen and **select** "Add device".

Click

Select

STEP 5

Select the Camera category and **confirm** the indicator light is still blinking red. **Click** "Next Step".

Select

Confirm

Help: Switch between pairing modes. See troubleshooting page 10.

STEP 6

Confirm that the displayed **WIFI** network is your **2.4GHz WIFI** network, **enter** your **WIFI** password and **click** "Confirm".

Confirm WIFI

Enter and Click

Help: If you need information about **2.4GHz WIFI** networks, click the link to go to our Connect FAQs on our website.

STEP 7

On the next screen, a QR Code will appear. Position your camera to scan this QR code on your phone. **Click** "Continue" when you are ready.

Touch the lens of the camera directly against the QR code on your phone and slowly move the camera away.

Click

Click

Click

Click

Once you hear an audible prompt from the camera, **click** the "I Heard a Prompt" button.

Click

STEP 8

Your Smart Camera will now be connected to the network. Confirm the settings for your device and then **Click** "Done".

Click

TIP: You can put your camera directly in a room by selecting one of the available rooms. **Click** the **+** button to change the name of the product.

Click

Click

Click

Your **Energizer** Smart Camera is now ready to use. You can now view the camera remotely and receive mobile alerts. We hope you enjoy using your **Energizer** Smart Camera. For frequently asked questions and instruction videos, please visit our website at www.energizerconnect.com.

INSTALLATION

Your Smart Camera can be positioned on any flat surface, or can be mounted on a wall.

Tip: When mounted, the camera's angle can still be adjusted by sliding the camera ring up/down and/or rotating the base left/right.

Follow these instruction to mount your Smart Camera on the wall:

STEP 1

Push a sharp implement though the holes in the camera's base to punch holes in base's foam pad.

STEP 2

Hold the camera at your desired location on the wall, and mark the screw hole positions on the wall through the mounting holes in the camera's base.

NOTE: When positioning the camera, take note of where you will connect its USB power cable.

STEP 3

Depending on your wall, use a screwdriver and drill (optional) to attach the camera securely to the wall with the provided screws and anchors (optional).

STEP 4

Manually rotate the camera for your desired viewing angle.

LEGAL & WARRANTY

To see Warranty information and Certification Legal warnings, please see our website: www.energizerconnect.com

©2023 Energizer. Energizer, Energizer Bunny design and certain graphic designs are trademarks of Energizer Brands, LLC and related subsidiaries and are used under license by Jem Connected IoT, Inc. All other brand names are trademarks of their respective owners. Neither Jem Connected IoT, Inc. nor Energizer Brands, LLC is affiliated with the respective owners of their trademarks.

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries.

App store is a service mark of Apple Inc.

Google, Android and Google Play are trademarks of Google LLC.

FCC Compliance

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

LEGAL & WARRANTY

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

TROUBLESHOOTING

HAVING TROUBLE WITH SETUP?

Don't return this product to the retailer, we're here to help! Please call us at 888-693-4189 or visit www.energizerconnect.com for video tutorials, updated manuals and more FAQs for your device.

My device won't connect to my network!

1. Make sure you are connected to your **2.4 GHz network** and your device is blinking red before you start trying to connect your device.
2. You may need to reset your device if you are having trouble. Check out page 7 for the location of your device's reset button.
3. To allow the app to locate the network, you may need to allow permissions for location and turn on your Bluetooth.
4. If you are not certain what type of network you have, contact your Internet Service Provider and ask them to create a separate, dedicated **2.4GHz network**. You can also do this manually in your router's settings.
5. Try moving to a spot closer to your router for connecting.
6. You can also purchase a WiFi extender to increase your WiFi range and strength.
7. In some cases, you can try using the secondary pairing mode by clicking "Pairing Mode" on the Add Device screen (see bottom of page 3). Follow the on-screen instructions.

My device says it's already bound when I try to connect it!

1. When you get the ALREADY BOUND screen, click the blue link to send us an Unbind Request. We can assist you further from the in-app Help Center.

When my camera is pointed at a window at night, I can't see through the glass!

1. At night, the camera's IR LEDs will turn on automatically to provide night vision when it gets dark. IR light reflects off of glass. So if you are trying to use your Indoor Camera through a window at night, go into the Device Settings -> IR Night Vision and set it to OFF.

When I try to view live view, it says "Offline" or "Cannot establish encryption channel!"

1. Unplug your camera from power and plug it back in.
2. Check to make sure you have the newest firmware for your camera. Go to the device settings and scroll down to Firmware Information.
3. Contact us so we can assist you.

Setting up Motion Detection and Recording

1. From the live view of the camera, click Notifications, or from the device settings, click Detection Settings.
- You can schedule when you want to receive notification of motion.
2. To save recordings, you can purchase Cloud Recording or install a microSD card (max 128GB, not included into the camera for LOCAL recordings).
- Recordings can be saved of motion or can be All Day.
- Please note: All Day recording will fill up a microSD card much quicker.
3. Every time a motion is detected, a screenshot is saved for your review. They can be found in the Notification Center. From the home page, click the **three lines** in the top left, and then click Notifications.
4. If you are using a microSD card, it will continue to record until the the microSD card fills up.
- If you are using Motion based recording: Separate files are recorded for each detection, so when the memory fills up, it will begin to record over the oldest detections, one at a time.
- If you are using All Day recording: One file is saved as the video is continuously recording. When the memory fills up, it will clear the entire recording and start fresh.

Two Way Audio

1. By default, the camera will only use the microphone OR the speaker. When you click the microphone on the live view, you will be able to speak through the camera, and when you click the microphone again to turn it off, the speaker will automatically turn on so you can hear what's being said at the camera.
2. For some cameras, you can turn on Full Two Way Audio by going to the Device Settings -> Basic Function Settings -> Talk Mode and click on Two-Way Talk.

Why Does It Need The Internet?

1. Our devices must connect to an internet server in order to be fully operational, otherwise they will not work as desired.

Why Does The App Need Location Permission To Function?

1. The latest mobile phone operating systems require location permission to access your Wi-Fi and to detect your Wi-Fi name.

Why Does The App Ask for Permission To Use My Microphone?

1. Since the app can be used with camera(s) and it's 2-way talk feature, Google's current Terms of Service requests microphone permissions when initially creating the account for device setup.

What's a Mixed Network?

1. Most newer routers are dual band and broadcast a separate 2.4GHz and 5.0GHz network bands. By default, they are setup to use the same Wi-Fi name and password for both. This combined dual network with the same name and password is referred to as a "Mixed Network".

My "Live View" isn't Working When I Access The App!

1. If "Live View" is not working, leave the Energizer Connect app and go to your phone's settings. Go to the Apps settings, locate the Energizer Connect App, Storage, and then clear cache.