



## LoRaWAN Temperature & Humidity Sensor

LHT52



### OVERVIEW:

The Dragino LHT52 Temperature & Humidity sensor is a long Range LoRaWAN Sensor. It includes a built-in Temperature & Humidity sensor and has a USB Type-C sensor connector to connect to external sensors such as external Temperature Sensor.

LHT52 senses environment temperature and humidity and send these values via long-range wireless LoRaWAN protocol. It targets professional wireless sensor network applications such as food service, smart metering, smart cities, building automation, and so on.

LHT52 supports 2 x AAA batteries and works for a long time up to several years. You can replace the batteries easily after they are finished.

LHT52 is fully compatible with LoRaWAN v1.0.3 protocol. It can work with standard LoRaWAN gateway.

LHT52 supports Datalog Feature to make sure users won't miss sensor data. It records sensor value for every uplink. These values can be retrieved by LoRaWAN server via downlink command.

LHT52 supports temperature alarm feature. It can uplink alarm in a short interval while temperature exceeds preset levels.

#### Features:

- Wall Attachable
- LoRaWAN Class A protocol
- AT Commands to change parameters
- Remote configure via LoRaWAN Downlink
- Firmware upgradable via program port
- 2 x AAA (R03) 1.5V batteries
- Built-in Temperature & Humidity sensor
- Optional External Sensors
- Infrared LED to indicate status
- Datalog and retrieve by LoRaWAN
- Temperature alarm feature

#### Environment:

- Working Temperature: -20~50°C
- IP Rating: IP53

#### Package:

- Dimension: 5.8 x 5.8 x 2.0 cm
- Package include LHT52
- Package Not include: Batteries, External Temperature Sensor

### Sensor Spec:

#### Built-in Temperature Sensor:

- Range: -20 ~ +50 °C
- Accuracy: ± 0.3°C
- Resolution: 0.01°C

#### Built-in Humidity Sensor:

- Range: 0 ~ 99.9% RH (no dew)
- Accuracy: ± 3.5% RH (20 ~ 80%RH)
- Resolution: 0.1% RH
- Response Time: < 1s

#### External Temperature Sensor:

- Resolution: 0.0625 °C
- MAX ±0.5°C accuracy from -10 to 85°C
- Max ±2°C accuracy from -55 to +125°C
- Cable length 2 meters
- Order Separately (P/N: AS-01)

### Order Info:

LHT52-XXX

XXX: Frequency Bands, options:  
EU433, CN470, EU868, 868, 863, KP920  
AS923, AU915, US915

### Dragino Technology Co., Limited

Room 200, Block B, BCT Innovation Base (BaoChengTall), No.8 CuiYueRoad  
LongCheng Street, LongGang District, Shenzhen 518115, China  
Direct: +86 755 88610629 / Fax: +86 755 88647123

**WWW.DRAGINO.COM**

**sales@dragino.com**

# FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The users manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. In cases where the manual is provided only in a form other than paper, such as on a computer disk or over the Internet, the information required by this section may be included in the manual in that alternative form, provided the user can reasonably be expected to have the capability to access information in that form.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.