



COVER

LINKSYS


Quick Start Guide

AC1200 DUAL-BAND GIGABIT WiFi 5 ROUTER
E5600



1. Where does your internet come from?

<p>A Separate Modem and Router</p>  <p>Modem Router</p>	<p>OR</p>	<p>B Modem-Router</p>  <p>Modem - Router (Gateway)</p>
<p>If you have a separate modem and router, disconnect and remove your old router.</p>		<p>If you have a modem-router, leave it connected.</p>

2. Plug the router into a power source.




3. **Connect your new router to your modem or modem-router.**

A Modem 	OR	B Modem-Router 
Plug one end of the included ethernet cable into the yellow Internet port on your new router. If you have a modem, plug the other end into the Ethernet (LAN) port on the modem.		Plug one end of the included ethernet cable to the yellow Internet port on your new router. If you have a modem-router, plug the other end into any available port .

4. Connect to the secure Wi-Fi name shown on the sticker. (You can change these details later.) Select the option to automatically connect to this network in the future. You will not have internet access until you complete router setup (see Step 5).

Place sticker here
Wi-Fi Name/Wi-Fi Password

5. Enter <http://myrouter.local> in a web browser. Follow the on-screen instructions to complete setup. You also can enter 192.168.1.1 in a browser to start setup.



6. Once you are finished with setup, please be sure to register your router so we can keep you informed about security updates, product recalls and other things that will improve your experience.



Register your product

Once you register we can share important security updates, product recalls and other things that will improve your experience. All we need is your email. We will only use your email for limited security and customer support purposes.

Email Address

☐ Linksys may also email me to keep me up to date with special offers and information from Linksys. You can unsubscribe at any time by using the link at the end of any email we send. [Read our Privacy Policy here.](#)

[Skip](#)

[Next](#)

© 2017 Belkin International, Inc. and/or its affiliates. All rights reserved.

BACK COVER

AS YOU COMPLETE SETUP, RECORD YOUR ROUTER SETTINGS IN THE EMPTY SPACES PROVIDED

2.4 GHz Wi-Fi name (SSID)

2.4 GHz Wi-Fi password

5 GHz Wi-Fi name (SSID)

5 GHz Wi-Fi password

Router password (default is "admin")

TIPS FOR SUCCESSFUL SETUP

- Check that you have a working broadband internet connection by connecting a computer directly to your modem.
- If you cannot connect to the internet after setting up your router, turn off your modem, router, and computer. Restart them in that order.

For more tips, visit linksys.com/support/E5600

Get help

Internet: linksys.com/support/E5600

Twitter: @LinksysCares

Phone (US/Canada): 800-326-7114 (complimentary during your warranty period)