

US/FR/DE/ES/IT/JP/RU/KR

# ICSEE OPERATION GUIDE

WiFi/4G smart camera

V2024-4.0



There is a difference between the photo and the product, please refer to the actual product.

# English

## FCC WARNING

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

**This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.**

## Online Customer Service Consultation

- Open the "iCSee" application and click on the icon to the right of "Devices" (**Fig.1**) to enter the Customer Service Center.

Select the device or click Consult Online Customer Service (**Fig.2**).

**Note: Before inquiring, please inform the customer service staff of the purchasing platform in order to expedite the resolution process.**




Fig.1




Fig.2




Fig.3

- If you encounter any problems, please promptly submit your device feedback, we will solve the problem for you as soon as possible.

# APP Download and Installation

## Method One

You Can Use Any "Scan" Program To Scan The "QR Code" Below To Download The APP.

## Note For Android Syetem

Please Click" Regular Download",Neither"Safe Download" Nor "High-Speed Download"



Scan the "QR code"  
to download

## Method Two

iOS System: Search "iCSee" in APP Store (Fig.4 )

Android System: Search "iCSee" in APP market (Fig.5 )




Fig.4 [iOS System]




Fig.5 [Android System]

## Register New Account and Login

1. Open APP "iCSee",click "Sign Up",and sign up a new account with your phone number/email(**Fig.6**)
2. After registering successfully,enter the username/email and password you just registered to login.
3. You can also use WeChat,Facebook,Line or "Visitor Login" to login in the APP.





Fig.6


## Battery camera switch operation

- Please understand the camera connector and buttons clearly before use.
- Before pairing, turn on the power button of the device. Once you hear the camera say "Starting Quick Setup", which indicates a successful wakeup, you can proceed to theNext step.

**Nota: Para las instrucciones de funcionamiento de [Battery Camera], los productos de alimentación constante ignoran esta página.**



## Solar panel charging indicator diagram



## (WiFi Camera) WiFi Connection

**Attention: Before configuration, please turn on the camera power first, wait for successful startup and reset before connecting to the network**

1. The paired mobile phone must be connected to your router WiFi network;  
(Only 2.4GHZ is Supported)
2. Click the "+" Sign(**Fig.7**) in the upper right corner of main APP interface,click "WiFi Camera"(**Fig.8**) and follow the device voice prompt(**Click "Next"**).
3. To "Router Setting" interface to choose the WiFi Router and enter the password (**Fig.9**),Click "**Confirm**" to enter "Scan Code Pairing instruction" interface.




Fig.7



Fig.8




Fig.9

## (WiFi Camera) WiFi Connection

4. After Scanning the code, set the password according to the prompt, and proceed to the next step
5. After pairing, newly added camera will be showed in the list, connecting successfully (Fig.10)
6. Click to view, operate, and make settings (Fig.11)




Fig.10



Fig.11



## Fast networking pairing

- ▲ Please power on the device first, and then configure the network.
- ▲ After logging in the APP program, the "Quick Pairing Window" pops up as (Fig.13), please click to confirm. Quick Pairing.

**Note: If the Quick Pairing window does not pop up, it means the device does not support Quick Pairing.**

1. The paired mobile phone must be connected to your router WiFi network;  
(Only 2.4GHZ is Supported)
2. Click the "+" sign (Fig. 12) on the upper right corner of the APP Home screen to enter the automatic device search interface. When using the current device, please click **"Confirm"** (Fig.13) to proceed to the next step and set the router password Code;
3. To "Router Setting" interface to choose the WiFi Router and enter the password (Fig.14), Click **"Confirm"** to enter "Scan Code Pairing instruction" interface.




Fig.12




Fig.13




Fig.14

## Fast networking pairing

4. After Scanning the code, set the password according to the prompt, and proceed to the next step
5. After pairing, newly added camera will be showed in the list, connecting successfully (**Fig.15**)
6. Click to view, operate, and make settings (**Fig.16**)




Fig.15




Fig.16

## Q&A with Frequent Electric Camera:

Q: Does the wireless security camera support 24/7 continuous recording?

A: Yes, it supports 24/7 continuous video recording, you can choose SD card storage or cloud storage for storage, cloud storage needs to be paid to use;

Q: Does it support automatic motion tracking?

A: Hello, the device can support automatic tracking, just need to open the "mobile tracking" function in the APP program, you can use the mobile tracking normally.

**(Note: Battery camera does not support automatic motion tracking)**

Q: Does the camera support 5Ghz Wifi?

A: No, the camera doesn't support 5Ghz WiFi, it only supports 2.4Ghz. Outdoors, 2.4G WiFi has a stronger ability to connect through walls than 5G WiFi.

Q: Is there a privacy risk with cloud storage?

A: The cloud storage is in partnership with Amazon Cloud and the storage location is where you purchase it. The surveillance camera uses military-grade encryption, so if you don't share the device, no one can access the camera.

Q: What are the specifications of the micro SD card used for local storage?

A: It is recommended that you use a micro SD card with the specification "8-128GB, format FAT32, Class10" for the camera. Otherwise, you will be prompted that the SD card is not supported and needs to be formatted. Please remove the card and format it to FAT32 using your computer.

Q: Can I share with another phone?

A: No. Open the APP on the first phone, select the device you want to share, click share and a sharing QR code will be generated, then the other phone can scan the shared QR code.

Q: How do I solve the problem of the device being disconnected/offline/unable to start?

1. First, check the distance between the router and the camera, usually within 10 metres. If the distance is too far, try moving the device to within 5 metres to test.
2. You can reboot the router device, clear the device cache, reboot the router once; reassign the IP address.
3. Check if there is any traffic restriction, if there is, please remove the restriction.
4. You can reset the device and reconnect it.

Q: How do I restore the factory settings? How do I reset?

A: Open the rubber plug on the head of the camera, long press the reset button on the camera for 5-10 seconds when you hear: Restoring factory settings in progress, please do not turn off, you can release it and wait for reboot.

Q: How can I contact the seller if I have any questions?

A: You can find us in iCSee APP device center bottom right corner of the program online customer service, we can help you solve any problem, please feel free to find us.