

Bluetooth Remote Control User Guide

The "Bluetooth Remote Control"needs to be paired with your phone before use. Please follow the procedure shown below to set up a connection to the Bluetooth Remote Control:

- 1. Ensure that Bluetooth is turned on:
- 2. Tap the button at the center of the "Bluetooth Remote Control"
- 3. Open the "Bluetooth Remote Control" app on your phone. The first time you use the App, it will prompt you to perform a search and to connect to the device. Tap the "Disconnected "blueton on the main series to bring up the Search for Device screen and connect to the Bluetooth Remote Control. If your connection is dropped. Delse follow the on-screen prompts.

 Your phone will automatically connect to the Bluetooth Remote Control once it finds it. Please be patient and give it a few seconds;

An on-screen prompt will appear after a successful connection is made.

The "Bluetooth Remote Control" offers the following functions:

Remote control your phone - Music: Play/Pause; Previous track/Next track; Lower volume/Increase volume(a single click adjusts volume by one increment; long press adjusts volume continuously; Camera: Activate camera; Rotate camera forward/backward (a single click rotates camera by a given angleJong press rotates camera continuously; Rapid switching between front/rear camera; Shoot;

Find my phone - Double click the Bluetooth Remote Control will trigger your phone to ring;

Disconnect alert - your phone will ring when it is disconnected from the Bluetooth Remote Control; Message notification - the Bluetooth Remote Control will flash when there is an incoming call or a message.

Settings: this includes user quide, firmware upgrade, help and about.

During Bluetooth connection please note

Make sure the two devices are placed within the Bluetooth maximum range (5 meters);
 Make sure there are no obstacles between the two devices, e.g. human bodies, walls, corners or

railings. Safety information

Please read carefully and follow all safety instructions before use to prevent injuries, fires, or explosions.

!\ Note

Using a battery of an unsuitable model may cause explosion. Used batteries must be disposed of

as instructed.

Batteries must not be exposed to direct sun light, fire, or any similar hot environment

/ Warning

Please use batteries, chargers, accessories, and appliances that are approved by the manufacturer

Do not subject your device to physical impact or damage

- Do not place the device inside or near heaters, microwave ovens, cooking appliances or high pressure containers.
- Do not use the device outdoors during thunderstorms
- Please follow all safety warnings and regulations concerning device-usage while driving
 Should any crack, breakage, or overheating occur, please stop using the device immediately and
- contact OPPO customer service
- Do not use the device to poke eyes, ears, or any other part of a body, and do not place in mouth.
- Do not place the device near human or animal eyes if the device has a flashing light or indicator light on it
- If you have a cardiac pacemaker, please use the device on the side opposite to your pacemaker in order to minimize interference.
- Should you need to use any medical equipment, please contact the manufacturer of the medical
 equipment before use to confirm whether the radio frequency emitted by the device will interfere
 with the medical equipment.

The radio frequency emitted by the device may interfere with certain types of hearing-aids and cochlear implants. Please contact the manufacturer of such a product before using our device to confirm whether the radio frequency emitted by our device will interfere with their product.

Note

- . Do not disassemble, modify, or repair the device.
- Any change or modification made to the device will void the manufacturer's warranty If the device needs repairing, send it to OPPO customer service.
- Do not disassemble or pierce batteries as this may cause explosion or fire.
- Do not paint the device or cover the device with adhesive paper.
 Paint and adhesive paper can cause blockage and hinder the device from working properly.
 If you are allerqic to the paint or metals used in this device, you may experience itchy skin, eczema,
 - in you are already. On the paint of metals used in this device, you may experience iterly skin, ezzer or skin swellings as a result. Should any of the aforementioned conditions arise, stop using the device and consult a doctor.
- Only allow qualified professionals to carry out repairs on the device. Repairs carried out by an
 unqualified person may cause damage to the device and can void your warranty.

Water and Dust

If water or dust enters device, it may cause damage to the device. Strictly follow the instructions in order to prevent damage to the device and to keep the device water-proof and dust-proof.

- Do not submerge the device under water over 1 meter deep for more than 30 minutes.
- Do not expose the device to high-pressure water such as waves or waterfalls.
- If the device or your hand is damp, dry your device or your hand before using the device.
- Do not subject your device to saline water, ionized water, or soapy water.
 Resistance to water and dust may be impaired if the device is dropped on hard surface or otherwise impacted.
- If the device becomes wet, dry it with a clean, soft cloth.

Your device has been tested in controlled environments, and has demonstrated water-resistance in given environments (conforms to international standards IEC 60529 - the protection level provided by the seal (deferines grade) meets the requirements of type IPG7); test conditions: 15°C 35°C, 86 - 106 kPa, 1m, 30 minutes continuously). Although the device has met these requirements, this does not mean your device is water-proof under any condition.

Due to the used enclosure material, the product shall only be connected to a USB Interface of version 2.0 or higher. The connection to so called power USB is prohibited.

The suitable temperature for the product and accessories is -10 C-50 C.

CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED RATTERIES ACCORDING TO THE INSTRUCTIONS

Hereby, GUANGDONG OPPO MOBILE TELECOMMUNICATIONS CORP.,LTD declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.





ECC statements:

This device complies with part 15 of the FCC rules. Operation is subject to the following two onditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause

harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct theinterference by one or more of the following measures:

- Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Reorient or relocate the receiving antenna.

-Consult the dealer or an experienced radio/TV technician for help.

Warranty description

Dear user, thank you for using our product. In case of any damage that is not due to human error, warranty service is available for a period of one year beginning from the original purchase date: The warranty covers; refund within 7 days, replacement within 1 month, and repair within 6 months.

To protect your legal interests, please read the following notes carefully:

- (1) The warranty card must be stamped by the distributor to become valid.
- (2) Consumers should retain their warranty card. The warranty card will not be re-issued if lost, and will be voided if altered.
- (3) In case of any damage of the product that is not due to human error, consumers are entitled to repairs at authorized service points free of charge within the warranty period. Before receiving such warranty service, customers are required to furnish the warranty card as well as their receipt of purchase, which includes the product ID.

The warranty is not applicable in the following cases that arise during product usage

- (1) Damages caused by accidental drops or by water immersion in a manner that does not conform to the stipulated instructions.
- (2) Damages caused by human errors such as unauthorized disassembly, modification, etc.
- (3) Damages caused by usage in environments not conforming to product specifications.
- (4) Damages caused by force majeure (e.g. fires, earthquakes, and lightning). (5) Damages caused by improper usage that does not conform to the user guide or operation manual.

(6) The serial number shown on the warranty card does not match that on the product, or the warranty card has been altered.
(7) SN barcode or seal tape of the product is missing, damaged, or blurred beyond recognition.
A product that is repairable but not covered by our free repair service may be repaired for a service fee.

OPPO Warranty Card (For Consumers) Consumer information (to be filled out by the consumer):			
Address:			
Tel (with area code	e):		
Product Information	on:		
(Product model/Co	olor/SNcode/Other Information):		
Retailer Information	on:		
Retailer Name (wit	h stamp):		
Retailer Tel (with a	rea code):		
Retailer address:			
	Year Month Day		
Receipt number:			

OPPO Warranty (Card (For Consun	ners)		
Consumer information (to be filled out by the consumer):				
Name:		Postcode:		
Address:				
Tel (with area code	e):			
Product Information	on:			
(Product model/C	olor/SNcode/Oth	er Information):		
Retailer Information	on:			
Retailer Name (wit	th stamp):			
Retailer Tel (with a	area code):			
Retailer address:				
		Month		
Receipt number:				

OPPO Warranty Card (For Cor	nsumers)			
Consumer information (to be filled out by the consumer):				
Name:	Postcode:			
Address:				
Product Information:				
(Product model/Color/SNcode/	Other Information):			
Retailer Information:				
Retailer Name (with stamp):				
Retailer Tel (with area code):				
Retailer address:				
Purchase Date: Year	Month Day			
Receipt number:				

oppo



