

User Guide
Smart Bracelet
ID107L



Thanks for choosing our device, please read
the user guide carefully before using.

Setting

Use VeryFitPro on iOS or Android smart phone to set
the wristband as follows:

Note: hardware and system of devices should meet the
requirements:



1 Download VeryFitPro

Search and download

Search and download "VeryFitPro" from the Apple Store or
Android App store .

Scan the QR code and download

It probably has a problem to open the link with WeChat or other
scan tools, please copy the link and open it through browser.



12

2- Product activation and installation

The product must be activated by charging before initial use, and then
charge the product to ensure normal power supply. The hand ring will
automatically power on.

Take out: Pull open the strap and take out the bracelet body



Charge the battery: Insert the chip-mounted end of the bracelet body
into the USB interface to activate the product by charging (be cautious
not to reverse the polarity, and comply with the required voltage and
current: 5V / 500mA)



Installation: Mount the bracelet body into the slot of the wrist strap.




Wear on: Adjust the length of the wrist strap until it is appropriate to
wear on the wrist.




13

3- Touch key



Single click the touch key:
Interface switch
Press and hold the touch key:
Enter

4- Make sure the Bluetooth of smart phone is ON,
open app"VeryFitPro"



When selecting the right band from the
search list, please slide the screen of
wristband to wake up the device and
then complete connecting.

Know your Device

1- Wearing Method

Wear the device on your wrist horizontally, about 2cm to carpal, the
same method as wearing watches.

2- Heart Rate Monitoring

To monitor Heart Rate more accurately, please wear the device on the
upper position of your wrist and a bit tighter than usual when you are
taking exercise.

3- Heart Rate Monitoring

Automatic heart rate Monitoring is ON as default, monitor Heart Rate
all the day automatically.


14

4- Working Time

Continuously working for 8 days under normal conditions

5- Interface

Click the touch key to display successively




Function Introduction

1.1 Time Mode

Instructions
Time dial can be switched as follows:
APP Devices Mode>More
[Click the touch key] to enter the next mode:
Data Mode
(you can customize the shortcut through the app)


1.2 Data Mode



[Click the touch key] to enter the next mode:
Heart Rate Mode
[Press and hold the touch key for 2s]
to enter the sub-mode of "Data Reading"

15


1.2.1 Data Reading Sub-Mode



[Click the touch key] to enter the next
sub-mode

Note: To go back to the Data Reading
Mode by clicking the touch key on the
final interface of Data Reading Sub-Mode


1.3 Heart Rate Mode



Change in 0.5s

Note: Upon staying at the Heart Rate interface for 1s, start to monitor the
heart rate, and a fig. like "89" is displayed before the correct data is
monitored, and upon the correct data being monitored, data is displayed.
[Click the touch key] to enter the next mode: Alarm Clock Mode


1.4 Alarm Clock Mode



Note: Alarm clock function should be turned
on in App for the alarm clock to be displayed.

16


1.5 Sports Mode



[Press and hold the touch key for 2s] to enter the
Sports Mode
[Click the touch key] to enter the next sports mode; and in
case there are no other sports modes, it will go back to the
time mode.


Note: Types of Sports mode can be selected in App (App
can handle 4 types of track recording sports and 10 types
of other activities)

1.5.1 Sports Start Mode



After the countdown interface of 3-2-1-GO is the sports underway mode.

1.5.2 Sports Underway Mode



Heart Rate


Steps

Calories

Mile

17

1.5.3 Sports Stop Mode



[Click the touch key] to enter the next sub-mode of
"Sports Underway"[Press and hold the touch key for 2s]
to enter any interface of Data Reading, press and hold 2s
to exit the sports mode.

Note: The speed and distance of riding can be displayed, but App need
to be connected and the riding and App needs to start at the same time.


1.5.3 Sports Stop Mode

1) If the sports last less than 1 minute, the
user will be reminded of not saving the data.
[Click the touch key] to remove the reminder of
automatic quitting from sports mode.
Note: 1.If there is no any activity in a period (15 minutes),
reminder will be displayed 15s before it stop.
2.New activities will remove the reminder of automatic
quitting from the sports mode.
3.If there are no any new operations before the end of the countdown of
automatic quitting from the sports mode, it will exit from the sports mode.

2) If the sports last more than 1 minute, the
Sports End Reminder will be displayed


[Click the touch key] to enter the sports data
display mode

3) Sports data display mode



18


1.5.4 Event Reminder in Sports Mode



1) Reminder of exiting from sports mode upon a period
of no activity
[Click the touch key] to remove the reminder of
automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start
the sports mode with the battery of device is in low.

2) Reminder of full-ram force quit
[Click the touch key] to confirm the full-ram
Force Quit
Note: When the memory of wrist strap is full
of sports data, the user will be reminded of
exiting from the Sports Mode

3) Sports data display mode




Short
training
session!
Not save


Good job!

19

1.5.5 Abnormal operations during the




The reminder will be available soon



[Click the touch key] to quit from the reminder waiting mode

1:

1. Camera mode control




Entry mode: Start the camera entry by App,
and the device will get in the camera mode
successfully.
Photo taking
methods: shake/wrist lifting/click
the touch key

Modes of exit:
1. Press and hold the touch key to exit from the camera mode
2. Exit through App will make the wrist strap quit from the
camera mode.


2. More modes of reminders

1) Call Reminder



Click the touch key to remove the call reminder
Press and hold the touch key to hang up the call
Note: The call reminder in the App needs
to be set open.


2) Message Reminder



In case of pages of messages, Click the touch key
to read the remained ones.
Note: The relevant settings need to be done
in the App.

21


3) Alarm Clock



Alarm Clock: The relevant settings need to be done
in the App.


Alarm Clock Types:
Wake up
Medicine taking
Sleeping
Party
Appointment
Exercise
Meeting

4)Long Sitting Reminder



Alarm Clock Reminder: The relevant
settings need to be done in the App.
Click the touch key: It will remove the
reminder.

5)Target completion reminder



When some goals are achieved, shake the wrist
strap to get the interface of target completion reminder
displayed Click the
touch key to quit from the reminder

22


6) Low battery reminder



Low-Battery! Please recharge timely!

Status Code:
-01 means the abnormality of acceleration sensor
-02 means the abnormality of heart rate sensor
-03 means the abnormality of touch key IC
-04 means the abnormality of flash

7) Device Error Notification




Note: When the device is detected with
an abnormality, the interface herein will be
displayed each time the device is opened.

Basic Specifications

Model No.: ID107L
Battery Capacity: 65mAh
Working Voltage: 3.7V
Host weight: about 22.4g
Sync: Bluetooth 4.0
Working temperature: -20°C - 40°C
Waterproof: IP68
Working Time: 5-10days
Product frequency band: 2402-2480MHz
Maximum transmit power: -7.03dBm

23

Declaration of toxic and hazardous substances in
electronic information products



FAQ

◆ Failed to find the device when pairing

- 1) Make sure the Bluetooth of smart phone is ON, and smart phone
OS Android 4.4 & Above, iOS 7.0 & Above.
- 2) Make sure the distance between phone and device is within
0.5meter, device is among the normal Bluetooth communication
distance range(within 10meter) after pairing finished.
- 3) Make sure the device is not under low battery. If there is still a
problem after fully charged, please contact us.

◆ Failed to connect with Bluetooth occasionally

- 1) Caused by the abnormality of Bluetooth service when it restarted
on the phone.
- 2) Reboot mobile phone or re-start the Bluetooth service, then it
works normal.

◆ How to restore factory defaults

Make sure the device is connected with smart phone, go in the App,
enter "device-- System setting", and choose "reboot device".

24

This device complies with Part 15 of the FCC Rules. Operation is subject
to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference
that may cause undesired operation.



Changes or modifications not expressly approved by the party responsible
for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a
Class B digital device, pursuant to Part 15 of the FCC Rules. These limits
are designed to provide reasonable protection against harmful interference
in a residential installation. This equipment generates, uses and can radiate
radio frequency energy and, if not installed and used in accordance with
the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a
particular installation.

If this equipment does cause harmful interference to radio or television
reception, which can be determined by turning the equipment off and on,
the user is encouraged to try to correct the interference by one or more of
the following measures:
— Reorient or relocate the receiving antenna.
— Increase the separation between the equipment and receiver.
— Connect the equipment into an outlet on a circuit different from that to
which the receiver is connected.
— Consult the dealer or an experienced radio/TV technician for help.

CAUTION
RISK OF EXPLOSION IF BATTERY IS REPLACED
BY AN INCORRECT TYPE
DISPOSE OF USED BATTERIES ACCORDING
TO THE INSTRUCTIONS

Old electrical appliances must not be disposed of together
with the residual waste, but have to be disposed of
separately. The disposal at the communal collecting point
via private persons is for free. The owner of old appliances
is responsible to bring the appliances to these collecting
points or to similar collection points. With this little
personal effort, you contribute to recycle valuable raw
materials and the treatment of toxic substances.

25