
# 15107-000565 SE8说明书 145\*105MM/70克书写纸/3\*2折页/正反单色印刷

WHAT'S IN THE CARTON

Contents


Confirm that the following parts are included



SE8

**ANC Wireless Headphones** 

# ☐ JJ⊃ USB cable 3.5 mm audio cable Airline headphone adapter Note: If any part of your product is damaged, do not use it. Contact your authorized customer service



# Power off Press and hold of for 3.5 seconds, until the indicator light on red one second and hearing the "power-off" tones.

on blue one second and hearing the "power-on" tones.

HEADPHONE CONTROLS

# Headphone functions

## Media playback and volume functions

The headphone controls are located on the right earcup.

Function	What to do
Play /Pause	Short press the Multi-function⊙button
Skip forward	Long press the O button
Skip backward	Long press the O button
Volume up	Short press the Obutton
Volume down	Short press the Obutton



# **Call functions**

The Multi-function button 
and microphone are located on the back of the right earcup.

Function	What to do
Answer a call	Short press the ⊙ button
End a call	Short press the ⊙ button
Decline an incoming call	Press ⊙ and hold for one 2 seconds
Answer a second incoming call and put the current call on hold	While on a call, press⊙once
Decline a second incoming call and stay on current call	While on a call, press⊙ and hold for 2 seconds
Switch between two calls	With two active calls, press⊙ once



## Noise Cancelling Modes

NOISE CANCELLATION & AMBIENT SOUNR

ncelling mode based on your listening preferences and environment **Ambient Sound Modes** 

Turn on Ambient modes to control how much surrounding noise you let in. With Quick Ambient Mode, you can listen in on street traffic, catch flight announcements, and hear when your kids or coworkers call out to you.

Summary: Turn on the noise Cancellation function of your headphones if you want to listen to music without the interruption of surrounding noise. Turn on Ambient Sound Mode if you want to hear the sounds around you.

# Switch Between Noise Cancellation and Ambient Sound Modes




- 2. Short press the NC button, enable the noise canceling function:
- 3, Short press the NC button again, switch to Ambient Sound Mode;
  4, Short press the NC button again, solitch to Ambient Sound Mode;
  4, Short press the NC button again, both noise canceling function and Ambient Sound Mode is off. Tip: Each press of the NC button changes the function. Loop in turn.

# Active Noise Cancelling

Active Noise Cancelling (ANC) mainly focuses on cancelling out lower frequency sounds like engines, aviation environment, trains, traffic noise, etc., so our valuable customers can focus on their music, movies, or books without being disturbed by outside noises. Our ANC headphones incorporate a microchip that measures ambient sound and generate a waveform that is an exact negative of the ambient sound and mix it with any audio signal our customers desires. Making it possible to listen to audio content without raising the volume excessively. Please do note, ANC does not cancel out noises like snoring, talking, music or high-frequency sounds, etc.

# BATTERY CHARGING




# Notes: • While charging, the battery indicator red. The battery light turns off when the battery is fully charged. • If the power is lower than 10%, you will hear the "Battery Low" tone, prompting every 3 minutes, until the battery is completely used up and automatically shuts down

# Charging time

Allow up to 5 hours to fully charge the headphones.

- When only use Bluetooth without noise cancelling, a full charge powers the headphones for up to 25 hours.
- When use Bluetooth with noise cancelling, a full charge powers the headphones for up to 20 hours.

## STATUS INDICATORS



	Indicator Light Display	System status
	Solid green	Noise cancellation ON
//o <del>j// / \</del>	Indicator Light Display	System status
	Flashing blue and red alternately	Power on & In pairing mode
$\bigcirc      $	Flashing red	Low Battery
	Solid red	Charging in Process
	Solid blue	Fully Charged
(10)	Flashing blue slowly	Paired

Note: If connected to an Apple device, the device displays the headphone battery level near the upper right corner of the screen.

# BLUETOOTH CONNECTIONS

You can connect your mobile device with your headphones using Bluetooth wireless technology.

## Connect using the Bluetooth menu on your mobile device

Note: The devices must be within range (49.2 ft. or 15 m) and powered on.


1.Turn on the headset. If connecting for the first time, the headphone will

**Tip:** Once powered on, the LED flashes blue and red alternately. 2. On your mobile device, enable the Bluetooth feature.

**Tip:** The Bluetooth feature is usually found in the Setting menu.

## 3. Select your headphones from the device list. Choose "SE8" to connect

Tip: Once paired, you hear "Connected" and see the indicator flash blue slowly.





### Disconnect a mobile device

1. Use the Bluetooth menu on your mobile device to disconnect your mobile device. 2. Power off headphones.

## Reconnect a mobile device

When powered on, the headphones try to reconnect with the last-paired device **Note:** The devices must be within range (49.2 ft. or 15 m) and powered on.

2.Connected on your second mobile device.

## Clear the headphone pairing list

Connect another mobile device

Press O and O simultaneously and hold for 3.5 seconds.
 Delete your headphones from the Bluetooth list on your mobile device. All devices are cleared and the headphones are ready to

Solution

Bad Bluetooth connect

No sound

If the Bluetooth signal is weak, out of range or interferes, the Bluetooth® wireless onnection may fail or the sound cuts in and out. Please see the information below to impro

ignal quality and reduce the possibility of interference. The Bluetooth wireless connection may fail or the sound will continue to cut in and out. hese due to weak Bluetooth signals or external signal interference. Please away from any

reference or obstructions.

Sluetooth headphone and device distance is less than 15M, Bluetooth and mobile phone in the same direction. Move your mobile device closer to the headphones.

The battery is running out of power, use it after charging.

Check if the network signal is OK (whether the player is in buffer).

The compatibility between the headphone and the Bluetooth device is not good, replace the rice with a higher Bluetooth version.

Prover on the neadphones and charge the battery.
 Check the state of the status indicators (see page 10).
 Increase the volume on your headphones, your mobile device and music source.
 Slide the Power/Blueboth switch to the right and release to hear the connected device. Make sure you are using the correct device.
 Move your mobile device closer to the headphones and away from any interfacence or obstructions.

Check that headphones and the connected device (i.e., smartphone) are turned on.
Turn up the volume of the connected device if it is too low.
Check the audio settings of the Bluetooth device to make sure the sound comes from the headphones during a call.
Re-establish the connection using the Bluetooth device.

While listening to music with the headphones, stop playback and press the button on the

Due to weak Bluetooth signals or external signal interference. In this case, move away from
wireless routers or microwaves and move your headphone closer to the Bluetooth device.
 Avoid using the headphones for a long time, otherwise the sound will be intermittent,
please reuse after a period of rest.


Even in wired mode, the battery power need to use, the headphones do not support the u

right or left unit to respond to an incoming call.

### WIRED CONNECTIONS

### Connect the audio cable


Use the 3.5 mm cable (provided) to connect a non-wireless device or to continue using the headphones



CARE AND MAINTENANCE

# Store your headphones

Place the headphones flat into the case.



connected by the back-up

Poor sound quality from a

doesn't work

device connected by audio cabl

Your headphones may require periodic cleaning.

• Wipe the outside surfaces with a soft, dry cloth.

• Don't allow moisture to get inside the earcups or the audio input connector.

Notes: • Make sure to power off the headphones when not in use. Before storing the headphones for more than a few months, make sure the battery is fully charged.

Connect another device (see page 11).

. Secure the ends of the USB charging cable.

Try another charging source.
 If your headphones have been exposed to high or low temperatures, let the headphones return to room temperature and try charging again.

· Are the ears all wrapped and re-equipped. Adjust the earpad position to fit your ears. If the

Are the earls an wrapped and re-equipped any upon the earlpad position to it your earls it due armuffs are loose, re-set the ear.
 Eliminate low frequency noise? The noise canceling function is effective in low frequency ranges such as airplanes, trains, offices, near air-conditioning, and is not as effective for higher frequencies, such as human voices.

Make sure that the noise canceling function is turned on.

## Clean the headphones

phones don't power on

TROUBLESHOOTING

• Try connecting another mobile device (see page 11).

Check the state of the status indicators (see page 10).
Charge the battery (see page 9).
Increase the volume on your headphones, mobile device and music app.

Common solutions

If you experience problems with your headphone

Check the state of the status indicators(see page 10).
Disconnect the back-up audio cable.
Disconnect the USB charging cable.
On your mobile device.
Disable the Bluetooth feature and then re-enable.
Delete your SEB from the Bluetooth list on your device. Connect again.
Move your mobile device (loser to the headphones and away from any interference or obstructions. Headphones don't connect Connect another mobile device (see page 11) Visit www.cowinaudio.com to see how-to videos

· Clear the headphone pairing list (see page 11) and connect again

If you could not resolve your issue, see the table below to identify symptoms and solutions to common problems. If you are unable to

Use a different music source.
Connect another mobile device (see page 11).
Sisconnect the second device.
Wove your mobile device closer to the headphones and away from any interference or obstructions. Poor sound quality

Charge the battery.

### Solution FCC STATEMENT Secure the ends of the back-up audio cable.

(1) This device may not cause harmful interference. and . Secure the ends of the back-up audio cable

# (2) This device must accept any interference received, including interference that may cause

undesired operation This equipment has been tested and found to comply with the limits for a Class B digital

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two

device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. — Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver
- Consult the dealer or an experienced radio/ TV technician for help.

Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

反面

