	Issue Department: Bedding Division	Date:	2017-8-15
	System Instruction	Author:	
Instruction of RF54		Edition:	1.1
		Page 1 of 5	

## Instruction of RF54





Figure 1 button of remote

### 1.1 ZG button (button 10 in figure 1)

Click the ZG button, the actuator moves to ZG position, stop when click any button during the movement;

Press and hold the ZG button for 5s, timer LED of remote flashes, the control box records current position as ZG position;

When in the process of moving to memory positions, the head and foot actuators move first,

 <small>A Phoenix Mecano Company</small>	Issue Department: Bedding Division	Date:	2017-8-15
	System Instruction	Author:	
Instruction of RF54		Edition:	1.1
		Page 2 of 5	

then the tilt and lumbar actuators move;

## 1.2 M1 button (button 4 in figure 1)

Click the M1 button, the actuator moves to M1 position, stop when click any button during the movement;

## 1.3 M2 button (button 6 in figure 1)

Click the M2 button, the actuator moves to M2 position, stop when click any button during the movement;

## 1.4 Head up (button 7 in figure 1)

Press and hold HEAD UP button of remote, head actuator moves out, stop when released;

## 1.5 Head down (button 8 in figure 1)

Press and hold HEAD DOWN button of remote, head actuator moves in, stop when released;

## 1.6 Foot up (button 11 in figure 1)


Press and hold FOOT UP button of remote, foot actuator moves out, stop when released;

## 1.7 foot down (button 12 in figure 1)

Press and hold FOOT DOWN button of remote, foot actuator moves in , stop when released;  
When moving to flat position, lumbar actuator and tilt actuator move first, after 500ms, head and foot actuators start moving;

## 1.8 Flat (button 9 in figure 1)

Click FLAT button, the bed goes flat, stop when click any button during the process of going

 <small>A Phoenix Mecano Company</small>	Issue Department: Bedding Division	Date:	2017-8-15
	System Instruction	Author:	
Instruction of RF54		Edition:	1.1
		Page 3 of 5	

flat;

### 1.9 Massage head (button 1 in figure 1)

Click MESSAGE HEAD button, head massage motor switches message intensity, message intensity switches among 0-1-2-3;

### 1.10 Massage FOOT (button 3 in figure 1)

Click MESSAGE FOOT button, head massage motor switches message intensity, message intensity switches among 0-1-2-3;

### 1.11 Massage ON/OFF (button 2 in figure 1)

Click Message ON/OFF button, if the message motors are on, then it turns off message motors, if message motors are off, then it turns on the message motors;

### 1.12 Massage Type (button 5 in figure 1)

Click message type button, to switch the message mode of message motors, message mode switches among type0→type1→type2→type3→type0; this button can only switch the message mode, it can not open message motors;


## FCC warning

### Federal Communications Commission Statement

This device complies with FCC Rules Part 15. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) rules. These limits are

 <small>A Phoenix Mecano Company</small>	Issue Department: Bedding Division	Date:	2017-8-15
	<b>System Instruction</b>	Author:	
<b>Instruction of RF54</b>		Edition:	1.1
		Page 4 of 5	

designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment causes harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by doing one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### **FCC Caution**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

#### **Radiation Exposure Statement:**


This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. To maintain compliance with FCC exposure compliance requirement, please follow operation instruction as documented in this manual.

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. To maintain compliance with ISED exposure compliance requirement, please follow operation instruction as documented in this manual.

Cet équipement est conforme aux limites d'exposition aux rayonnements ISED établies pour un environnement non contrôlé. Les utilisateurs finaux doivent suivre les instructions d'utilisation spécifiques pour satisfaire la conformité d'exposition RF. Pour maintenir la conformité aux exigences de conformité d'exposition ISED, veuillez suivre les instructions d'utilisation comme documenté dans ce manuel.

#### **ISED RSS Warning:**

This device complies with Innovation, Science and Economic Development Canada licence exempt RSS standard(s). Operation is subject to the following two conditions:

 <small>A Phoenix Mecano Company</small>	Issue Department: Bedding Division	Date:	2017-8-15
	<b>System Instruction</b>	Author:	
<b>Instruction of RF54</b>		Edition:	1.1
		Page 5 of 5	

- 
- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radioexempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.