



MERKURY INNOVATIONS **CONFIDENTIAL**

FILE INFORMATION
DATE: 08/22/24
MODEL NUMBER:
TS-WP013-101
TS-WP213-101 (Manual)

PRINTER SPECIFICATIONS
FILE NAME: TS-WPX13-101_Manual_082224_0L.ai
SCALE: 100%
SIZE: W 400mm x H 140mm
PAPER STOCK: 80g Art Paper
INKS: 1/1
Greyscale
PRESS WORK / NOTES: Trim to size, score, fold, & glue in specified areas.
DO NOT print Comments or Dielines.
Physical sample according to specs must be approved by MERKURY before proceeding to production.

CONTACT
MERKURY CHINA:
Perry
perry@merkuryinnovations.com.cn

COMMENTS (Internal reference only)
File created by Jakob
- Please include in all packaging for TS-DW014-101
- Double sided printing
- one folds
- Greyscale

Front



Initial Setup and Pairing

Power On: Press the button once to turn on the device. You'll hear a ringing sound indicating it's ready.

- Pair with Apple Devices:**
- Open the "Find My" app on your iPhone or iPod
 - Tap the "Items" tab.
 - Select "Add New Item" and then choose "Other Supported Items"
 - Select "Smart Tag Device" and tap "Connect."
 - Customize the name for your device and choose an emoji.
 - Agree to register the device to your Apple ID.
 - Tap "Finish" to complete the pairing process

Enabling Lost Mode

- Open "Find My": Go to the "Find My" app on your Apple device
- Select Your Device: Tap the "Items" tab and choose your device from the list
- Enable Lost Mode: Tap "Lost Mode" and follow the on-screen instructions
- Provide your contact information (phone number or email address).
- Confirm the settings and tap "Enable" to activate Lost Mode

Removing the Device

- Open "Find My": Go to the "Find My" app on your Apple device
- Select Your Device: Tap the "Items" tab and choose your device from the list
- Remove Device: Scroll to the bottom and tap "Remove Item "
- Confirm the removal by tapping "Remove "

Important Notes

- **Re-pairing:** If you want to pair the device again within 3 minutes of removing it, you can do so directly using the "Find My" app. If more than 3 minutes have passed, then you must restore it to factory settings.
- If you need to pair the device with a new account or if the original account is removed from "Find My," you'll need to restore the factory settings
- To restore factory settings, quickly remove and reinsert the battery 3 times

Support:
If you are having problems please contact our customer support team for help at support@merkuryinnovations.com
To explore our full selection of products, visit us at www.merkuryinnovations.com

© 2024 Merkury Innovations • 45 Broadway 3rd FL, New York NY 10006. The illustrated product and specifications may differ slightly from those supplied. Apple is trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license. To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. All other trademarks and trade names are those of their respective owners. The illustrated product and specifications may differ slightly from those supplied. **Made in China**

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards

FCC Notice:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna
• Increase the separation between the equipment and receiver
• Consult the dealer or an experienced radio/TV technician for help

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

IMPORTANT: PLEASE READ BEFORE USING THIS PRODUCT