


oraimo
smart accessories



WELCOME GUIDE

* For safety issue, the product remains low capacity during shipping.
Please fully charge the product before initial use!
Please read this Guide carefully before using the product

Product Overview



Basic Product Specifications

Display Screen:	1.69" TFT 240*280
Battery Capacity:	300mAh
Battery Type:	Lithium polymer battery
Standby Time:	7 days
Watch Size:	51.8* 36.8* 12.2mm (Strap Not Included)
Weight:	37.0g (Strap Included)
Material:	ABS/PC/LSR
Waterproof:	IP68

* oraimo Lab test result

EN 01


Setting Up Your Smart Watch

For the best experience we recommend using the Joywear 2 App for iOS and Android.



iOS 9.0 or above
Android 4.4 or above


Setting up the smart watch on your phone To get started
1. Find the Joywear 2 App in one of these locations, depending on your device:



2. Install the App. Note that if you don't have an account with the store you'll be required to create one before you can download the App.


3. When the App is installed, open it and be guided through a series of questions that help you create your account, or login to your existing account.

4. Continue following the onscreen instructions to connect, or pair the product to your phone.




Your account asks for information such as height, weight, and gender to make various calculations such as stride lengths to estimate distance and basal metabolic rate to estimate calorie burn. You can modify your information in Joywear 2-Profile-Me.

EN 02



Use Joywear 2 APP to scan QR code on the watch:



EN 03




If you can't pair successfully, try the following methods:

1. Make sure the BT permission is allowed for the app;
2. Make sure the watch is not connected with another phone;
3. Try turning off and on again the BT switch on your phone;
4. If none of these work, try rebooting your phone and the watch, and repeat the above steps again.

Getting To Know Your Smart Watch

Wrist Placement

For all-day wear, your watch should usually rest a finger's width below your wrist bone and lay flat, as you would normally wear a watch.



Charge Your Watch

Connect the metal contacts on the charging dock to those on the back of the device, then put them on a flat surface.



Connect the charging cradle to a power supply, the device's screen will light up and display the battery level.

EN 03



The charging dock is not water resistant. Wipe the port, metal contacts, and the device dry before charging.

Power On/Off

- When the watch is powered off, charge the watch or long press the home button for 3 seconds to power it on.
- When the watch is turned on, press and hold the side button for 3 seconds. Choose Power Off and tap again to confirm. The watch vibrates and turns off. You can also power off from the "Settings" menu. (Settings - System Settings - Power Off)

Wake Up the Watch

When you're not using this product, the display is off. To wake it up:

- Press the side button.
- Turn your wrist towards you. This function, known as "Raise to Wake", can be turned off in Settings - Raise to wake - Raise to wake. You can also schedule when it's activated during the day.

Using The Clock And Menus

The home screen is a clock. From here you can swipe to see data about your steps, activity time, calories, heart rate, and functions like training modes, weather, message, music, etc.



Connect the charging cradle to a power supply, the device's screen will light up and display the battery level.

EN 04



The charging dock is not water resistant. Wipe the port, metal contacts, and the device dry before charging.

Power On/Off

- When the watch is powered off, charge the watch or long press the home button for 3 seconds to power it on.
- When the watch is turned on, press and hold the side button for 3 seconds. Choose Power Off and tap again to confirm. The watch vibrates and turns off. You can also power off from the "Settings" menu. (Settings - System Settings - Power Off)

Wake Up the Watch

When you're not using this product, the display is off. To wake it up:

- Press the side button.
- Turn your wrist towards you. This function, known as "Raise to Wake", can be turned off in Settings - Raise to wake - Raise to wake. You can also schedule when it's activated during the day.


Using The Clock And Menus

The home screen is a clock. From here you can swipe to see data about your steps, activity time, calories, heart rate, and functions like training modes, weather, message, music, etc.



Connect the charging cradle to a power supply, the device's screen will light up and display the battery level.

EN 04



The charging dock is not water resistant. Wipe the port, metal contacts, and the device dry before charging.

Power On/Off

- When the watch is powered off, charge the watch or long press the home button for 3 seconds to power it on.
- When the watch is turned on, press and hold the side button for 3 seconds. Choose Power Off and tap again to confirm. The watch vibrates and turns off. You can also power off from the "Settings" menu. (Settings - System Settings - Power Off)

Wake Up the Watch

When you're not using this product, the display is off. To wake it up:

- Press the side button.
- Turn your wrist towards you. This function, known as "Raise to Wake", can be turned off in Settings - Raise to wake - Raise to wake. You can also schedule when it's activated during the day.


Using The Clock And Menus

The home screen is a clock. From here you can swipe to see data about your steps, activity time, calories, heart rate, and functions like training modes, weather, message, music, etc.



Connect the charging cradle to a power supply, the device's screen will light up and display the battery level.

EN 05



The charging dock is not water resistant. Wipe the port, metal contacts, and the device dry before charging.

Power On/Off

- When the watch is powered off, charge the watch or long press the home button for 3 seconds to power it on.
- When the watch is turned on, press and hold the side button for 3 seconds. Choose Power Off and tap again to confirm. The watch vibrates and turns off. You can also power off from the "Settings" menu. (Settings - System Settings - Power Off)


Wake Up the Watch

When you're not using this product, the display is off. To wake it up:

- Press the side button.
- Turn your wrist towards you. This function, known as "Raise to Wake", can be turned off in Settings - Raise to wake - Raise to wake. You can also schedule when it's activated during the day.

Using The Clock And Menus

The home screen is a clock. From here you can swipe to see data about your steps, activity time, calories, heart rate, and functions like training modes, weather, message, music, etc.



Connect the charging cradle to a power supply, the device's screen will light up and display the battery level.

EN 06



The charging dock is not water resistant. Wipe the port, metal contacts, and the device dry before charging.

Power On/Off

- When the watch is powered off, charge the watch or long press the home button for 3 seconds to power it on.
- When the watch is turned on, press and hold the side button for 3 seconds. Choose Power Off and tap again to confirm. The watch vibrates and turns off. You can also power off from the "Settings" menu. (Settings - System Settings - Power Off)


Wake Up the Watch

When you're not using this product, the display is off. To wake it up:

- Press the side button.
- Turn your wrist towards you. This function, known as "Raise to Wake", can be turned off in Settings - Raise to wake - Raise to wake. You can also schedule when it's activated during the day.


Using The Clock And Menus

The home screen is a clock. From here you can swipe to see data about your steps, activity time, calories, heart rate, and functions like training modes, weather, message, music, etc.



Connect the charging cradle to a power supply, the device's screen will light up and display the battery level.

EN 07



The charging dock is not water resistant. Wipe the port, metal contacts, and the device dry before charging.

Power On/Off

- When the watch is powered off, charge the watch or long press the home button for 3 seconds to power it on.
- When the watch is turned on, press and hold the side button for 3 seconds. Choose Power Off and tap again to confirm. The watch vibrates and turns off. You can also power off from the "Settings" menu. (Settings - System Settings - Power Off)

Wake Up the Watch

When you're not using this product, the display is off. To wake it up:

- Press the side button.
- Turn your wrist towards you. This function, known as "Raise to Wake", can be turned off in Settings - Raise to wake - Raise to wake. You can also schedule when it's activated during the day.

Using The Clock And Menus

The home screen is a clock. From here you can swipe to see data about your steps, activity time, calories, heart rate, and functions like training modes, weather, message, music, etc.



Connect the charging cradle to a power supply, the device's screen will light up and display the battery level.

EN 08



The charging dock is not water resistant. Wipe the port, metal contacts, and the device dry before charging.

Power On/Off

- When the watch is powered off, charge the watch or long press the home button for 3 seconds to power it on.
- When the watch is turned on, press and hold the side button for 3 seconds. Choose Power Off and tap again to confirm. The watch vibrates and turns off. You can also power off from the "Settings" menu. (Settings - System Settings - Power Off)

Wake Up the Watch

When you're not using this product, the display is off. To wake it up:

- Press the side button.
- Turn your wrist towards you. This function, known as "Raise to Wake", can be turned off in Settings - Raise to wake - Raise to wake. You can also schedule when it's activated during the day.

Using The Clock And Menus

The home screen is a clock. From here you can swipe to see data about your steps, activity time, calories, heart rate, and functions like training modes, weather, message, music, etc.



Connect the charging cradle to a power supply, the device's screen will light up and display the battery level.

EN 09



The charging dock is not water resistant. Wipe the port, metal contacts, and the device dry before charging.

Power On/Off

- When the watch is powered off, charge the watch or long press the home button for 3 seconds to power it on.
- When the watch is turned on, press and hold the side button for 3 seconds. Choose Power Off and tap again to confirm. The watch vibrates and turns off. You can also power off from the "Settings" menu. (Settings - System Settings - Power Off)

Wake Up the Watch

When you're not using this product, the display is off. To wake it up:

- Press the side button.
- Turn your wrist towards you. This function, known as "Raise to Wake", can be turned off in Settings - Raise to wake - Raise to wake. You can also schedule when it's activated during the day.

Using The Clock And Menus

The home screen is a clock. From here you can swipe to see data about your steps, activity time, calories, heart rate, and functions like training modes, weather, message, music, etc.



Connect the charging cradle to a power supply, the device's screen will light up and display the battery level.

EN 10



The charging dock is not water resistant. Wipe the port, metal contacts, and the device dry before charging.

Power On/Off

- When the watch is powered off, charge the watch or long press the home button for 3 seconds to power it on.
- When the watch is turned on, press and hold the side button for 3 seconds. Choose Power Off and tap again to confirm. The watch vibrates and turns off. You can also power off from the "Settings" menu. (Settings - System Settings - Power Off)

Wake Up the Watch

When you're not using this product, the display is off. To wake it up:

- Press the side button.
- Turn your wrist towards you. This function, known as "Raise to Wake", can be turned off in Settings - Raise to wake - Raise to wake. You can also schedule when it's activated during the day.

Using The Clock And Menus

The home screen is a clock. From here you can swipe to see data about your steps, activity time, calories, heart rate, and functions like training modes, weather, message, music, etc.



Connect the charging cradle to a power supply, the device's screen will light up and display the battery level.

EN 10



The charging dock is not water resistant. Wipe the port, metal contacts, and the device dry before charging.

Power On/Off

- When the watch is powered off, charge the watch or long press the home button for 3 seconds to power it on.
- When the watch is turned on, press and hold the side button for 3 seconds. Choose Power Off and tap again to confirm. The watch vibrates and turns off. You can also power off from the "Settings" menu. (Settings - System Settings - Power Off)

Wake Up the Watch

When you're not using this product, the display is off. To wake it up:

- Press the side button.
- Turn your wrist towards you. This function, known as "Raise to Wake", can be turned off in Settings - Raise to wake - Raise to wake. You can also schedule when it's activated during the day.

Using The Clock And Menus

The home screen is a clock. From here you can swipe to see data about your steps, activity time, calories, heart rate, and functions like training modes, weather, message, music, etc.



Connect the charging cradle to a power supply, the device's screen will light up and display the battery level.

EN 10

For more information, please visit:



www.oraimo.com @oraimo_accessories