

Two-in-one wireless fence

1. Instructions for use

- a. Plug in the power supply DC5V
- b. Press the on/off key to indicate the red light is on, and the nixie tube will turn on when there is a number displayed.
- c. Gear adjustment: Press the "+/-" key to adjust the gear, the gears range from 60 feet to 2000 feet.
- d. When the fence is working, the electric shock can be adjusted.
- e. Mode conversion: There are three dog training modes, namely electric shock, vibration and sound.
- f. The digital tube has a battery power display, the battery can be recharged, and it can be used indoors and outdoors.

2. Receiver

- a. Press the on/off button to indicate that the red light is on and the device is turned on.
- b. Plug in the DC5V power supply when charging, the red light flashes quickly, and there will be a warning sound when the battery is short, and then it will automatically shut down.
- c. Vibration reminder first, then electrostatic shock.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.