

Multiple Colors Available, Match Your Style

SMART Quick start manual

SMART

Compact Color
Screen
ELRS
Transmitter

Full
function
small
size
radio



Space Gray

Platinum White

Lily Pink

Deco Yellow

Mint Green


Cyan Blue

Cold Purple


JumperTX



Brief introduction




Menu I




1. Press and hold the "O" button to enter the menu. Use the left-side directional buttons (Up, Down, Left, Right) to navigate through the menu. Adjust settings using the "+" and "-" buttons. The "O" button confirms selections, and the "X" button exits. Press and hold the "X" button to enter the flight controller switching menu.

Servo Travel Settings



2. Press and hold the "O" button to enter the travel adjustment settings. Press the "O" button again to toggle between normal and reversed direction. Use the "+" and "-" buttons to adjust the travel range. The "X" button exits. Press and hold the "X" button to enter the channel mapping menu. Use the left-side directional buttons (Up, Down, Left, Right) to select the channel to be mapped. Use the "+" and "-" buttons to change the input source. The "X" button exits.

Mixer Selection



- Press and hold the "O" button to enter the mixing settings. Use the left-side directional buttons (Up, Down, Left, Right) to set the direction (normal/reversed) and travel range for CH1-CH4. Press the "O" button again to toggle between normal and reversed direction. Use the "+" and "-" buttons to adjust the travel range. The "X" button exits.

System Menu



- Configure settings as needed.
Note: If "Idle Alarm" is enabled, the transmitter will automatically shut down after the set "Alarm Time" is reached.
Note: If "Low Voltage Alarm" is enabled, the transmitter will automatically shut down when the voltage drops below the "Alarm Voltage."
For further updates, please follow our official announcements.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.