





Quick Start Guide

Velox™ Magnetic Wireless Charging
Air Vent Mount

iottie

Product Installation

1



EN Attach Velox™ mount to your vehicle's air vent.

FR Fixez le support Velox sur la bouche d'aération de votre véhicule.


GE Bringen Sie die Velox-Halterung an der Lüftung Ihres Fahrzeugs an.

IT Fissa il supporto Velox alla presa d'aria della tua automobile.

ES Fije el soporte Velox a la ventila de aire de su vehículo.

JP Veloxマウントを車両のエアベントに取り付けます。

2



Connect the USB-C cable to the 12V adaptor included in the box.

Branchez le câble USB-C à l'adaptateur 12V inclus dans le boîtier.

Verbinden Sie das USB-C-Kabel dem in der Verpackung enthaltenen 12V Adapter.

Collega il cavo USB-C all'adattatore 12V incluso nella confezione.

Conecte el cable USB-C al adaptador de 12V incluido en la caja.

USB-Cケーブルを同梱の12Vアダプターに接続します。

EN Only compatible with MagSafe iPhone series and accessories. / **FR** Uniquement compatible avec la série et les accessoires iPhone Magsafe. / **GE** Ausschließlich kompatibel mit der MagSafe iPhone-Reihe und dem entsprechenden Zubehör. / **IT** Compatibile solo con la serie MagSafe di iPhone e accessori. / **ES** Solo es compatible con la serie y accesorios MagSafe para iPhone. / **JP** MagSafe iPhoneシリーズと付属品のみ対応します。

We'd love to hear from you!

Don't forget to leave a review
Follow @iottie for the latest news and updates!
Need help? Reach out to us directly by emailing:
cs@iottie.com
Please visit our website for more information
www.iottie.com

<https://www.iottie.com/manual/veloxwirelessavm>

Scan QR code for full manual



FCC Caution

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Radiation Exposure Statement

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2. This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.
3. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

IC Warning

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device has been evaluated to meet general RF exposure requirement. To maintain compliance with RSS-102 — Radio Frequency (RF) Exposure guidelines, this equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body. Le dispositif a été évalué à répondre général rf exposition exigence, pour maintenir la conformité avec les directives d'exposition du RSS-102-Radio Fréquence (RF). ce matériel doit être installé et exploité à une distance minimale de 20 cm entre le radiateur et votre corps.