



iCam365快速操作手册

WIFI摄像机

20210709

ENGLISH DESCRIPTION ON THE BACK

A 连接设备




下载APP
使用手机的“扫一扫”功能扫描二维码，下载并安装“iCam365”APP





连接电源
将设备连接电源，持续1分钟左右直到显示屏亮

B 添加设备



C 功能说明



D 常见问题

问题	原因/解决方案
添加设备不能成功怎么办?	检查WiFi网络是否连接,并可以正确连接网络,然后尝试重新添加,或尝试将摄像头重置一次。
如何将录像下载到手机中?	在回放时点击“下载”按钮,等待一段后会自动开始下载,录像文件将保存在手机。
添加设备失败怎么办?	关闭手机网络重启之后,或尝试将摄像头重置后重新添加,如果重置后依然失败,请在APP中查找故障排除,或联系客服。
存储空间满了,如何处理?	关闭手机设置,摄像头存储空间小于等于500M时会自动删除最近的录像文件。
存储卡显示无存储卡或故障	1.摄像头不支持该格式,请换用支持的格式,或重新格式化。 2.摄像头故障,请联系厂家售后。 3.摄像头卡接触不良,请重新插卡。
看不到直播画面怎么办?	确认摄像头是否支持该格式,或尝试将摄像头重置,如未重置手机设置中关闭“省电模式”和“后台运行”设置,或尝试将摄像头重置。

A Connect the device



Download the app
Use the "Scan" function of your mobile phone to scan the QR code, download and install the "iCam365" APP











Connect power
Connect the device to the power supply and wait for about 1 minute

B Add device



C Function Description



D Common problem

Problems	Solution
What should I do if the device is unsuccessfully added?	Check whether the WiFi password is correct, and the network can be connected correctly. Then RESET the camera, and add it again after completion.
How to download video?	Click the "Record Screen" button during playback, and click the red button after recording, and the video file will be saved to the phone.
What if the display device is offline?	First confirm whether the power supply and network are normal, and there is no problem before powering off the camera and restarting it. If the connection is still disconnected.
The memory card is full, what should I do?	No manual processing is required. When the remaining memory card capacity is less than or equal to 500M, the camera will automatically overwrite the oldest video file.
The memory card shows no memory card or abnormal	1. The camera does not support hot swapping. When inserting a memory card, it needs to be powered off. Please contact the camera. 2. The memory card is still not recognized after restarting the camera, please replace with a new card and try again. 3. If the new card is still not recognized, the card slot may be damaged or the card is faulty. Contact the supplier to replace the device.
What should I do if I cannot receive the warning message?	Confirm whether the system has turned off the message push permission of iCam365. If it is turned off, please turn on the "message notification" permission in the phone settings, and check whether the message push is turned off in the device settings. Alarm messages are stored for up to 7 days.

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter.

RF Exposure Statement: To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum distance of 20cm between your body. This device and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter.