*** BlackBerry

BlackBerry Limited

440 Phillip Street, Waterloo, Ontario, Canada Tel: (519) 888-7465 ; Fax: (519) 888-6906

| | Date | | | | | ate: November 2, 2014 | |
|--|---|------------------|------------------------|-------------------------|----------------------------|-----------------------------|--|
| We have declared below featured for device identified as FCC ID: L6ARHH150LW | | | | | | | |
| (1) DFS Device ☐ Master, ☐ Client with Radar detection capability , ☐ Client without radar detection capability, ☐ N/A | | | | | | | |
| (2) | Passive Scanning capability | | | | | | |
| | Frequency Band (MHz) | Scanning Plan | Ad Hoc Mode capability | Access point capability | WiFi Direct Group Owner | WiFi Direct Group Client | |
| | 2412 – 2462 | Passive | No | No | Yes | Yes | |
| | 5745 – 5825 | Passive | No | No | Yes | Yes | |
| | 5180 - 5240 | Passive | No | No | Yes | Yes | |
| | 5260 - 5320 | Passive | No | No | No | No | |
| | 5500 - 5700 | Passive | No | No | No | No | |
| (4) | If yes, pls explain how it was implemented: (pls also help to provide detail of options for each country selection) Transmission in 5600 MHz to 5650 MHz is notched - Yes, □ No | | | | | | |
| (5) | Meet Part 15.202 requirement - ☑ Yes, ☐ No, * A master device is defined as a device operating in a mode in which it has the capability to transmit without receiving an enabling signal. In this mode it is able to select a channel and initiate a network by sending enabling signals to other devices * A client device is defined as a device operating in a mode in which the transmissions of the device are under control of the master. A device in client mode is not able to initiate a network. | | | | | | |
| (6) | For client devices that have software configuration control to operate in different modes (active scanning in some and passive scanning in others) in different bands (devices with multiple equipment classes or those that operate on non-DFS frequencies) or modular devices which configure the modes of operations through software, the application must provide software and operations description on how the software and / or hardware is implemented to ensure that proper operations modes can not be modified by end user or an installer. | | | | | | |
| | The software and configuration tables for permissible channels and power levels is stored in persistent, non-volatile memory that cannot be modified by the user. Only BlackBerry can modify this software. | | | | | | |
| | Sincerely, | | | | | | |
| | Masuel Altry. | | | | | | |
| | | | | | | | |

Masud S. Attayi, P. Eng. Manager, Regulatory Certification EMC, Radio and RF Compliance Email: mattayi@blackberry.com